## GE JB970SB Oven Timer Help Topic

## Introduction

This guide shows you how to use the timer function on the GE Profile Performance Series JB970SB Oven.

## **Task Completion Steps**

- 1. Press the button on the left of the display labeled 'Timer'.
- 2. Adjust the hour and minute buttons until the display matches desired timer amount.
  - a. Note: The timer displays hours and minutes, not seconds.
- 3. Once you set the time, wait until ':' stops blinking.
  - a. Note: To turn off the timer, press the timer button again.

## **Additional Support**

For detailed product instruction and help, visit

www.GEprofileperformanceoven.com/instruction.