
Softroot

From nookDevs

- Warning: nookDevs.com is not liable if you screw up during the root process. kthxbai
- Warning: This will probably (probably = actually) void your warranty, nookDevs.com is not liable for that either in any way shape or form.
- Warning: What you are about to do should only be undertaken by a competent person, not your pet monkey Guenter, even if he has a small hat (Futurama (https://web.archive.org/web/20140819222710/http://en.wikipedia.org/wiki/Mars University))
- Warning: Make sure you read the FULL page BEFORE starting anything to confirm you know what you are getting into!
- Warning: By following the instructions below you release nookDevs and all related parties from any and all liability and damages as a result of this process. We can help you if you run into problems but we help at OUR discretion.

To start the rooting process please scroll down...





Warning: If your Nook serial number begins with **1003** or above and is running firmware 1.4.1 or higher, do *not* do the procedure below. Instead go to Rooting New Hardware for alternate methods.

Contents

- 1 What The Softroot is
- 2 What's in the Softroot

- 3 How Do I Use It
 - 3.1 Pre-requisites
 - 3.2 Steps
- 4 How to Go Back to Stock Firmware

What The Softroot is

The NookDevs.com Softroot/ROM is a custom tailored firmware image for all versions of the Barnes and Noble Nook.

What's in the Softroot

- ADB over USB. For more information see: ADB Over USB
- NookLibrary 0.1.0 Allows for better organization of sideloaded books with enhanced sorting abilities.
- NookBrowser 0.0.9 Predates the official browser, some different functionality.
- NookFileManager 0.0.2 Allows you to deal with filesystem operations without needing ADB.
- Nooklets (rev:3) Allows for mini javascript/web games to be easily made for the nook.
- Trook (rev:68) RSS Reader, Allows syncing with Calibre
- mynook.ru Launcher This allows for 3rd party applications to be installed and executed.
- Non-Market App Fixes The Android system was modified to allow non-market apps to be install/upgraded
- Helper Scripts A minimal amount of helper scripts have been written to help with Softroot/ROM upgrades.

How Do I Use It

Pre-requisites

- You need a B&N nook (with battery charged to at least 20%, preferably fully charged).
 - This nook must not have a serial number starting with 1003 or higher. If yours does, please go to Rooting New Hardware instead.
- You need a 128MB-or-higher microSD card with a single, FAT32-formatted partition.

Steps

Skip to Step #4 if you're already using a rooted nook.

1. Download the official 1.0.0 signed update download

(https://web.archive.org/web/20140819222710/http://www.nookdevs.com/dl/1.0/signed_bravo_update.dat) mirror (https://web.archive.org/web/20140819222710/http://www.multiupload.com/10EOGCL46N) mirror2 (https://web.archive.org/web/20140819222710/http://uploading.com/files/3fbe2539/signed_bravo_update.1.0.0.dat) mirror3 (https://web.archive.org/web/20140819222710/http://www.filefactory.com/file/33nvid53mlm7/n/signed_bravo_update.1.0.0.dat)

SHA1SUM: 84287D73B70E98DA6A6AF9F362B31E96D4E6EEA4

Barnes and Noble has likely introduced a new hardware revision which bricks your unit if you install their official 1.0.0 Firmware (A step needed to root). As of right now, Nooks with serial #s starting with 1003 AND HIGHER (running firmware 1.4.1) cannot be rooted using this method, and should NOT be attempted. See Rooting New Hardware for more details.

- 2. Copy 1.0.0 signed update to your nook's internal SDcard (should be named NOOK)
- 3. Go to the home screen, your e-ink screen will have a notification saying it's reading the update, your nook will reboot by itself and 1.0.0 will install to your nook.

- 4. Download the NookDevs.com (perfinion's) 2.5.1 (B&N:1.5.0) Softroot/ROM download (https://web.archive.org/web/20140819222710/http://www.feise.com/~jfeise/Downloads/bravo_update-2.5.1.dat)
 - SHA1SUM: 438D387126530E08DE896BB4A4A25E2F2725F430
- 5. Copy the NookDevs.com 2.5.1 Softroot/ROM to your external SDcard (The one that isn't named NOOK). And change its name to "bravo_update.dat".
- 6. Hold the power until your e-ink screen goes off.
- 7. Press and hold the "<" button on the right side of the nook, and then press and release the power button, while continuing to hold the "<" button.
- 8. You can release "<" once a screen appears indicating that your device is updating. Wait through the entire process and when you see a launcher screen, **reboot once more**.
- 9. After your nook boots, hold the touchscreen portion down to pull up the launcher menu. You can click "+" to add apps to the main screen here.
- 10. You're all done, now go watch some TV.
 - Calibre Users: See Calibre for a late fix to your nook not being recognized.
 - Attention Chrome users: if instead of the bravo_update.dat and signed_bravo_update.dat you end up with bravo_update.dat.zip and signed_bravo_update.dat.zip accordingly, DO NOT UNZIP these files, you will just need to rename them to bravo update.dat and signed bravo update.dat.
 - IMPORTANT: Make sure you do the reboot as detailed in step #8, or else don't even ask us for help.

Visit us on our IRC channel if you have issues.

How to Go Back to Stock Firmware

Perform steps 1-3 of the softrooting section, then follow the official upgrade instructions at Barnes and Noble's support site here (https://web.archive.org/web/20140819222710/http://www.barnesandnoble.com/nook/support/?cds2Pid=30195) . All 3rd party apps and settings will be removed by installing the official update.

Retrieved from "http://nookdevs.com/Softroot" Category: NookClassic

- This page was last modified on 3 June 2012, at 19:26.
- Content is available under Creative Commons Attribution-Noncommercial-Share License.