INSTALLATION INSTRUCTIONS

Instucciones de instalacion

WHEN INSTALLING OVER NEW HANDY POST NO-DIG SUPPORT

15/8" x 72" Galvanized Steel Pipe with (2) Spacers



- Step 1 Locate the desired spot for your new Handy Post. Be fairly certain there won't be rock or roots below the ground surface.
- Step 2 Slide your two Black Spacers together in the middle of the pipe (3ft off each end). Slightly tighten to temporarily secure.
- Step 3 Drive the Pipe with a T-Post Driver or small Sledge Hammer (use ladder if necessary), keeping the pipe as level as possible. Note: It is recommended to drive the Pipe a minimum of 24" in the ground. 30" is preferred. Note: Make sure the Pipe is not more than 52" above ground when finished.
- Step 4 Loosen the bolts on each Black Spacer and slide one down to 12" above the ground and the other up to 12" from top of Pipe.
- Step 5 Square both Spacers the same so the Handy Post will face the proper direction.
- Step 6 Tighten the bolts on each Black Spacer firmly with your wrench.
- Step 7 Slide the vinyl 4"x4"x54" sleeve over the Pipe and Spacers until it rests on the ground.
- Step 8 Use (1) screw from the Handy Post Kit and place it just below the lower Spacer (11.5" off ground) in the rear of the sleeve.
 Note: The screw will only be going through the vinyl, but it will keep the sleeve from up lifting by hitting the Spacer.
- Step 9 Bring the 5"x5"x24" vinyl arm down over the vertical sleeve by inserting through both 4" square holes.
- Step 10 You can locate the arm anywhere along the upright. Check with your local Post Office for mailbox height regulations.
- Step 11 Use (4) screws from the Handy Post Kit to secure the arm in the pre-drilled holes. Two on each side.
 CAUTION: Do not over tighten the screws. Once the vinyl begins to indent, back the screw off until the vinyl is smooth.
- If you are using the Handy Post as a *Sign* or *Planter* Post, secure the additional cap (included) with a touch of PVC cement. **CAUTION:** Be careful not to allow cement/glue to get on the outside of the Arm or Cap, as it will turn yellow from the sun.
- Visit <u>www.thehandypost.com</u> for Optional Enhancements and photos of Handy Post installations.
- **WARNING**: When attaching a mailbox to the Handy Post arm, use screws that do not protrude over ¼" inside the arm. This can lead to interference with objects being placed inside the arm, or can cause injury when reaching inside the arm.