Liberty & Statesville Assembly

MIS002

General Information:


- Read instructions carefully before beginning assembly.
 - Identify each component from material list.
- Do not use excessive force when assembling components.
- high-pressure water. To clean this product, for best results use a soap solution and
- In the event of missing or defective parts, please call our customer service department.

Liberty Mail Post Materials List:


Quantity		0000	
Part # Description	1 Decorative post2 Mailbox arm	Hardware Pack Includes: 3 1/4" x 3" galvanized lag bolt 4 5/16" galvanized flat washer 5 #10 x 3" stainless steel screw 6 Plastic snap cap	7 4x4 Wood Post not included (84" length recommended)

Tools Required:


- Cordless drill
 - Phillips drill bit
- 7/16" socket wrench - Tape measure
- Level
 - Shovel



- 4x4 wood post, mailbox, and mailbox mounting hardware NOT included with any Mayne mail posts
 - Medium or large mailbox recommended (up to 16lbs), heavier mailboxes can be reinforced by securing 2 screws through the back of the mailbox directly into the post



post. Once the concrete has been given time to cure wood post. Leave 48" exposed above ground. Fill in the hole with pre-mix concrete (not included) and level the wood Dig a 36" deep hole in the desired location and insert a 4x4 proceed to STEP 2.





Mail Post

Liberty


Slip the decorative post (part 1) over the wood post ensuring that the base sits flush with the ground.

Optional Ground Screw: Twist the screw into the ground and attach a 4x4 post (approx. 48" length, not included) with the 5x lag bolts provided. Slide the decorative post







(part 3) with flat washers (part 4) for the top and two 3" screws (part 5) in the bottom of the arm. Plastic snap caps (part 6) are provided to cover the screw heads.



Please note that the pre-cut hole in the bottom of the post is cut closest to the front face of the mail post. This is imporant since the mailbox arm must be installed on this same face.



cated in STEP 2, the wood post slips inside the decorapanels. Notice the location of the wood post. As indi-Align the mailbox arm (part 2) with the post as shown The arm is notched to fit flush with the inset tive post closest to the front face. above.



Pre-drill 4 holes with a 3/8" drill bit through the mailbox and paper holder arm as shown above. Using a nut, bolt, and tighten. 2" bolts are recommended (mailbox and mailbox washer combination secure the mailbox to the arm and mounting hardware not included).

Instructions Liberty & Statesville Assembly

MIS002

General Information:


- Read instructions carefully before beginning assembly.
 - Identify each component from material list.
- Do not use excessive force when assembling components.
- high-pressure water. • To clean this product, for best results use a soap solution and
- In the event of missing or defective parts, please call our customer service department.

Statesville Mail Post Materials List:


Part #	Part # Description	Quantity	
_	Decorative post	_	
2	Post Cap	_	
က	Mailbox arm	~	
Hardw	Hardware Dack Includes:		
4	1/4" x 3" galvanized lag bolt	2	
2	#10 x 3" stainless steel screw	2	
9	Plastic snap cap	2	
7	#8 x 1 1/2" stainless steel screw	2	
∞	4x4 Wood Post not included		7
	(82" length recommended)		

Tools Required:


- Cordless drill
- Phillips drill bit
- 7/16" socket wrench - Tape measure
 - - Level
 - Shovel



- 4x4 wood post, mailbox, and mailbox mounting hardware NOT included with any Mayne mail posts
- heavier mailboxes can be reinforced by securing 2 screws Medium or large mailbox recommended (up to 16lbs), through the back of the mailbox directly into the post.




post. Once the concrete has been given time to cure proceed to STEP 2. wood post. Leave 46" exposed above ground. Fill in the hole with pre-mix concrete (not included) and level the wood Dig a 36" deep hole in the desired location and insert a 4x4




Statesville Mail Post Slip the decorative post (part 1) over the wood post Optional Ground Screw: Twist the screw into the ground and attach a 4x4 post (approx. 48" length, not included) Slide the decorative post ensuring that the base sits flush with the ground. with the 5x lag bolts provided.


over the 4x4.




Install the post cap (part 2) by aligning the notches. Use the 2" screw (part 7) to secure the cap in place. A starter hole is molded on the rim of the cap to indicate the proper screw location.



Please note that the pre-cut hole in the bottom of the post is cut closest to the front face of the mail post. This is imporant since the mailbox arm must be installed on this same face.



the top and two 3" screws (part 5) in the bottom. Plastic above. Secure the arm with two 3" lag bolts (part 4) at Align the mailbox arm (part 2) with the post as shown snap caps are provided to cover the screw heads.



paper holder arm as shown above. Using a nut, bolt, and washer combination secure the mailbox to the arm and tighten. 2" bolts are recommended (mailbox and mailbox Pre-drill 4 holes with a 3/8" drill bit through the mailbox and mounting hardware not included).