



INSERT ARROW TIP AND FEATHER END INTO TUBE

FEATHER END

Predrill holes at A&B In bottom of tube – add screws

TIP: Use a nail or center punch to locate drill hole.

Do not over tighten screws.

Factor