
FIELD CONVERSION FOR 1118E ARROW LOCK DOOR SECURITY UPGRADE KIT



CONVERSION PROCEDURE

- 1.OPEN COLLECTION DOOR
- 2.PLACE NEW LATCH BRACKET OVER EXISTING BRACKET CENTERING SQUARE HOLES
- 3.CLAMP NEW BRACKET ONTO EXISTING BRACKET WITH LOCKING PLIERS.
- 4.DRILL TOP RIVET HOLE USING A .196 DRILL BIT
- 5.RIVET TOP BRACKET HOLE USING 3/16 RIVET PROVIDED
- 6.DRILL BOTTOM RIVET HOLE WITH NEW BRACKET CENTERED OVER EXISTING BRACKET
- 7. RIVET BOTTOM BRACKET HOLE USING 3/16 RIVET PROVIDED



CS5601

THIS DRAWING IS THE SOLE PROPERTY OF AUTH-FLORENCE MANUFACTURING WHO CLAIMS PROPRIETARY RIGHTSIN THE MATERIAL DISCLOSED. IT IS SUBJECT IN CONTIDENCE FOR ENGINEERING INFORMATION ONLY AND MAY NOT BE COPIED OR USED FOR INFORMATION OR MANUFACTURE OF ANYTHING SHOWN WITHOUT SPECIFIC PERMISSION FROM AUTH-FLORENCE MANUFACTURING. COPYRIGHT AUTH-FLORENCE MANUFACTURING.