
Newspaper Holder Instructions Introduction


Congratulations on the purchase of your mailbox newspaper holder. Our newspaper holder is constructed of 16 gauge galvanized, powder coated steel. The mounting bracket is 14 gauge galvanized, powder coated steel. The mailbox newspaper holder is designed to be used in conjunction with the curbside mailbox locking mailbox, a mailbox post, and/or and one of our spreaders. When mounted with a single mailbox that is mounted on an individual post, the newspaper holder can hang on either side of the post. When mounting three newspaper holders on a triple spreader, the center newspaper holder will have to sit off to one side of the post while the other holders will lie directly underneath their respective curbside mailbox. When using a double or quad spreader, all the newspaper holders will mount directly centered under each box.

Step 1

If you are mounting this newspaper holder on our post with a single mailbox or you are mounting it under the center mail box on a triple spreader, see figure 1A. If you are mounting this newspaper holder underneath a double, quad spreader, or on the outer edges of a triple spreader see figure 1B.




Center the four rubber washers over the 4 holes in the top of the holder that are the closest to the front opening. Line up the circular holes in the bracket with the holes on the rubber washers as shown in figure 1A. (Note: you can rotate the bracket 180 degrees depending on if you want your newspaper holder on the left or the right side of the post)




Center the 4 rubber washers over the 4 holes in the top which are closest to the rear of the newspaper holder. Line up the 4 circular holes in the bracket with the holes on the rubber washers. Make sure the elongated holes in the bracket are centered over the newspaper holder as shown in figure 1B.


Step2

Insert the four stainless steel machine screws through the top and into the newspaper holder as displayed in figure 2A and 28. While pressing each screw down with your thumb, finger tighten the stainless steel nuts, flange first, on the inside of the newspaper holder. Using a #2 Phillips screw driver, tighten each of these screws.







Remove the 4 rubber plugs and the tube of grease from the hardware kit. Thoroughly coat the smallest side of the plugs with grease and insert them into the holes on the top of the newspaper holder that are not being used. This will aid in preventing water from entering your newspaper holder.



Step4A

When mounting the newspaper holder on a single post simply align the elongated holes on the newspaper bracket with the holes with the top of the post figure 4A. Align the holes in the mounting plate from the mailbox on top. Then using the machine screws that came with the post to secure the base plate as well as the newspaper holder to the post using a 13mm socket or wrench. Note: Use these instructions to mount the center newspaper holder on the triple spreader unit. The only difference is that the spreader unit should be placed between the mounting plate and the newspaper holder bracket.





Step4B

Use these instructions to mount a newspaper holder to our mailbox spreader plates (with the exception of the center of a triple spreader). Mount the spreader plate to the post æ described in the spreader plate installation instructions. Align the elongated holes on the newspaper holder bracket with the top of the post. Then align the holes on the mounting plate from the mailbox with the others æ detailed in figure 48. Then using the machine screws that came with the spreader plate, secure the assembly using a 13mm socket or wrench æ displayed.

