Parcel Drop – 4955

Installation Instructions

With a rugged all aluminum construction, Salsbury's 4955 parcel drop will provide years of maintenance free service.

Notes

- 1. Wall opening and lumber frame must be square.
- 2. Parcel drops should be shielded from direct weather conditions.
- **3.** Hardware is not included to install units into rough opening.
- 4. Customer to supply parcel receiving receptacle for parcel drop.

Installation Instructions

- 1. It is recommended that the parcel drop be unpacked and reviewed before construction of the rough opening and support framing. The parcel drop is shipped fully assembled.
- **2**. Using standard construction framing methods, frame wall according to the rough opening dimensions provided. The unit is designed to fit between studs on 16" centers.
- **3**. Place unit in rough opening and securely fasten to the support framing with screws through the holes provided.

Caution: Do not deform, force, or twist the frame to fit an incorrect rough opening or against an irregular surface, as this will affect the alignment of the assembly.

