
F2 ETCS Kernel
F2.7 SpeedSupervision_Integration
API_Odometry
API_persistentData
odometry
NationalValues
F2.1 Manage_TrackSideInformat...
ApplyServiceBrake
Service_brake_requested_by_modes_and_levels
F2.5 ManageLevelAndMode
Service_Brake_Command
EB_Requested
Emergency_brake_requested_by_modes_and_levels
brakeCmd
F2.11 manageDMI_Output
inBrakeCommand
inSpeedSupervision
F2.6 calculateTrainPosition
trainPosition
TrainPosition
sdmToDMI
F2.3 trainData
actualTrainData
trainData
trainProps
F2.10 manageDMI_Input
fromDMI_TrainRunningNumber
dataFromTrackAtlas
F2.4 TrackAtlas
preindicationLocation
to_Supervision