

Table of Contents

1.	Introduction
2.	What's in the Box
2.1	Get Familiar with Your ZipVac
3.	Setup
3.1	Using the Vacuum
3.2	Cleaning the Vacuum
3.3	General Tips
3.4	Installing the Roller Brush Cover
4.	Precautions
4.1	Specifications



Thank you for choosing one of our exciting and innovative products. We strive to bring you the latest technology, providing lifelong value and keeping you ahead.

Vacuuming shouldn't feel like a workout—especially when only dealing with small cleaning tasks. This super-lightweight, portable vacuum switches from a traditional vacuum cleaner to a handheld vacuum cleaner in seconds. A simple, convenient solution to your basic vacuum cleaner needs is right here.

- \cdot Makes cleaning a breeze with a super-lightweight design weighing under 5lbs.
- \cdot Quickly switches from traditional vacuum cleaner to handheld vacuum cleaner.
- · Included crevice tool lets you vacuum those hard-to-reach places.

Get ready to clean in FLOOR WHEEL DRIVE!



2 What's in the Box

Your new ZipVac is easy and quick to assemble. Let's start with all the parts you will be taking out of the box:

Handheld Vacuum Base

HEPA Filter

Extender Handle

Large Dustbin

Slim Nozzle Attachment

Floor Roller Brush

Instruction Manual







3 Setup

- 1. Insert the handle into the top of the vacuum and secure with the release clip.
- 2. Attach the floor nozzle or the crevice tool to the bottom of the vacuum.

3.1 Using the Vacuum

- There are two ways to clean with the vacuum—standard mode using the floor nozzle or handheld mode using the crevice tool.
- To switch to handheld mode, detach the handle from the vacuum unit by undoing the release clip and pulling it out. Press the release clip down into the vacuum unit to hide it.
- Remove the floor nozzle from the dustbin's suction component and attach the crevice tool instead.
- 2. Use the wire cord to plug the vacuum into the nearest wall outlet.
- The power switch is located on the handheld vacuum base. "I" powers ON the vacuum, "O" turns the vacuum OFF.
- 4. Start cleaning!

3.2 Cleaning the Vacuum

Dustbin

- 1. Use the release clip on the bottom of the dustbin to empty dust.
 - · Remove any attachments from the dustbin for an easier clean.

HEPA Filter

 Use the release clip on the handheld vacuum base to open the dustbin and remove the HEPA filter.

Continued...

- 2. Wash the HEPA filter under running water and let air dry.
 - If you are replacing the HEPA filter, there is no need to wash it!
 Throw the old one out and insert a new one instead.
- 3. Make sure the HEPA filter is completely dry before re-inserting.

3.3 General Tips

- The floor nozzle and wheels can sometimes become jammed, in which case
 it will need to be cleaned to maintain maximum effectiveness. To do this, be
 sure that the vacuum is powered off and carefully remove anything that has
 become entangled in the floor nozzle or wheels.
- \cdot The HEPA filter should be cleaned at least twice a year, or when becoming visibly soiled.
- \cdot The crevice tool is best used for corners, edges, radiators, drawers, etc.

4. Precautions

- 1. Always operate the vacuum with the dustbin and HEPA filter installed.
- 2. Unplug the vacuum before cleaning.
- 3. Be sure to not let the dustbin become too full.
- 4. Clean the HEPA filter by hand under running water only.
- 5. Do not use things like a hair dryer to dry the HEPA filter. Air dry only.
- 6. Unplug vacuum while not in use.
- 7. Do not use outdoors or on wet surfaces.
- 8. Keep away from children.
- 9. Do not use with damaged cord or plug.
- Return to authorized service center if the vacuum is not working, has been dropped, damaged, left outdoors, or dropped in water.
- Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners.
- 12. Be sure to keep the air intakes clean from dust, lint, hair, or anything else that may block or reduce airflow.
- 13. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- 14. Do not handle plug with wet hands.
- 15. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- 16. Turn vacuum off before unplugging.
- 17. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
- Do not vacuum anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

0 14! 1!
Specifications

Power 400W MAX

Suction power >=12KPA

Size : 44.4 x 5.9 9.8 inches

Rated Voltage : 110-120V 50-60HZ

Dustbin Capacity 1.5L

Noise <=78 DB

Weight About 4.5lbs

IonVac ZipVac Item No. 8200. Distributed by tzumi inc. NY, NY, 10016.

©Copyright 2021 tzumi. All Rights Reserved. Made In China.

All pictures shown are for illustration purpose only.

Actual product may vary due to product enhancement.

If you have any questions or need support setting up or using your ZipVac, email us at support@tzumi.com or call 1-855-GO-TZUMI

For more details on the ionVac family of products or to check out more brilliant innovations visit; www.tzumi.com.

