

## EXTERNAL SIGNALS

The following signals must be integrated into all designs using the design block:

Signals

—(EXT\_I2C\_SCL/1.5G) —(EXT\_I2C\_SDA/1.5G)

Note: Additional I2C pull—up resistors required to +3V3

-\DW\_SYNC/1.10C

-(INTERRUPT/1.5F)

Antennas

RF1/1.6A

Guarantee 120° offset in-between antennas to maximize polarization difference and antenna diversity

RF2/1.6B

RF traces should respect the keepout zones and be surrounded by a via shield. Furthermore, try to keep them as short and straight as possible

Power Supply

+3V3/1.10K

Be aware that the DecaWave is very sensitive regarding its power supply.

We suggest using the "MAX8887EZK33+T" from Maxim Integrated. You can find a reference layout at github.com/lab11/polypoint/pcb/tritag.

TriPoint

REV:

Author: Andreas Biri

Date: 17.07.18 22:17

Sheet: 2/2