CV - Capacitance vs Voltage FBK-UFSD4 W18 GR3_0 T9 4x6 - Pixel Row 0 Column 0; Run: CVIV-Run0183

100p Is Coarse **→** True **→** False 80p Capacitance [F] 60p 40p 20p 10 20 0 30 40 50 60 Bias Voltage [V]