IVs - Current vs Voltage

FBK-UFSD4 W18 GR3_0 T9 4x6 - Pixel Row 0 Column 0; Run: CVIV-Run0000 - First IV Run

