IV - Current vs Voltage

FBK-UFSD4 W18 GR3_0 T9 4x6 - Pixel Row 0 Column 0; Run: CVIV-Run0003 - First CV Run. Stop

