
DIGITAL **DESIGNER 4.2**



4 \

Step 2 of 38






Step 3 of 38






Step 4 of 38





Step 5 of 38






Step 6 of 38






Step 7 of 38






Step 8 of 38






Step 9 of 38






Step 10 of 38






Step 11 of 38






Step 12 of 38





1 x 2 x






Step 15 of 38








Step 17 of 38








Step 19 of 38






Step 20 of 38







Step 21 of 38






Step 22 of 38






Step 23 of 38






Step 24 of 38






Step 25 of 38






Step 26 of 38






Step 27 of 38






Step 28 of 38






Step 29 of 38






Step 30 of 38











Step 32 of 38






Step 33 of 38






Step 34 of 38






Step 35 of 38






Step 36 of 38





Step 37 of 38













© 2012 The LEGO Group. All rights reserved.
Use of the LEGO Digital Designer html print tool, signifies your agreement to the terms of use.