Lab 2: Implementation of AM in GNU Radio



Aim of the experiment

- To understand the basics of analog communication
- Implementing modulation demodulation flow graphs for both amplitude modulation (AM) in GNU Radio



Important Note

Using QT GUI Tab Widget to monitor multiple signals:-

QT GUI Tab Widget block in gnuradio can be used to monitor multiple graphs by giving a label to each graph to overcome the confusion about the source of a graph. For example, if you want to monitor two signals in the time domain, namely modulated and demodulated, then use two QT GUI time sinks e.g., sink1 and sink2.

- Open the block 'QT GUI Tab Widget'
- 2 Set the ID to 'tab' or any name you want to use
- Set no. of tabs to 2 (the number of labeled graphs you want to monitor)
- In Label 0 enter the label for first graph which is 'Modulated' in our example
- 5 In Label 1 enter the label for second graph which is 'Demodulated' in our example
- Now to connect the GUI sinks to QT GUI Tab Widget, open the block of respective QT GUI Time sink (in the current example)
- In GUI hint field of QT GUI Time sink 1 which is plotting modulated signal enter tab@0 ('ID of GUI Tab Widget'@'Index of tab')
- 3 In GUI hint field of QT GUI Time sink 2 which is plotting demodulated signal enter tab@1 ('ID of GUI Tab Widget'@'Index of tab')

Important Note



Figure: Using QT GUI Tab Widget to monitor multiple signals



Important Note

- Use the sample rate of 48KHz for all un-modulated signals (this sample rate is termed as Audio Rate in FM blocks-however, you don't have to use the ready made blocks)
- Use the sample rate of 960kHz for all the frequency or phase modulated signals in GNU-Radio (this rate is termed as Quadrature Rate in GNU radio FM blocks)
- Debugging steps:
 - If something is not working, trace the point of failure(by checking the signal at various nodes)
 - If you're not able to get the display after a new GNU-Radio block was added in the schematic, most likely you have entered wrong parameters in the new block (check carefully!)
 - Make sure that you are consistently accounting for the sample rate whenever decimation (for downsampling) and interpolation (for upsampling) are used.
- IIR filter block implementation:
 - FF coefficients= $[b_0,b_1]$;FB coefficients= $[a_0,a_1]$;Old Style of Taps=True, implements the discrete time filter:

$$\frac{Y(z)}{X(z)} = \frac{b_0 + b_1 z^{-1}}{a_0 - a_1 z^{-1}}$$

• A bug in implementation always sets the value of $a_0 = 1$. Therefore, you must use $a_0 = 1$ in all your calculations for filter coefficients.



Task 1: Implementation of DSB-FC

 Implement an entire DSB-FC AM modulation-demodulation flow graph in GNU radio. Use an envelope detector for the demodulation.

Note: You cannot use the built-in blocks for demodulation like AM-demod

- Parameters to be used:
 - Message signal (single-tone): 10 kHz
 - ⋄ Carrier signal: 100 kHz
- You are allowed to use the ready-to-use Low Pass Filter block from GNU radio library
- Observe the message signal and modulated signal for DSB-FC in time and frequency domains
- Replace the tone message signal with an audio message. Can you recover the message post-demodulation?

Task 2: Implementation of DSB-SC

You now have to implement DSB-SC modulation and demodulation. Assume perfect carrier synchronisation at the receiver.

- Implement the modulation flowgraph for DSB-SC transmission. Use a single tone at 10kHz as the message, and 100kHz as the carrier frequency.
- Observe the spectrum of the modulated signal.
- Implement the demodulation flowgraph.
- Observe the spectrum of the demodulated message signal.
- Replace the tone message signal with an audio message. Can you recover the message post-demodulation?


Q: What is the impact of a carrier frequency mismatch between the transmitter and receiver? How about a phase mismatch?



Task 3: IQ modulation and Demodulation

Part1: IQ Modulation


- 1 Implement the IQ modulation using two music files given (background.wav & vocal.wav). Treat one as the in-phase signal I(t) and the other as the quadrature-phase signal Q(t).
- Set the carrier frequency as 100KHz
- Store the modulated signal in data1.dat file in file sink





Part2: IQ Demodulation

- Demodulate the IQ modulated signal as shown in the block diagram, from data stored in data1.dat
- Use a low pass filter to filter higher unwanted frequencies
- Play the demodulated audio files. Observe if you get a faithful reconstruction.






Task 4: Implementation of SSB

You have already implemented DSB-SC modulation. Here, only one sideband of the message is transmitted. For real messages, note that this is sufficient. This requires only half the bandwidth of DSB transmission!









• Implement the modulation flowgraph for SSB-SC (upper sideband) transmission. Use a single tone at 10kHz as the message, and 200kHz as the carrier frequency.

Hint: Think of the transmitted (passband) signal as

$$s_p(t) = Re([s_I(t) + js_Q(t)]e^{j2\pi f_c t})$$

= $s_I(t)cos(2\pi f_c t) - s_Q(t)sin(2\pi f_c t)$

What should s_I and s_Q be for SSB transmission?

- Observe the spectrum of the modulated signal.
- Implement the demodulation flowgraph.
- Observe the spectrum of the demodulated message signal.
- Replace the tone message signal with an audio message. Can you recover the message post-demodulation?
- Repeat the above to achieve lower sideband transmission.

