AuraBrew Smart Coffee Maker X200

Product Information Guide

Model: AB-X200 | SKU: ABX200-BLK | Version 2.1 | Released: March 2025

Note: AuraBrew is a fictional product created for demonstration and RAG testing purposes.

1. Product Overview

The AuraBrew Smart Coffee Maker X200 is a Wi-Fi-enabled, 12-cup programmable drip coffee maker with a built-in conical burr grinder. It brews coffee from whole beans in under 8 minutes and can be controlled from the AuraBrew mobile app (iOS and Android) or via voice assistants such as Alexa and Google Assistant.

Key Features

- Built-in conical burr grinder with 5 grind settings (extra fine to coarse).
- 12-cup (1.8 L) borosilicate glass carafe with thermal warming plate.
- Brew strength selector: Mild, Medium, Bold, and Extra Bold.
- Schedule brewing up to 7 days in advance through the mobile app.
- Automatic descaling reminder every 60 brew cycles.
- Auto shut-off after 2 hours of inactivity for safety.
- Reusable permanent filter included; also compatible with #4 paper filters.

What's in the Box

AuraBrew X200 main unit, 12-cup glass carafe with lid, permanent mesh filter, bean hopper lid, cleaning brush, quick start guide, and warranty card.

2. Technical Specifications

Specification	Value
Model number	AB-X200
Capacity	12 cups (1.8 liters)
Bean hopper capacity	250 g (8.8 oz)
Power	1100 W, 220-240 V, 50/60 Hz
Connectivity	Wi-Fi 2.4 GHz (802.11 b/g/n), Bluetooth 5.0
Dimensions (W x D x H)	24 x 34 x 40 cm
Weight	4.6 kg
Water reservoir	1.8 L, removable, with level indicator
Cord length	1.0 m
Color options	Matte Black, Silver, Copper
MSRP	USD 189.99 / INR 15,999

3. Getting Started

First-Time Setup

1. Unbox the unit and remove all packaging materials and tape.
2. Wash the carafe, lid, and permanent filter with warm soapy water, then rinse.
3. Fill the water reservoir to the MAX line and run one full brew cycle without coffee to clean internal parts.
4. Discard the water from the carafe.
5. Add whole beans to the hopper and close the lid securely.

Connecting to Wi-Fi

Download the AuraBrew app and create an account. Press and hold the Wi-Fi button on the control panel for 5 seconds until the blue LED blinks. In the app, tap 'Add Device', select 'X200', and enter your home Wi-Fi credentials. The X200 supports only 2.4 GHz networks; 5 GHz networks are not supported. When connected, the LED turns solid blue.

Brewing Your First Pot

Fill the reservoir with fresh cold water, select the number of cups (2-12), choose grind size and strength, then press the Brew button. Brewing 12 cups takes about 8 minutes. The carafe warming plate keeps coffee hot for up to 2 hours.

4. Care and Maintenance

Daily Cleaning

Empty and rinse the carafe, permanent filter, and filter basket after every use. These parts are top-rack dishwasher safe. Do not put the main unit or the grinder assembly in the dishwasher or submerge them in water.

Descaling

Descale the machine every 60 brew cycles, or every 3 months if you use hard water. Mix equal parts white vinegar and water (approximately 900 ml each), pour into the reservoir, and start the 'Clean' cycle from the control panel or app. After the cycle, run two full reservoirs of fresh water to remove any vinegar residue.

Cleaning the Grinder

Once a month, unplug the unit, remove the hopper, and use the supplied brush to clear coffee residue from the burrs. Avoid grinding oily or flavored beans, as they can clog the grinder.

5. Troubleshooting

Problem	Possible Cause	Solution
Machine will not turn on	Not plugged in or outlet has no power	Check the power cord and try a different outlet.
Coffee tastes weak	Grind too coarse or strength set to Mild	Choose a finer grind and select Bold strength.
Coffee overflows filter basket	Grind too fine or filter clogged	Use a coarser setting and clean the filter.
Grinder makes loud noise	Foreign object or stone in beans	Unplug the unit, empty the hopper, and remove the object.
Cannot connect to Wi-Fi	Router is 5 GHz only or weak signal	Enable 2.4 GHz on the router and move it closer to the machine.
Error code E2 on display	Water reservoir empty or not seated	Refill the reservoir and reseat it firmly.
Error code E4 on display	Heating element overheated	Unplug for 30 minutes, then retry. Contact support if it persists.
Slow brewing	Mineral buildup	Run a descaling cycle.

6. Safety Information

- Keep the appliance out of reach of children.
- Never operate with an empty water reservoir.
- Do not use the carafe on a stovetop, in a microwave, or over open flame.
- Do not immerse the cord, plug, or base in water.
- Always unplug before cleaning or when not in use.

7. Warranty and Support

Warranty Coverage

The AuraBrew X200 comes with a 2-year limited warranty from the date of purchase covering manufacturing defects in materials and workmanship. The glass carafe is covered for 6 months. The warranty does not cover damage from misuse, unauthorized repairs, scale buildup due to lack of descaling, or normal wear such as filter replacement.

Return Policy

Customers may return the product within 30 days of purchase for a full refund if it is in original condition with all accessories and packaging. Refunds are processed within 7-10 business days after the returned item is received.

Contact Support

Email: support@aurabrew.example.com
Phone: 1-800-555-0142 (Mon-Fri, 9 AM - 6 PM IST)
Live chat: available in the AuraBrew app under Help.

8. Frequently Asked Questions

Q: Can I use pre-ground coffee?
A: Yes. Bypass the grinder by selecting 'Pre-ground' mode in the app or on the control panel, and add ground coffee directly to the filter basket (about 1 tablespoon per cup).

Q: Does the X200 work with Alexa?
A: Yes. Enable the AuraBrew skill in the Alexa app and link your account. You can say, 'Alexa, ask AuraBrew to brew 4 cups.'

Q: How long does the coffee stay hot?
A: The warming plate keeps coffee hot for up to 2 hours, after which the machine shuts off automatically.

Q: Can I make iced coffee or espresso?
A: The X200 is a drip coffee maker and does not make espresso. For iced coffee, use the 'Bold' or 'Extra Bold' setting and brew over ice.

Q: How do I update the firmware?
A: Firmware updates are delivered over Wi-Fi. Open the AuraBrew app, go to Settings > Device > Firmware Update, and tap 'Update Now'. Do not unplug the machine during the update.

Q: What is the water hardness recommendation?
A: Use filtered or soft water when possible. For hard water above 180 ppm, descale every 30 brew cycles.