Sensors and Actuators-I Internet of Things, Lecture-9

Rahul Shandilya

Definition

A sensor is a device (typically electronic) that detects events or changes in its physical environment (e.g., temperature, sound, heat, pressure, flow, magnetism, motion, and chemical and biochemical parameters) and provides a corresponding output.

► A sensor is a device that converts a physical quantity to an electrical signal, and therefore either provides a voltage or a current, or causes a change of its resistance.

Definition

- ➤ A sensor is a device that converts a physical quantity to an electrical signal, and therefore either provides a voltage or a current, or causes a change of its resistance.
- ► More generally, the impedance of the sensor, which also comprises capacitive and inductive sensors, may change.

Definition

- ➤ A sensor is a device that converts a physical quantity to an electrical signal, and therefore either provides a voltage or a current, or causes a change of its resistance.
- ► More generally, the impedance of the sensor, which also comprises capacitive and inductive sensors, may change.
- ▶ Based on these electrical these electrical quantities, it can be classified as:

Definition

- ➤ A sensor is a device that converts a physical quantity to an electrical signal, and therefore either provides a voltage or a current, or causes a change of its resistance.
- ► More generally, the impedance of the sensor, which also comprises capacitive and inductive sensors, may change.
- Based on these electrical these electrical quantities, it can be classified as:
 - 1. Resistance-based sensors

Definition

- ➤ A sensor is a device that converts a physical quantity to an electrical signal, and therefore either provides a voltage or a current, or causes a change of its resistance.
- ► More generally, the impedance of the sensor, which also comprises capacitive and inductive sensors, may change.
- Based on these electrical these electrical quantities, it can be classified as:
 - 1. Resistance-based sensors
 - 2. Voltage-based sensors

Definition


- ➤ A sensor is a device that converts a physical quantity to an electrical signal, and therefore either provides a voltage or a current, or causes a change of its resistance.
- ► More generally, the impedance of the sensor, which also comprises capacitive and inductive sensors, may change.
- ▶ Based on these electrical these electrical quantities, it can be classified as:
 - 1. Resistance-based sensors
 - 2. Voltage-based sensors
 - 3. Current-based sensors.


Analog Sensors

Resistance-based Sensors

Potentiometer

A potentiometer is a variable resistor where a slider moves up and down a resistance and shortens the distance of one end point to the slider, thereby reducing the resistance between two terminals. The distance between the slider and the other end point lengthens, causing the resistance between the slider and the other terminal to increase correspondingly.






Analog Sensors


Resistance-based Sensors

Potentiometer


A potentiometer is a variable resistor where a slider moves up and down a resistance and shortens the distance of one end point to the slider, thereby reducing the resistance between two terminals. The distance between the slider and the other end point lengthens, causing the resistance between the slider and the other terminal to increase correspondingly.


A variation of the potentiometer is a *joystick*, which is based on two orthogonally mounted potentiometers, controlled by a small stick.






lt changes its resistance depending on the exposure to light. The range of variation depends on the device and typically ranges from a few 100 Ω to MΩ.







- It changes its resistance depending on the exposure to light. The range of variation depends on the device and typically ranges from a few 100 Ω to $M\Omega$.
- ► The operating principle of this and many other sensors is based on the availability of electrons in the conduction band of a material.



- It changes its resistance depending on the exposure to light. The range of variation depends on the device and typically ranges from a few 100 Ω to $M\Omega$.
- ► The operating principle of this and many other sensors is based on the availability of electrons in the conduction band of a material.
- ► In *photoresistors* the base material is often CdS, a semiconductor with a bandgap of about 2.4 eV.











- It changes its resistance depending on the exposure to light. The range of variation depends on the device and typically ranges from a few 100 Ω to $M\Omega$.
- ► The operating principle of this and many other sensors is based on the availability of electrons in the conduction band of a material.
- ▶ In *photoresistors* the base material is often CdS, a semiconductor with a bandgap of about 2.4 eV.
- ► This energy equals that of photons of green light with a wavelength of about 500 nm. Therefore, green photons can elevate electrons from the valence to the conduction band and thus create electron-hole pairs.











lt is a calibrated platinum-based sensor with a resistance of exactly 100Ωat 0C.

- It is a calibrated platinum-based sensor with a resistance of exactly 100Ω at 0C.
- ▶ It is based on the fact that the resistance of a very pure metal is determined only by scattering of electrons in the conduction band with phonons, which are vibrations of the ions that make up the crystal lattice of the metal.

- It is a calibrated platinum-based sensor with a resistance of exactly 100Ω at 0C.
- ▶ It is based on the fact that the resistance of a very pure metal is determined only by scattering of electrons in the conduction band with phonons, which are vibrations of the ions that make up the crystal lattice of the metal.
- ► Moreover, higher temperatures cause stronger vibrations of the lattice, with correspondingly higher resistance. Intuitively one might think of the crystal ions at higher temperature to oscillate with larger amplitudes, creating a larger target for the electrons to scatter, thus impeding their motion.

- It is a calibrated platinum-based sensor with a resistance of exactly 100Ω at 0C.
- ▶ It is based on the fact that the resistance of a very pure metal is determined only by scattering of electrons in the conduction band with phonons, which are vibrations of the ions that make up the crystal lattice of the metal.
- Moreover, higher temperatures cause stronger vibrations of the lattice, with correspondingly higher resistance. Intuitively one might think of the crystal ions at higher temperature to oscillate with larger amplitudes, creating a larger target for the electrons to scatter, thus impeding their motion.
- ► Commercial sensors are often made of platinum wire wound on a ceramic support body. Example are PT100 temperature sensor.

- It is a calibrated platinum-based sensor with a resistance of exactly 100Ω at 0C.
- ▶ It is based on the fact that the resistance of a very pure metal is determined only by scattering of electrons in the conduction band with phonons, which are vibrations of the ions that make up the crystal lattice of the metal.
- Moreover, higher temperatures cause stronger vibrations of the lattice, with correspondingly higher resistance. Intuitively one might think of the crystal ions at higher temperature to oscillate with larger amplitudes, creating a larger target for the electrons to scatter, thus impeding their motion.
- Commercial sensors are often made of platinum wire wound on a ceramic support body. Example are PT100 temperature sensor.
- ► The PT100 sensors are connected to a calibrated current source and the voltage drop across the sensor is measured with a volt meter, just as any other resistance measurement.

Thermistors are resistors that have their temperature dependence deliberately made large. In *positive temperature calibration* (PTC) devices, the resistance increases with temperature, and in *negative temperature calibration* (NTC) devices, it decreases.

► PTCs are mostly used as protection devices that switch the resistance from a low- to a high-resistance state if a certain temperature is exceeded.

- ▶ PTCs are mostly used as protection devices that switch the resistance from a low- to a high-resistance state if a certain temperature is exceeded.
- ► They are based on polycrystalline materials that change their dielectric constant at a certain temperature, the Curie temperature, by a large amount.

- ▶ PTCs are mostly used as protection devices that switch the resistance from a low- to a high-resistance state if a certain temperature is exceeded.
- ➤ They are based on polycrystalline materials that change their dielectric constant at a certain temperature, the Curie temperature, by a large amount.
- ▶ Above the Curie temperature, the state of the magnetic dipoles is disordered and the dielectric constant is small. This causes the formation of large potential barriers between the crystal grains, which leads to a high resistance.

- ▶ PTCs are mostly used as protection devices that switch the resistance from a low- to a high-resistance state if a certain temperature is exceeded.
- ➤ They are based on polycrystalline materials that change their dielectric constant at a certain temperature, the Curie temperature, by a large amount.
- ▶ Above the Curie temperature, the state of the magnetic dipoles is disordered and the dielectric constant is small. This causes the formation of large potential barriers between the crystal grains, which leads to a high resistance.
- ▶ Below the Curie temperature the molecular dipoles are aligned, the dielectric constant is large, and the resistance is low.

► The converse thermistors are NTCs, which decrease their resistance with increasing temperature.


- ► The converse thermistors are NTCs, which decrease their resistance with increasing temperature.
- ► They are often used for temperature sensing and are based on a doped semiconducting material that has occupied impurity donor levels below the conduction band.

- ► The converse thermistors are NTCs, which decrease their resistance with increasing temperature.
- ► They are often used for temperature sensing and are based on a doped semiconducting material that has occupied impurity donor levels below the conduction band.
- ► Increasing the temperature thermally excites these electrons to jump into the conduction band, thus increasing the conductivity.

- ► The converse thermistors are NTCs, which decrease their resistance with increasing temperature.
- ► They are often used for temperature sensing and are based on a doped semiconducting material that has occupied impurity donor levels below the conduction band.
- ► Increasing the temperature thermally excites these electrons to jump into the conduction band, thus increasing the conductivity.
- ▶ Both NTC and PTC thermistors are sensed by connecting them to a constant-current source and measuring the voltage drop across the thermistor.

- ► The converse thermistors are NTCs, which decrease their resistance with increasing temperature.
- ► They are often used for temperature sensing and are based on a doped semiconducting material that has occupied impurity donor levels below the conduction band.
- ► Increasing the temperature thermally excites these electrons to jump into the conduction band, thus increasing the conductivity.
- ▶ Both NTC and PTC thermistors are sensed by connecting them to a constant-current source and measuring the voltage drop across the thermistor.


- ► The converse thermistors are NTCs, which decrease their resistance with increasing temperature.
- ► They are often used for temperature sensing and are based on a doped semiconducting material that has occupied impurity donor levels below the conduction band.
- ► Increasing the temperature thermally excites these electrons to jump into the conduction band, thus increasing the conductivity.
- ▶ Both NTC and PTC thermistors are sensed by connecting them to a constant-current source and measuring the voltage drop across the thermistor.



Voltage-based Sensor

LM35 temperature sensor


► LM35 temperature sensor, which is a silicon-bandgap temperature sensor and directly produces a voltage at its output pin.



Voltage-based Sensor

LM35 temperature sensor

- ► LM35 temperature sensor, which is a silicon-bandgap temperature sensor and directly produces a voltage at its output pin.
- ▶ The operating principle is based on passing known currents I_n with n=1,2 with current densities j_n across the base-emitter junctions of two bipolar transistors, and comparing their respective voltage drops $V_{BE,n}$.




Voltage-based Sensor

LM35 temperature sensor

- ► LM35 temperature sensor, which is a silicon-bandgap temperature sensor and directly produces a voltage at its output pin.
- The operating principle is based on passing known currents I_n with n=1,2 with current densities j_n across the base-emitter junctions of two bipolar transistors, and comparing their respective voltage drops $V_{BE,n}$.
- ► The voltage difference is proportional to the temperature which can be understand using diode junction potential equation.

where $E_g = 1.2 \sqrt{\text{is the bandgap energy of silicon}}$, k is the Boltzmann constant.




Thermocouples are temperature sensors that are based on the effects of temperature and temperature gradient on conductors made of different materials.


- Thermocouples are temperature sensors that are based on the effects of temperature and temperature gradient on conductors made of different materials.
- ▶ Directly at the junction of the conductors, the Peltier effect causes a current that depends on the temperature.


- Thermocouples are temperature sensors that are based on the effects of temperature and temperature gradient on conductors made of different materials.
- Directly at the junction of the conductors, the Peltier effect causes a current that depends on the temperature.
- ► On the wire segments a temperature gradient causes an additional current to flow, the Thomson effect.

- Thermocouples are temperature sensors that are based on the effects of temperature and temperature gradient on conductors made of different materials.
- Directly at the junction of the conductors, the Peltier effect causes a current that depends on the temperature.
- ▶ On the wire segments a temperature gradient causes an additional current to flow, the Thomson effect.
- And finally, joining the two junctions and the wires causes a current to circulate, provided the loop is closed. This is called the Seebeck effect.


- Thermocouples are temperature sensors that are based on the effects of temperature and temperature gradient on conductors made of different materials.
- Directly at the junction of the conductors, the Peltier effect causes a current that depends on the temperature.
- ▶ On the wire segments a temperature gradient causes an additional current to flow, the Thomson effect.
- And finally, joining the two junctions and the wires causes a current to circulate, provided the loop is closed. This is called the Seebeck effect.
- ► If the loop is open, as shown at the top left of, a voltage U develops at the end terminals as a consequence of the Peltier, Thomson, and Seebeck effects.









► In a thermopile a number of wire segments of materials A and B are connected in series.






- ▶ In a thermopile a number of wire segments of materials A and B are connected in series.
- ► Thermopiles are often found in devices sensing heat and infrared radiation, such as thermal imaging devices or contact-free thermometers.

► Hall sensors produce a voltage that is proportional to the magnetic induction B.






- ► Hall sensors produce a voltage that is proportional to the magnetic induction B.
- ► In the presence of a magnetic field, the Lorentz force deflects the charge carriers electrons and holes towards perpendicularly mounted electrodes.





- ► Hall sensors produce a voltage that is proportional to the magnetic induction B.
- ▶ In the presence of a magnetic field, the Lorentz force deflects the charge carriers electrons and holes towards perpendicularly mounted electrodes.
- ► This creates a potential difference (a voltage) between the electrodes, which causes a transverse electric field that counteracts the deflection from the Lorentz force such that the following charge carriers can move towards the exit electrode undeflected.





- ► Hall sensors produce a voltage that is proportional to the magnetic induction B.
- ▶ In the presence of a magnetic field, the Lorentz force deflects the charge carriers electrons and holes towards perpendicularly mounted electrodes.
- ➤ This creates a potential difference (a voltage) between the electrodes, which causes a transverse electric field that counteracts the deflection from the Lorentz force such that the following charge carriers can move towards the exit electrode undeflected.
- ► The A1324 Hall sensor has signal-conditioning circuitry on board and only needs three pins for ground, supply voltage, and output voltage. The latter is proportional to the magnetic field, with a sensitivity of 50 mV/mT centered at 2.5 V when no field is present.

