DIGITAL COMPUTERS AND INFORMATION A computer is basically a programmable computing machine. Computers are used A computer is basically a programmable computers in a modern and industrialized now a days by all kinds of people for a variety of tasks in a modern and industrialized now a days by all kinds of people for a variety of tusto place, namely, homes, schools, society. Their presence is felt at almost every working place, namely, homes, schools,


colleges, offices, industries, hospitals, banks, retail stores, research and design organizations and so on. Developments in software allow massive applications of computers for non computational jobs like text preparation, manipulation, storage and

retrieval, transmission of texts, graphics and pictures from one place to another.

Computers which are in use today are digital computers. They operate on binary digits 0 and 1. They understand information composed of only 0s and 1s. In the case of alphabetic information, the alphabets are coded in binary digits. A binary digit is called bit. A group of 8 bits is called a byte. The most prominent characteristic of a digital computer is its generality. It usually follow a sequence of instructions, called a program, that operates on given data to perform a specific task. The user has the flexibility of manipulating the data or program according to specific needs. Consequently, a digital computer can perform a various information processing tasks that range over a wide spectrum of applications. The general purpose computer is the best known example of a digital system.

Digital system refers to the systems which manipulate discrete quantities of information that are represented in binary form. Any set that contains finite number of elements is said to process discrete information. Examples of discrete sets include 26 alphabetic letters, 10 decimal digits, 52 playing cards and so on. Earlier digital computers were used mostly for numeric computations, wherein discrete elements used were the digits. From such an application, the term digital computer emerged.

In digital systems, the discrete elements of information are represented by physical quantities called signals. The signals use two discrete values, and hence said to be binary. Usually these discrete values are represented by voltage ranges called HIGH and LOW. The other notations used to represent the two discrete values are TRUE and FALSE, ON and OFF, and 1 and 0, Fig. 1.1.1 depicts the input and output voltage ranges.



The high input voltage allows 3.0 to 5.5 volts to be recognized as a HIGH, and the low input voltage allows -0.5 to 2.0 volts to be recognized as a LOW. The high output voltage ranges between 4.0 to 5.5 volts, and the low output voltage ranges between -0.5 and 1.0 volts.



NOTE

The input and output voltage ranges differs for the various logic families.

Information Representation

In digital computers, information is represented in terms of binary digits 0 and 1. A binary digit (either '0' or '1') is called a bit. Group of bits can be made to represent information like numbers, alphabets and symbols. For this purpose various coding techniques have been used to transform numbers, alphabets and symbols into group of binary digits. A properly arranged group of bits can specify to the computer the instructions to be executed and the data to be processed.

Since digital computers understand information composed of only 0s and 1s and if any analog quantity is to be processed, it must be quantized (i.e., converted into digital) before processing. The quantization of the analog signal in magnitude and time is performed by an analog to digital convertor device.

Computer Structure

The block diagram of a digital computer is shown in Fig. 1.1.2.




Fig. 1.1.2 Block Diagram of a Digital Computer

The central processing unit is the brain of a computer. Its primary function is to execute programs. The CPU also controls the operation of all other components such as memory, input and output devices. The datapath unit of CPU performs arithmetic and data processing operations as specified by program. The control unit provides the control signals to supervise the flow of information between the various components of a computer. The control unit retrieves the instructions, one by one, from the program stored in the memory. For each instruction, the control unit manipulates the datapath to execute the operation specified by the instruction.

1 11 11 1

Number of digits in fractional part. m

digits in integer part: -

Also, the weight of each digit (either integer or fractional part) can be determined as,

Weight of $i_{n-1} = i_{n-1} \times (base)^{n-1}$

Weight of $f_{-m} = f_{-m} \times (base)^{-m}$

Here, weight of any digit can be defined as its relative position in number.

1.2.1 Decimal Number System

Decimal (or dernary) number system has a base of 10. This means that there are 10 different symbols that make up the number system namely, 0, 1, 2, 3, 4, 5, 6, 7, 8 and 9. All the numbers are given using these basic symbols. Let us consider another number, say 5247.924. The numerical value of above number can be expressed as,

7.924. The numerical value of above fiducials
7.924. The numerical value of above fiducials

$$5247.924 = 5000 + 200 + 40 + 7 + 0.9 + 0.02 + 0.004$$

 $= (5 \times 10^3) + (2 \times 10^2) + (4 \times 10^1) + (7 \times 10^0)$
 $+ (9 \times 10^{-1}) + (2 \times 10^{-2}) + (4 \times 10^{-3})$

Fig. 1.2.2 illustrates the positional values of digits of a given number relative to the Positional Values decimal point.





Fig. 1.2.2 Decimal Positional Values as Powers of 10

Here the integer part (5247) of the number is separated from its fractional part (924) by a point called radix point (or base point). In decimal system, it is called as decimal point.

1.2.2 Binary Number System

- The binary number system operates on two voltage levels. The binary number system has a base of 2. This means that this system has only two symbols. They are 0 and 1. Every binary number is given as combination of these two symbols.
- Just like the decimal system, the binary system is also a positional-value system. Each bit has a positional value as a power of 2. Fig 1.2.3 illustrates the positional values for a binary number 1011.10.



In Fig. 1.2.3, left of binary point (radix point in base-2 system) are positive powers of 2, and right of it are, negative powers of 2. The left most bit has the largest weight, P hence called as Most Significant Bit (MSB). The right most bit has the smallest weight, hence called as Least Significant Bit (LSB).

1.2.3 Octal Number System

- The octal number system has a base of 8. This means that this system has eight symbols. They are 0, 1, 2, 3, 4, 5, 6, and 7. All the numbers given as combination of these symbols.
- As in the other number systems discussed, each of these digits has a positional value. In this case the weightage to each position will be a power of 8. The right most digit has the least weightage. The left most digit has the highest weightage. To find its equivalent in the decimal system we simply take the sum of the products of each value and its positional value,

$$(352)_8 = (3 \times 8^2) + (5 \times 8^1) + (2 \times 8^0)$$

= $(3 \times 6^4) + 40 + 2 = 192 + 40 + 2 = (234)_{10}$

How do we count in octal system?

Once we get to 7, simply start over with another column and continue as follows, 10, 11, 12, 13, 14, 15, 16, 17

20, 21, 22, 23, 24, 25, 26, 27

30, 31, 32, 33, 34, 35, 36, 37 and so on...

124 Hexadecimal Number System

- The hexadecimal number system has a base f'16. This means that it has sixteen (Hex + Decimal) symbols. Since, the basic number system consists of only ten digits (Hex + Decimal) symbols. Since, the (from 0 to 9), the first six letters of the English alphabets are borrowed to make (from 0 to 9), the first six letters of the the remaining 6 symbols. Hence, the hexadecimal number system is made-up of the the remaining 6 symbols. Hence, the hexadecimal number system is made-up of the
- Every hexadecimal number is given as combination of these symbols. In the above Every hexadecimal number is given as corresponds to decimal number. In the above list of symbols, it should be noted that A corresponds to decimal number 10, 'B' to 12, 'D' to 13, 'E' to 14 and so finally 'F' to 15.

Let us consider a hexadecimal number 5C. The value of the hexadecimal number 5C is given as,

$$5C = (5 \times 16^1) + (C \times 16^0)$$

Since, 'C' corresponds to the decimal number 12, the value of 5C can be written as, $5C = (5 \times 16^{1}) + (12 \times 16^{0})$

1.2.5 Count for Radix (Base)

In any number system, any number can be represented by multiplying each digit with its corresponding positional weights as shown in Fig. 1.2.4.




Fig. 1.2.4 Representation of a Number with its Corresponding Weights

Thus,

$$N_b = a_{n-1}b^{n-1} + \dots + a_1b^1 + a_0b^0 + a_{-1}b^{-1} + a_{-2}b^{-2} + \dots + a_{-m}b^{-m}$$

$$N_b = a_{n-1}b^{n-1} + \dots + a_{-m}b^{-m}$$
The previous sections,

Where, 'N' is a number and 'b' is the radix or base. In the previous sections, we have seen number systems with radix (base) r equal to 10, 2, 8 and 16. Each number system has 'r' set of characters (symbols). For example, in decimal number system r equals to 10 has 10 characters from 0 to 9, in binary number system r equals to 2 has 2 characters 0 and 1 and so on. In general, we can say that a number represented in radix r, has r characters (symbols) in its set and r can be any integer value greater than one. The set of symbols used in various number systems is illustrated in Table 1.2.1.

Table 1.2.1 Radix and Symbol Set

Radix (Base) r	Characters (symbols) in set
2 (Binary)	
3 (Trinary)	0,1,2
4 (Quinary)	0,1,2,3
5	0, 1, 2, 3, 4
6	0, 1, 2, 3, 4, 5
7	0, 1, 2, 3, 4, 5, 6
8 (Octal)	0, 1, 2, 3, 4, 5, 6, 7
9	0, 1, 2, 3, 4, 5, 6, 7, 8
10 (Decimal)	0, 1, 2, 3, 4, 5, 6, 7, 8, 9
11	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, α
12	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, α, β
16 (Hexadecimal)	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, I

1.9

Number Ranges

number of bits available in the hardware structures that store and process information. The number of bits available in these structures is expressed as a power of two, such as $8(=2^3)$ bits, $16(=2^4)$ bits, $32(=2^5)$ bits and so on. The range of numbers that can be represented in digital computers is based on the

unsigned integers is from 0 to $2^{N}-1$. For example, for a computer processing 8 bit unsigned integers, the range of integers is from 0 to 2^8 - 1, that is, from 0 to 255. If the same computer is processing 8 bit unsigned fractions, the range of fractions that can be represented is from 0 to $(2^8 - 1)/2^8$, or from 0.0 to 0.99609375. The range of numbers that can be handled by a digital computer processing N bit

NUMBER BASE CONVERSIONS

have the conversion in between these number systems. used as a shorthand means of expressing large binary numbers. So it is necessary to It is inconvenient to read or write. For this reason, octal and hexadecimal numbers are the output devices. While dealing with the large quantity of binary numbers of many bits, the binary number into its decimal equivalent while displaying the result of operation on equivalent binary while feeding number into the digital system (computer) and to convert outside a digital system. Therefore, it is necessary to convert decimal number into its the decimal system is also important since it is universally used to represent quantities The binary number system is the most commonly used in the digital systems, but

Decimal to Radix 'r' System Conversion

multiplication by radix(r) is done for integer part and fractional part respectively. popular is the double-dabble method. In this method, successive division and successive There are many ways to convert a decimal number to any radix-r system, but most

Successive Division for Integer Part Conversion

the radix-r number system. in base r. That is, the first remainder is the LSD and the last remainder is the MSD in radix-r number system. The remainders are taken in the reverse order to form a number " until the quotient is zero. The remainder of each division becomes the number in the In this method, we repeatedly divide the integer part of the decimal number by radix

Following are the steps to be followed for integer part conversion

of quotient (Q) and remainder (R) Step 1 : Divide the integer part of the decimal number by radix-'r' and note the values

STEP 2 : Repeat step 1 until quotient becomes zero

system. STEP 3 : Remainders in "everse order gives the equivalent number in desired radix-r

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory Successive Multiplication for Fractional Part Conversion

Following are the steps to be followed for fractional part conversion.

Step 1: Multiply the fractional part of the decimal number by desired radix 'r'.

and fractional part as the new fractional part. STEP 2: Integer part of the product becomes a digit in the desired radix r system number

Scanned by CamScanner

STEP 3: Repeat steps 1 and 2 until fractional part is zero or until necessity of

required. STEP 4: Read downwards to represent the equivalent fractional number in radix-r system

Example Problem 1.1

Convert (26)10 into its binary equivalent.


The process of repeated division by 2 is shown below,


Quotient

Remainder

26 + 2 = 12 0 $(26)_{10} =$

another way of showing the process of repeated division by 2 is as follows,






the grouping of 3 bits to form its equivalent octal (I.e., 2), hence the group three bits to form an equivalent octal number. Table 1.3.1 gives The base for octal numbers (i.e., 8) is the third power of the base for binary numbers

Binary Equivalent 000 001 010 011 100 101 110 1	Signal .	DISTRIBUTE BINARY to Octal Convers	Bine	Ny to	Octal C	onver	sion		
	Binary Equivalent	000	007	010	011	100		110	-

Convert 1110101 . 1010011 into octal number system.

STEP 1: For integer part grouping of 3 bits starts from LSB to MSB. For fractional The grouping of three binary digits can be done as follows part grouping of 3 bits starts from MSB to LSB.



STEP 2: Add zeros for making the groups of 3 bits. For integer part, add zeros on left of MSB and for fractional part, add zeros on right of LSB.

.. (1110101 . 1010011)₂ = (165.514)₈ 001 110 101.101 001 100

Binary to Hexadecimal Conversion

numbers (i.e., 2), hence group four bits to form an equivalent hexadecimal number. The base for haxadecimal numbers (i.e., 16) is the fourth power of the base of binary

Table 1.3.2 gives the hexadecimal decimal equivalent of group of four binary digits

Hexadecimal Digit 8 9 A B	Binary Equivalent 1000 1001 1010 1011	Hexadecimal Digit 0 1 2	Binary Equivalent 8000 8001 8010 8	Table 1372 Binary to Hexadecimal Conversion
C . D	1100	+	1110 0110 1010 0010 1100	mai Conv
D	H01	Un	0101	ersion
11	0111	6	0110	
TI	1111 0111	7	0113	

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)


Convert 1110101 . 1010011 into hexadecimal number. The conversion of binary number to hexadecimal number is done as follows, Step 1 : For integer part, grouping of 4 bits starts from LSB to MSB. For fractional part grouping of 4 bits starts from MSB to LSB. 1 1 0 1 0 1 1
Fundamentals of Logic Doubler. Tall number is done as follows arts from LSB to MSB. For fracts.
0 2

READ Octal to Binary Conversion

octal digit with its equivalent binary number. Octal numbers are converted into its equivalent binary numbers by replacing each

Convert (567.32) into binary number.

Replacing each octal digit by 3 bit binary equivalent.




Octal to Hexadecimal Conversion

is given below, The conversion of octal number to hexadecimal number is done in two steps and

Step 2 : Convert the binary number to its hexadecimal equivalent (binary-to-hexadecimal STEP 1 : Convert the octal number to its binary equivalent (octal-to-binary conversion).

conversion).

nexadecimal. Another method is to first convert the given octal number into decimal and then to



10

Hexadecimal to Binary Conversion

 $(18D.88)_{16} = 18D.88H$

hexadecimal digit with its equivalent binary number. Hexadecimal numbers are converted into equivalent binary numbers by replacing each

Example Problem 1.10

Convert (567.A4)₁₆ into binary number.

Replacing each hexadecimal digit by 4 bit binary equivalent.

: (567.A4)₁₆ = (10101100111 . 101001)₂ 0101 0110 0111 1010 0100

Hexadecimal to Octal Conversion

The simplest way to convert hexadecimal number to octal number contains two steps,

Step 1 : Convert the hexadecimal number to its binary equivalent.


STEP 2 : Convert binary number to its octal equivalent.

decimal to the octal number. Another method is to convert the given hexadecimal number into decimal and then

Convert (AB6.13)16 into octal equivalent.

STEP 1: Convert the hexadecimal number to its binary equivalent.

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)



ARITHMETIC OPERATIONS

to use only 'r' allowable digits and perform all computations with base-r digits. applicable for arithmetic operations with numbers in base-r. However, one must be careful The rules used for performing arithmetic operations for decimal numbers is also

Binary Arithmetic Operations

number can be done by using the Table 1.4.1. The arithmetic rules for the addition, subtraction, multiplication and division of binary

4)	3)	2)	1)	S.No.
1+1=1.0	1 + 0 = 1	0+1=1	0+0=0	Addition
1+1=1.0 1-1=0	1-0-1	1.0-1-1	0-0-0	Subtraction
1×1=1	1×0=0	0 × 1 = 0	0×0=0	Subtraction Multiplication
1+1=1	1+0=NA*	0+1=0	0+0=NA*	Division

Binary Addition

carry generated;

·borrow taken;

*Not Allowed

bits, adding the carry results from the previous additions. Consider the addition of two binary numbers 1110 and 1010. numbers are added. The addition is started from the LSB and proceeds to higher significant Addition of two binary numbers can be performed in the same way as the decimal

Binary Division

any number by 0, is meaningless. The process of binary division can be defined as, It is similar to the division procedure in decimal number system. If we are dividing

the dividend. STEP 1 : If the divisor is less than the dividend then subtract the divisor repeatedly from

dividend; and increase the number of 0 in dividend STEP 2: If the divisor is greater than the dividend then put a decimal in quotient and

Example Problem 1.13 Divide the following

(a) 11110+101 9 1111 + 110

101 11110

1010 101

000 000

000

110)1111.0

10.1

required in dividend. quotient, put decimal in the dividend and the quotient both. Then increase the 0's In the example problem 1.13(b) division is not possible, so after placing 0 in the

Arithmetic Operations with Octal, Hexadecimal System

Octal Addition

performed. The steps are given below, Addition of octal number is carried out in the same way as the decimal addition is

STEP 1 : First, add the least significant digits of the octal number in decimal.

can be directly written as a octal digit. STEP 2 : During the process of addition, If the sum is less than or equal to 7, then it

next digit position STEP 3: If the sum is greater than 7, then subtract 8 from the digit and carry 1 to the

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory 1.19 Fundamentals of Logic Design

Ster 4: This process is repeated for each larger significant digit of the octal number.

5 : Carry generated from most significant bits addition will be included in the result

COMMENT

of 9 in case of decimal system In this addition, we should remember that the largest octal digit is 7 instead

Scanned by CamScanner

Add (432), and (746),

Subtract 8 from digit whose sum is greater than 7 = Sum (Using decimal number system) = Augend Addend = Result = 3 0 Carry

 $(432)_{8} + (746)_{8} = (1400)_{8}$

COMMENT

Carry generated from sum of most significant octal digits will be MSB in the result.

Example Problem 1.15


Add (6352), and (5143),

Sol. :


Subtract 8 from digit whose sum is > 7 = Add digits using decimal system = Augend = Addend = Result = Carry

 $(6352)_8 + (5143)_6 = (13515)_8$

respective positions only. have sum greater than 8 (i.e.,) 11, 9 respectively. Hence 8 is subtracted from the In the above example, only most significant digits and 2nd least significant dig



In the octal subtraction, the method, which we have adopted, is similar to that of binary subtraction method. The only difference lies in the carry part. During octal subtraction, instead of 1, we will borrow 8 and the rest of the steps are similar to that of binary subtraction.



Minuend =
$$7\frac{18}{3}$$
 Borrow Decimal Equivalent Subtrahend = $6\frac{4}{7}$ Subtrahend = $\frac{6}{7}$ $\frac{4}{7}$

 $(73)_8 - (64)_8 = (7)_8$

Hexadecimal Addition

The addition operation performed with the hexadecimal numbers is similar to the decimal addition except with a few differences that are discussed in the following steps.

STEP 1 : First, add the unit column of the hexadecimal digits in decimal


STEP 2: During the process of addition, observe it the sum is 15 or less than it can be directly expressed as a hexadecimal digit.

STEP 3: If the sum is greater than 15, then subtract 16 from the particular digit and carry 1 to the next digit position.

STEP 4: This process is repeated for each larger significant digit of the hexadecimal number.

STEP 5 : Carry generated from most significant bits addition will be included in the result.

PROFESSIONAL PUBLICATIONS (A Prefect Guide Towards Success)



The hexadecimal subtraction is based on the same principles as that of binary subtraction. In this subtraction, 16 will be used as borrow instead of 1. The rest of the steps are similar to the binary subtraction.

Example Problem 1.20

Subtract (37)16 from (48)16

Example Problem 1.21

Subtract (48)16 from (54)16

 $(54)_{16} - (48)_{16} = (9)_{16}$ Subtrahend Result = Here 16 + 4 = 20

Example Problem 1,22

Subtract (6AB2)16 and (5BF3)16

Sof. :

Subtrahend Minuend 8

The above example explained as follows,

At LSB (1st bit) position : (16+2)-3=15=F

At 2^{no} bit position B will be one value less (i.e.,) $B \Rightarrow B - 1 = A$. Since B gives borrow of 16 to LSB (1st bit) hence now

 $\therefore (16 + A) - F = (16 + 10) - 15 = 26 - 15 = 11 = B$

At 3rd bit position (i.e.,) $A \Rightarrow A - 1 = 9$. A gives borrow to 2nd bit, hence A will be one value less

 \therefore (16 + 9) - B = (25) - 11 = 14 = E

At 4th bit position Similarly 6 gives borrow to 3rd bit, hence 6 will be one value less (i.e.,) $6 \Rightarrow 6 - 1 = 5$. Thus 5 - 5 = 0

.: (6AB2)₁₆ - (5BF3)₁₆ = (EBF)₁₆

DECIMAL CODES

special characters and control functions are to be converted into binary format. and circuit elements that have two stable states. Hence the numerals, alphabets or special characters. But the digital systems use signals that have two distinct values handle data (represent and manipulate) which may be consisting of numbers, alphabets The electronic digital systems like computers, microprocessors, .etc., are required to

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory

Fundamentals of Logic Design

- The process of conversion into binary format is known as 'binary coding'. The equivalent binary, we call it as "straight binary coding". codes (or) decimal codes. When decimal number is represented by its binary hexadecimal numbers etc.), alphabets, symbols or control functions are called 'binary combination of binary bits that represent numbers, (may be decimal numbers, octal,
- a 2-bit binary code, with each element assigned one of the following bit combinations combinations of 1's and 0's. For example, a set of four elements can be coded with An n-bit binary code is a group of n bits that can represent upto 2" distinct 00, 01, 10, 11.
- If the number of elements in the set is not a power of 2, then binary code may have (BCD). In BCD, decimal digits 0 through 9 are represented by their binary equivalents some unused bit combinations. One such decimal codes is binary coded decimal using four bits.

Table 1.5.1 shows the 4 bit 8421 or BCD-code used to represent a single decimal

9	8	7	6	(n	4	્ધ	2	1	0	Digit	Decimal	Table 1.5.1
1	1	0	0	0	0	0	0	0	0	80	+	
0	0	1	1	1	1	0	0	0	0	4	BCD Code	or BC
0	0	-	1	0	0	1	1	0	0	2	Code	8421 or BCD Code
	0	1	0	1	0	1	0	1	0	-		

using only ten. The result of six codes combinations are not used i.e., 1010 to 1111 are invalid in this BCD code. With four bits, 24 i.e., sixteen numbers can be represented. But in this code, we are

1.25

In multi digit coding, each decimal digit is individually coded with BCD code. For

example, 67.8 in decimal can be encoded in BCD as,

1000

Though BCD numbers are represented in bits, they are decimal numbers and not 0110 0111 •

binary numbers. One key distraction between a BCD number and a decimal number is that the BCD numbers use the binary codes 0000, 0001, 0010,...., 1001, while the decimals are written with the symbols 0, 1, 2, 3,...., 9.

Convert the given binary number 11011.101 into BCD number system.

it into decimal number and then each decimal is coded individually with four bits. Any given binary number can be converted into its equivalent BCD by first converting

(11011,101)₂ → (?)₁₀ Step 3: 1 × 2⁴ + 1 × 2³ + 0 × 2² + 1 × 2¹ + 1 × 2⁰ + 1 × 2⁻¹ + 0 × 2⁻² + 1 × 2⁻³ 23 22 0 21 20 2-1 2-2 0

= 16 + 8 + 2 + 1 + 0.5 + 0.125 = 27.625

(27.625)₁₀ →)BCD

.. $(11011.101)_2 \rightarrow (00100111.011000100101)_{BCD}$ 0010 0111 0110 0010 0101

BCD Addition

Procedure for BCD addition is as follows

STEP 1 : Add the two-binary numbers of BCD similar to binary addition

STEP 2: If the 4-bit group sum is < 9, it a valid BCD

Add 6 i.e., $(0110)_2$ to the 4-bit group sum to skip the six invalid states and return to Step 3 : If the 4-bit group sum is > 9, or if carry is generated, it is not a valid BCD.

the code 8421. Notice that if the 4-bit group sum results into a carry, the carry is added in the next

significant 4-bit sum group.

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory Case 1 (Sum Equals 9 or Less) : Consider adding 4 and 3 using BCD to represent each BCD code for 3 = 0011 BCD code for 4 = 0100 Sum = 0111 BCD code for 7

the BCD code for 7. As another example, take 45 added to 33. The addition is carried out as in normal binary addition and the sum is 0111 which Addend in BCD = (+) 0011 0011 Augend in BCD 0111 1000 0100 0101

which is BCD for 8. Similarly, adding the second-decimal-digit positions produces 0111, which is BCD for 7. The total is 01111000, which is the BCD code for 78. In this example, the four-bit codes for 5 and 3 are added in binary to produce 1000,

= mus

{ {

9, therefore, no decimal carries were produced. For these cases, the BCD addition process is straightforward and is actually the same as binary addition. In the examples above, none of the sums of the pairs of decimal digits exceeded

corresponding sum term. than 9 will result an invalid BCD number. Whenever this arises, add $(6)_{10}
ightarrow 0110$ to that Case 2 (When Sum Greater than 9 with No Carry) : In this case, sum of two digits greater

Add 368.5 and 534.6 in BCD form

Sol. : ADD 01102 to illegal codes = Add 01102 to illegal code = Addend in BCD = Augend in BCD = Correct result = 1010 0110 1100 1000 1001 1100 . 1011 1001 1000 1010 0011 . 0001 0011 0100 - 0110 0000 1000 , 0101 0011 . 0001 0110 : 0110 = 903.1

Logic and Switching Theory

1.27


Fundamentals of Logic Design

Case 3 (When Sum Greater than 9 with Carry) : If there is a carry out of one sum term or if the sum term is an illegal code, then add $6_{10}=(0110)_2$ to the sum for correction.

Example Problem 1.2

In BCD Formate Add 59 and 38.

Sol. :



In the above example, least significant digits (i.e.,) 9, 8 addition produces a sum of 10001 = 17. Thus generates a carry into the next digit position to be added to the codes for 5 and 3. Also, since 17 > 9, a correction factor of +6 is added to the LSB sum. Addition of this correction does not generate a carry. The carry was already propagated in the original addition.

ALPHANUMERIC CODES

The codes which represent numbers, alphabets (both upper and lower case) and special symbols are called as alphanumeric codes.

ASCII Character Code

An input output code known as the American Standard Code for Information Interchange (pronounced as ask-ee) used in most computers by its manufacturer. It represents a character set with 7 bits, which can be stored as one byte, with an extra unused bit. The ASCII is a 7 bit code whose format is $X_6 \ X_5 \ X_4 \ X_3 \ X_2 \ X_1 \ X_0$, where each bit is either 0 or 1.

Example : A is coded as 100 0001. The Table 1.6.1 shows the capital letter A has an X_6 X_5 X_4 of 100 and X_3 X_2 X_1 X_0 of 0001.

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

The state of the s	X, X, X, X,	0000	1000	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111
	010	SP	-	4	#	in	100	St.		^)		+	4	-3	-2	,
	011	0	1	13	3	4	51	6	7	8	9	1.5	11	٨	1	v	è.
x, x, x,	100	0	^	В.	С	D	-	B	G	н	1	J	~	ı	M	z	0
,×	101	P	0	R	S	T	C.	<	W	×	Y	. Z					
	110	240	25	G	c	d	0	f	09	'n	-	j	×	. 1	m	n	0
	111	p	9	-	S	-	=	V	W	×	У	Z					

Parity Bit

In the process of binary data transmission, errors may occur. In order to detect errors, sometimes an extra bit, known as parity bit is added to each ASCII character being transmitted. The parity bit is added to ASCII character code to make the total number of 1's either even or odd. The two ASCII characters with their even and odd parity are as shown in Table 1.6.2.


Table 1.6.2 ASCII Characters with Even and Odd Parity

ASCII Character	With Odd Parity	With Even Pari
A = 1000001	11000001	01000001
X = 1011000	01011000	1101100

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

"output is HIGH only when all of the inputs are HIGH. When any of the inputs are LOW, From Table 1.7.2, it can be noticed that the logical AND operation is such that the

the lamp is OFF (logic 0) if any one or both switches are OPEN (logic 0). 1.7.2. The lamp glows (logic 1) when both switches S₁ and S₂ are closed (logic 1). Obviously The logic operation AND can be represented by a switching-circuit as shown in Fig.



Big Switching Circuit Implementing AND Gate

TO Logical OR Operation

OR operation between two inputs variables A and B can be represented as The logical OR operation is performed on a two or multiple input variables. The logical

shows the result of OR operation on the variables A and B. The common symbol used for logical OR operation is addition symbol (+). Table 1.7.3

0 0	0	0	A	Inp	Table 1.7.
Output F	1	0	8	Inputs	2-inpu
	1	0	-	Output	input OR Gate Truth Table


PROFESSIONAL PUBLICATIONS (A Perfect Guide Townris Success)

0

Legic and Switching Theory

Fundamentals of Logic Design

 \mathbf{S}_1 and \mathbf{S}_2 are closed. The lamp is OFF when both the switches are opena switching circuit as shown in Fig. 2.2.3. The lamp glows when one or both switches when one or more inputs are HIGH". The logical OR operation can be represented by From Table 1.7.3 logical OR operation can be simply stated as "The output is HIGH



Logic Gates

- Logic gates are the functional building blocks of digital systems. Logic gate is an electronic circuit that operates on one or more input signals to produce an output
- 0. The output level (logic HIGH or logic LOW) depends upon the combinations of input are termed as HIGH and LOW or TRUE and FALSE or ON and OFF or simply 1 and The inputs and outputs of logic gates can occur only in two levels. These two levels levels. Any logic gate operation can be understood with the help of Truth Table.
- Digital electronics deals with different types of logic gates. They are
- OR, AND, NOT gates (also known as basic gates) which are mostly used in combinational logic design.
- NAND, NOR gates (also known as universal gates) because all the other gates can be realized using either, only by NAND gates or only by NOR gates.

NOT Gate

NOT operation is performed on a single input variable. If A is an input variable to the NOT gate, then the output (F) can be expressed as,

F = A (or) A'.

A" or "F equals the complement of A". This expression is read as, "F equals NOT A" or "F equals the inverse of

- a logic 1 to a logic 0 and a logic 0 to a logic 1. NOT operation is also referred as "inversion or complementation". It changes
- Fig. 1.7.4(a) shows the symbol for NOT gate, which is more commonly called as "INVERTER". It always has a single input and single output

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

пипп


- The AND gate has one output and two or more inputs. If two inputs A and 8 are combined using the AND operation, the result F, can be represented as,
- all of the inputs are logic HIGH. When any of the inputs are logic LOW, the output The operation of the AND gate is such that the "output is logic HIGH only when
- The logic symbol of two input AND gate is shown in Fig. 1.7.4(b).

OR Gate

The OR gate has one output and two or more inputs. Let A and B represent two independent input logic variables to the OR gate, the output F can be

$$F = A + B$$

- An OR gate produces a logic 1 (HIGH) output when any of the inputs is at logic logical OR operation is stated as "the output is HIGH when one or more inputs 1. The output is logic 0 (LOW) only when all the inputs are at logic 0. Simply
- The logic symbol for the two input OR gate is shown in Fig. 1.7.4(c).



The operation of these logic gates can be illustrated using truth tables as shown

Fig. 1.7.4 Logic Symbols of Basic Gates

(b) AND Gate

(c) OR Gate

V

(a) NOT Gate




PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory

Fundamentals of Logic Design

Timing Diagrams of Basic Logic Gates : Fig. 1.7.5 shows the timing diagram for the the two possible voltage levels. diagram represents time and the vertical axis shows a signal as it changes between corresponding output signal for each type of gate. The horizontal axis of a timing



BOOLEAN ALGEBRA

by 0. Boolean functions defined on the switching algebra are called 'switching functions' elements, the largest number represented by 1 and the smallest number represented and design of switching circuits that make up digital systems. It contains two extreme Boolean algebra B2 ({0, 1}, ., +, ', 0, 1) known as "switching algebra" is used for analysis can be mathematically expressed. Among all the Boolean algebras, the two-element Boolean Algebra is different from the normal algebra in many ways, such as : 'Boolean algebra' is a set of rules, laws and theorems L, which logical operations

- numbers, which are infinite. Boolean algebra deals with finite elements while normal algebra deals with real
- Complement operator is available in Boolean algebra.
- Boolean algebra obeys the distributive law i.e., $A + (B.C) = (A + B) \cdot (A + C)$.

Basic Identities

section we will study the basic rules of Boolean algebra necessary to obtain the simple expressions for Boolean function. expression reduces the number of logic gates and the number of inputs to gates. In this manipulating a Boolean expression according to Boolean algebra rules. This simpler It is often possible to obtain a simpler expression for the Boolean function by

Principle of Duality: Duals are opposites or mirror images of original operators or signs, all '.' to '+' signs and complementing all 0's and 1's. Keep a note that the constants. In Boolean algebra, we can produce dual by changing all '+' signs to '.' variables are not complemented in this procedure.

PROFESSIONAL PUBLICATICNS (A Perfect Guide Towards Success)

i i

176.0	OR()	AND (+)	Operator
	AND (+)	OR(.)	Dual

Basic Identities of Boolean Algebra

columns that demonstrate the property of duality, Table 1.8.2 lists the most basic identities of Boolean algebra arranged into two

ı			
ı	ī	ı	i
ı	ı	H	i
ı	ı	ľ	Š
ı	ı	L	5
ı	ı	E	į
ı	ı	ŀ	ä
ı	ı	Ŀ	ì
J	ı	ŀ	'n
1	ij	ŀ	Š
ı	ı	ľ	ē
ı	ı		
ı	ı	ŀ	2
ı	ı		Section
ı	ı	Š	9
ı	ì	1	ä
ı	ı	ľ	9
ı	ı	-	2
۱	ı	2	Š
l	ı	ú	ģ
Ì	١	-	200
۱	ı	-	Ŋ
п	:4	-	-

DeMorgan's	$\overline{A \cdot B} = \overline{A} + \overline{B}$	$\overline{A+B} = \overline{A \cdot B}$
Distributive	A + BC = (A + B)(A + C) Distributive	A(B+C) = AB + AC
Associative	A(BC) = (AB)Z	A+(B+C)=(A+B)+C
Commutative	AB'=BA	A+B=B+A
Involution		A = A
Complement	A. A = 0	$A + \overline{A} = 1$
Idempotency	A. A= A	A+A=A
Null	A.0 = 0	A+1=1
Identity	A.1= A	A=0=A

Identity 5: It states that double complementation (Involution) restores the = 0. Both equations are true according to the definition of the UR Jugic operation. X+1=X, let X=1 to obtain 1+1=1 and then let X=0 to obtain 0+0substituting each of the two possible values for X. For example, to show that The first five identities involving a single variable can be easily verified by

written will not affect the result when using the OR and AND operations. Identity 6: The commutative law state that the order in which the variables are

variable to its original value. Thus, if X = 0, then X = 1 and X = 0 = X.

the parentheses can be removed altogether as follows, among three variables is independent of the order that is taken and therefore, Identifies 7: The associative laws, state that the result of forming an operation

$$X(YZ) = (XY)Z = XYZ.$$

PROFESSIONAL PUBLICATIONS (A Perfert Guide Towards Success)

Logic and Switching Theory

Fundamentals of Logic Design

1.35

Identity 9 is referred to as DeMorgan's theorem. This is a very important theorem and is used to obtain the complement of an expression-

Demorgans First Law: According to the DeMorgan's first law, the complement of a sum is equal to the product of the individual complements, that is,

If there exists 'N' variables, then the Demorgan's first law gives,

Demorgan's Second Law : According to the DeMorgan's second law, the complement of a product is equal to the sum of individual complements, that

$$\overline{A \cdot B} = \overline{A} + \overline{B}$$

If there exists 'N' variables, then the DeMorgan's second law gives,

$$\overline{A \cdot B \cdot C \cdot \dots + N} = \overline{A} + \overline{B} + \overline{C} + \overline{D} + \dots + \overline{N}$$

These Laws can be verified using truth table as shown in Table 1.8.3.

In blooks Truth Tables to Verify DeMorgan's Theorem

Del	horg	DeMorgans First Theorem	heorem	De	2	Morga	Morgans Sec	DeMorgans Second Theorem
D	œ	A + B	X.Y	A		8	BA	
0.	0	0	1	0		0	0 1	0 1 1-
0.	₩.	1	0	0		H	1 1	1 1 0
111	0	1	0	п		0	0 0	0 0 1
-	1	1	0	1		1	1 0	1 0 0

Algebraic Manipulations

circuit as well as less number of gates, which should be a designer's objectives. Minimization of the number of literals and the number of terms leads to less complex function designated as input to the gate. The literal may be primed or unprimed variable. When a Boolean expression is implemented with logic gates, each literal in the

available is a cut and try procedure using the postulates, the basic theorems. The manipulations. There is no such rules that will guarantee the final answer. The only method following examples Illustrates this procedure The number of literals in a Boolean function can be reduced by algebraic

Logic and Switching Theory Example Problem 1.27

1.37

Fundamentals of Logic Design

Simplify the following logic expressions using Boolean algebra.

Example Problem 1.26

Simplify the following boolean functions to least number of literals by manipulation of Boolean algebra.

- ABCD + ABD + BCD + AB + BC ABC + ABC + ABC + ABC
- 9 5 (B+C)(B+C)+A+B+C $x + xyz + \overline{x}yz + xw + x\overline{w} + \overline{x}y$
- (x + y + z)(x + y)x

Sol. :

(x+yx)[xz+xz(y+y)]

٥

A + AB + ABC + ABCD +

 $ABC + A\overline{B}C + AB\overline{C} = AB(C + \overline{C}) + A\overline{B}C$

= AB+ABC A[B+BC]

 $(: \times + \overline{\times} = 1)$

 $(\cdot \cdot \times + (y.z) = (x + y).(x+y))$

(A+B)(A+B)(A+C) ABC + ABC + ABC

- a) f = ABCD+ABD+BCD+AB+BC
- 3
- $\overline{BD(\overline{A} + AC)} + BC\overline{D} + \overline{AB} + B\overline{C} = \overline{BD(\overline{A} + \overline{C})(\overline{A} + A)} + BC\overline{D} + \overline{AB} + B\overline{C}$

 $\overline{BD}(\overline{A}+\overline{C})+B(\overline{A}+\overline{C})+BC\overline{D}=(\overline{A}+\overline{C})(\overline{B}D+B)+BC\overline{D}=(\overline{A}+\overline{C})(\overline{B}+B)+(D+B)+BC\overline{D}$

 $\overline{A}B + \overline{A}D + \overline{C}D + B(\overline{C} + C\overline{D}) = \overline{A}B + \overline{A}D + \overline{C}D + B(\overline{C} + \overline{D})(\overline{C} + C)$ $(\overline{A} + \overline{C})(D + B + BC\overline{D} = \overline{A}B + \overline{A}D + \overline{C}B + \overline{C}D + BC\overline{D}$

E

 $(A+B)(A+\overline{B})(\overline{A}+C) = (A+A\overline{B}+BA+B\overline{B})(\overline{A}+C)$

= 0+0+0+0+AC+ABC+ABC+0 (: $\times \cdot \times = 0$)

= AC[1+ \overline{B} +B] = [AC (1 + 1)]

(-1 + A = 1)

(:: 1 + A = 1)(: x · 1 = x)

= AA + AAB + BAA + ABB + AC + ABC + ABC + CBB

= A[B + C]

- $\overline{AB} + \overline{AD} + \overline{CD} + B\overline{C} + B\overline{D}$
- $=\chi(1+yz+w+\overline{w})+\overline{x}yz+\overline{x}y = x+\overline{x}y(z+1) = x+\overline{x}y = (x+\overline{x})\cdot(x+y)$
- f = ABC + ABC + ABC + ABC
- $\overline{A} + \overline{B} + \overline{C} + BC(\overline{A} + A) + A\overline{B}\overline{C} = BC + \overline{B}[1 + A\overline{C}] + \overline{A} + \overline{C}$
- B + C + A + C = B + A + 1 = 1
- $B\overline{B} + B\overline{C} + BC + C\overline{C} + \overline{A} + B + \overline{C} = \overline{BC} + BC + \overline{A} + B + \overline{C}$
- C(1+B)+B(1+C)+A = A+B+C
- f = (x + y + z)(x + y)(x)

e)

- (x + y + z)(x + xy)
- x.x + xy.x + x.y + xy.y + xz + xyz = x + xy + xz + xyz
- = x(1 + y + z + yz) = x
- $= (x + \overline{x} \overline{y})[(xz + x\overline{z}(y + \overline{y}))] = (x + \overline{x})(x + \overline{y})[(xz + x\overline{z}(y + \overline{y}))]$

- $(x+\overline{y})[x(z+\overline{z})] = (x+\overline{y})x$

PRCTESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

- $(x+\overline{y})[xz+x\overline{z}(y+\overline{y})] = (x+\overline{y})(xz+x\overline{z})$

- 0 0 5 $f = x + xyz + \overline{x}yz + xw + x\overline{w} + \overline{x}y$ (B+C)(B+C)+A+B+C

- c) B(A+B)(B+C)
- 0 B(A + C) + C
- AC(ABD) + ABCD + ABC

Example Problem 1.28

WYNES CON BY WAY

Simplify the following expressions

(A+B)(A+B+D)D

c) A + AB + ABC +.... = A[1+B+BC+....]

= A[1]

= AC = AC.1

- AB(B+C)
- AB(A+C)+AB(A+B+C)

Sof. :

a

- $f = (\overline{A} + B)(A + B + D)\overline{D} = (\overline{A}A + \overline{A}B + \overline{A}D + BA + B + DB)\overline{D}$
- = (AB + AD + BA + B + DB)D
- AB + AD + B(A+1) + DB D $(: \times \times = 0)$

Thus from Table 1.8.4, we have complement of a given function as, F = ABC + ABC + ABC

Find the complement of a function, F = AB + C

Sol : 1.8.5. The value of a F computed for every combination of A, B and C is as shown in Table

Table 1.8.5 Truth Table of Given Boolean Function

1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory

1.43

Fundamentals of Logic Design

column F as shown in fifth column of Table 1.8.5. From Table 1.8.5, we have The complement of a function F is obtained by complementing each entry in

complement of a function as,

Second Method (Using DeMorgan's Theorem): The complement of a function may also be obtained algebraically through Demorgan's Theorem. The following examples illustrates the complement of a function obtained using Demorgan's theorem.

Example Problem 1.32

Find the complement of the functions,

F = A'BC' + AB'C

5 F = A(B'C + B'C')

a The complement of a function obtained by applying Demorgans theorem as many

times as necessary is as follows,

F' = (A' B C' + A B' C)' = (A' B C')' . (A B' C')' $(\cdot \cdot \cdot (A + B)' = A' \cdot B')$

= (A + B' + C) (A' + B + C) $= [(A')' + B' + (C)'] \cdot [A' + (B')' + (C)']$

(: (A.B)' = A'+B')

F' = [A (B'C + B'C')]'= A' + [B'C + B'C']'

5

= A' + [(B'C)', (B'C')']

(: (A+B)' = A' . B') (: (AB)' = A'+B')

 $= A' + [(B')' + C'] \cdot [(B')' + (C')']$

= A' + (B + C') . (B + C)

Third Method (Using Duals): The complement of a given Boolean function obtained using duals are illustrated using the following examples,

Determine the complements of the following functions,

f = ABC+ABC.

⋾ t = B(AC + A.C).

Sol. :


f = ABC+ABC

=

STEP 1: The dual of f1,

$$f_1^0 = (\overline{A} + \overline{B} + C) \cdot (A + \overline{B} + \overline{C})$$

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)



Scanned by CamScanner

STEP 2 : The complement of each literal :

$$f_1^{p^*} = (A+B+\overline{C}).(\overline{A}+B+C)$$

For verification consider $f_1' = \overline{A} B C + A \overline{B} C$

$$= (\overline{A} \cdot \overline{B} \cdot C) \cdot (A \cdot \overline{B} \cdot \overline{C})$$
$$= (\overline{A} + \overline{B} + \overline{C}) \cdot (\overline{A} + \overline{B} + \overline{C})$$

 $=(A+B+\overline{C}).(\overline{A}+B+C)$

II)
$$f_2 = \overline{B}.(AC + \overline{A}.\overline{C})$$

Step 1 : (Dual of
$$f_2$$
) : $f_2^0 = \overline{B} + \left[(A+C), (\overline{A}+\overline{C}) \right]$

Step 2 : (Complement each literal) :
$$f_2^{\circ} = B + [(\overline{A} + \overline{C}) \cdot (A + C)]$$

STANDARD FORMS

be expressed in following forms, variables either in its complement or in its normal form. In general, Boolean function can Logical functions are generally expressed in terms of various combinations of logical

- SOP/FOS Forms.
- Canonical SOP/POS Forms.

in its normal form. of variables or literals may present in the Boolean expression either in complement or either in complement or in its normal form. In SOP/POS forms, one, two or any number In the canonical form, all 'n' variables or literals are present in the Boolean expression

Minterms and Maxterms

may appear in either form, then there are four possible combinations : ab, ab, ab are two binary variables a and b combined with AND operation and each variable or in its normal form is called a minterm or a standard product. Suppose that there Minterms: The product of n-variables in Boolean expression either in its complement

properties of minterms are listed below, In general, for n number of variables, 2n minterms will be determined. Some

- Each minterm is obtained by the AND operation of all the variables of the function
- complemented form In minterms, each variable may appear in either in its normal form or in its

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory If the corresponding bit of the binary number is 0 each variable is in

- number is 1. Minterm is denoted by the symbol Σ . complemented form and in its normal form if the corresponding bit of the binary
- appear in either form, then there are four possible combinations : a + b, two binary variables a and b associated with OR operation and each variable may or in its normal form is called a maxterm or standard sum. Suppose that there are Maxterms: The sum of n variables Boolean expression either in its complemented

a + b, a + b and a + b. In general, for n number of variables 2n maxterms are determined. Some

- properties of maxterms are listed below,
- Each maxterm is obtained by the OR operation of all variables of the function.
- In maxterms each variable may appear in either in its normal form or in complemented form.
- If the corresponding bit of the binary number is 1 each variable is in variable is in its normal form. Maxterm is denoted by the symbol #. complemented form and if the corresponding bit of the binary number is 0 each
- Table 1.9.1 represents the eight possible minterms and maxterms for three binary variables A, B and C.

Three Variable Minterms and Maxterms

1	-	-	-		0	0	0	0	Þ	
I	-		0	0	-	-	0	0		V.
	1949	0	144	0	100	0	-	0	. 0	
	ABC	ABC	ABC	ABC	ĀBC	ĀBC	ĀBC	ĀBC	Representing Terms	Minterms
	7m	m ₆	ms	lui,	пр	me	tur	m ₀	Designation	erms
0.00	A + B + C	$\overline{A} + \overline{B} + C$	A + B + C	A+B+C	A + B + C	A + B + C	A + B + C	A+B+C	Representing Terms	Maxterms
MZ		M ₆	M ₅	M,	M	M ₂	Mı	Mo	Designation	erms

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

From the above Table 1.9.1, we can clearly say, that each maxterm is the complement of the corresponding minterm. For example, if the maxterm is $(\overline{A} + \overline{B} + \overline{C})$, then its complement is,

(A + B + C) = ABC, which is its corresponding minterm.

SOP/POS Forms

In standard forms, the terms that form the Boolean function may contain one, two, or any number of literals. There are two types of standard forms,

1) Sum of Products: The sum of products is a Boolean expression containing AND terms, called product terms, of one, two or more literal each. The sum denotes Oring of these terms. Following is an example of SOP expression.

Example:
$$F_1$$
 (A, B, C) = A'B + AB'C + A'

The 3 variable function F_1 has three product terms of two, three and one literals each, respectively. All these product terms are connected with OR operation,

 Product of Sums: The product of sums is a Boolean expression containing OR terms, called sum terms, of one, two or more literals each. The product denotes ANDing of these terms.

Example :
$$F_1(A, B, C) = (A + B + C) \cdot (A + B) \cdot (A)$$

In this example, Boolean function, F_1 , of three variables has three sum terms of three, two and one literals each respectively. All these sum terms are connected with AND operation.

Canonical Forms / Standard Forms

In Canonical forms, the terms that form the Boolean function must contain all n variables either in complemented or in its normal form. There are two types of canonical forms,

Canonical Sum of Products (CSOP): It is an SOP form in which each product term contains all the variables either in complemented or true (uncomplemented) form i.e., for a 3 variable function, each product term must contain 3 variables. So, here each product term is called as minterm. This type of representation is called "sum of minterms" (or) canonical SOP (or) disjunctive normal expression.

Examples of canonical SOP with 3 variables are,

- 1) ABC + ABC + ABC
- ii) $xyz + \overline{x}\overline{y}z + x\overline{y}\overline{z}$.

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory 1.47 Fundamentals of Logic Dosign

2) Canonical Product of Sums (CPOS): It is a POS form in which each sumterm contains all the variables either in complemented or uncomplemented form i.e., for a 3-variable Boolean function, each sum term must contain 3-variables.

Here, the sum is also called as "maxterm" and this type of expression is called canonical POS or product of maxterms or Conjuctive Normal Form (CNF) expression. The following are the examples of canonical POS form for a three input variable.

- $(x+y+z).(x+\overline{y}+\overline{z}).(\overline{x}+\overline{y}+z).$
- i) (A+B+C).(A+B+C).(A+B+C).

Conversion of a SOP/POS Form to the Canonical Form

Conversion From SOP to Canonical SOP Form

To convert SOP to canonical SOP form, the following steps are required,

STEP 1 : Examine each term, if it is a minterm, retain it and continue to the next term.

STEP 2: If the product term is not a minterm, then check the literals that do not occur.

Step 3: Multiply (AND) the product terms having missing literal x_i with $x_i + \overline{x}_i$.

For example, for a three variable function (x, y, z) if a term contains only x, y, since it is not a minterm hence multiply xy with $(z+\overline{z})=xy(z+\overline{z})=xyz+xy\overline{z}$.

STEP 4: Multiply all products and eliminate the redundant terms.

xample Problem 1.34

Convert the following Boolean expression into canonical SOP form.

f = AB + C + ABC


Sol. :

Step 1 : Check the product terms or minterms for the missing literals in it.

F(A, B, C) = AB + C + ABC

Literal C is missing

No literal is missing



Example Problem 1.37

Convert the Boolean expression $f(A, B, C) = (\overline{A} + \overline{B}) (A + \overline{C}) (A + B)$ into its CPOS form,

Sol. :


In the given expression, maxterm $\bar{A} + \bar{B}$ has the missing literal C, so add it with C. \bar{C} . And maxterm $A + \bar{C}$ has the missing literal B, so add it with $B + \bar{B}$. Also A + B has the missing literal C, so add it with $C.\bar{C}$. Thus,

$$f = (\overline{A} + \overline{B} + C\overline{C}) (A + \overline{C} + B\overline{B}) (A + B + C\overline{C})$$

$$= (\overline{A} + \overline{B} + C) (\overline{A} + \overline{B} + \overline{C}) (A + \overline{B} + \overline{C}) (A + B + C) (A + B + C)$$


$$= (\overline{A} + \overline{B} + C) (\overline{A} + \overline{B} + \overline{C}) (A + \overline{B} + \overline{C}) (A + B + \overline{C}) (A + B + C)$$

$$= (\overline{A} + \overline{B} + C) (\overline{A} + \overline{B} + \overline{C}) (A + \overline{B} + \overline{C}) (A + B + \overline{C}) (A + B + C)$$



15

one, three, or any odd number of errors in each character being transmitted. parity of the received character is not even, it implies that atleast one bit has changed How the Errors are Defected : Suppose if an ASCII character is transmitted with even its value during transmission. This is illustrated in Fig. 1.6.1. This method detects parity. At the receiving end the parity of the transmitted character is checked, if the



an ACK (Acknowledge) control character having even parity eight bits 00000110. 10010101 (shown in Table 1.6.1). If no error is detected, the receiver sends back back a NAK (Negative Acknowledge) control character having even parity 8 bits random and will not occur again. Thus, if the receiver detects a parity error, it sends the transmitter to retransmit the character on the assumption that the error was What is done After an Error is Detected: Once an error is detected, one must request

BINARY LOGIC AND GATES

Binary Logic

by (HIGH, LOW) or (ON, OFF) or (TRUE, FALSE) or (YES, NO) or (0, 1). such as a, b, c or A, B, C. The two values the variables take may be represented operations. The variables are designated by using either upper or lower case letters Binary logic consists of variables that takes on two discrete values, and logical

- There are three types of logic operations AND, OR and NOT.
- a mathematical expression. Binary logic is used to define manipulation and processing of binary information using
- Binary logic is also used to analyze and design of digital systems

PROFESSIONAL PUBLICATIONS (A Perfect Guide Towards Success)

Logic and Switching Theory

1.29

Fundamentals of Logic Design

MARIE Logical NOT Operation


the NOT gate, then the output (F) can be expressed as, NOT operation is performed on a single input variable. If A is an input variable to

$$F = \overline{A}$$
 (or) A' .

This expression is read as, "F equals NOT A" or "F equals the inverse of A" or "F

and a logic 0 to a logic 1. In terms of logic levels, it changes a logic HIGH to a logic LOW one logic level to it's opposite level. In terms of bits, it changes a logic 1 to a logic 0 equals the complement of A". NOT operation is also referred as "inversion or complementation". It changes the

understanding. For this, Fig. 1.7.1 is considered and the analogy of NOT is shown in Table The NOT operation can be realized by using a switching circuit for better



Switch Condition (Input) Lamp Condition (Output) Switch close (high) Switch open (low) Lamp ON (high) Lamp OFF (low)

When switch 'S' is open, lamp is 'ON' and when switch 'S' is close, lamp is OFF

Logical AND Operation

A and B are combined using the AND operation, the result F, can be represented as, Logical AND operation is performed on a two or multiple input variables. If two inputs

shows the result of the AND operation on the variables A and The common symbol for logical AND operation is multiplication symbol (.). Table 1.7.2

The process can be explained as

Step 1 : The least significant bits are added i.e., 0 + 0 = 0.

STEP 3: The carry generated in the second step is 1, added to the next higher significant i.e., 1+1=0 with a carry 1. STEP 2: The carry in the previous step is 0. The next higher significant bits are added

bits i.e., 0 + 1 + 1 = 0 with a carry 1. Hence, the sum obtained is 11000. Its equivalent in decimal numbers system is

|原理形 Binary Subtraction

always two cases, subtraction is started from the LSB and proceeded to the MSB. In subtraction there are Subtraction of two binary numbers is same as in the decimal number system. The

Case 1 (When Borrow is not Taken): Suppose that the minued is 1100 and subtrahend

The process of subtraction in this case can be explained as,

- STEP 1: The LSB in first column are 0 and 0. Hence 0 0 = 0.
- Step 2: In the next column, subtraction is again performed between 0 and 0.
- STEP 3: In the next column, the difference is obtained by subtracting 1 and 0. So, 1 - 0 = 1.
- STEP 4: At the last, subtract 1 1 = 0, so the difference is 0100.
- Case 2 (When Borrow is Taken): Suppose that minuend is 100 and subtrahend is 0110.

PROFESSIONAL PUBLICATIONS (A Perf. at Guide Towards Success)

Logic and Switching Theory

Fundamentals of Logic Design

The process of subtraction in this case is as follows,

- STEP 1 : The LSB's in the first column are 0 and 0, so the difference is 0 0
- third and second column will become 0, 1, 10 respectively. Thus the result the borrowing has to be done from next higher bit. Hence, the minuend in fourth, the borrow will be taken from the adjacent higher bit, but that bit is also 0. So, Step 2: In the second column, the subtraction of 1 from 0 is not possible. So, obtained in the second column is 10 - 1 = 1.
- Step 3: In the third column, the result is 1 1 = 0.
- Step 4: The difference obtained in the fourth column is 0 0 = 0.

Finally, the result is 0010.

Binary Multiplication

multiplication. The procedure is as follows, It is much simpler than decimal multiplication. The process is similar to that of decimal

STEP 1 : The LSB of multiplier is taken. If,

- The multiplier bit is 1, copy the multiplicand as it is given
- The multiplier bit is 0, place 0 at all the bit positions
- STEP 2 : By taking the next higher multiplier bit, find the partial product and write it by shifting 1 bit towards left.

STEP 3 : Repeat the step 2 for all bits in multiplier.

STEP 4 : Find the sum of all the partial products.


Example Problem 1.12

Multiply the given binary numbers

- 1010 and 110
- 11.01 and 1.01.

Sol. :

					0
н	-				
	0	pa			
1	***	0	0	*	**
4	0	-	0	ü	0
0		0	0	jús	+
0	1 0 1 0		0	0	0
+ Result	← Shift 1 bit left	← Shift 1 bit left		Multiplier	Multiplicand
					(b)
-	-				
0	gud.	0			
6	0	0	100	×	-
0	-	0	-	-	1
0		0	0	0	0
pá	1 1 0 1		14	-	1
← Result	← Shift 1 bit left	← Shift 1 bit left		Multiplier	Multiplicand



Log


Logic and Switching Theory

- The memory of a digital computer stores the results, program and data.
- The program and data given by the user are transferred into memory by means of an input device such as keyboard. An output device, such as a CRT monitor, displays the results of the computations to the user. An output device, printer gives the printed results of the computations to the user.

Life without numbers is quite impossible to imagine. A number can be denoted using different symbols. A system of symbols used to represent numbers is called a number system.

These number systems are classified according to the values of the base of the number system. Base (or radix) represents the total number of symbols (or digits) used in a system.

- In digital systems, following number systems are frequently used,
 - Decimal Number System: In decimal number system, there are 10 digit symbols used to represent any number. So its base is 10 and the symbols used to represent any number are 0,1, 2, 3, 4, 5, 6, 7, 8, 9.
 - Binary Number System: In binary number system, 2 digit symbols (called bit) are used to represent any number. So its base is 2 and symbols used to represent any binary number are 0, 1. In binary number system, a group of 4 and 8 bits is called a nibble and a byte respectively.
 - Octal Number System: Octal number system uses 8 digit symbols. They are 0, 1, 2, 3, 4, 5, 6, 7. Because of 8 digits its base is 8.
 - Hexadecimal Number System: Hexadecimal number system uses 16 symbols hence its base is 16. The 16 symbols used in hexadecimal number system are 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, F.
- A number is made up with a collection of digits and it has two parts, integer and fractional, set apart by a radix point(.). General representation of a number is as shown in Fig. 1.2.1.



Where,

A number. Nb

Radix or base of the number system. b

Number of digits in integer part. n