

SMARTLINK AC1200 Wi-Fi ROUTER

User Manual — Setup, Indicators, Configuration & Troubleshooting

1. Product Overview

The SmartLink AC1200 is a dual-band wireless router designed to provide wired and wireless Internet access for homes and small offices. It supports 2.4 GHz and 5 GHz Wi-Fi networks, Ethernet connections, automatic Internet configuration, guest access, and basic security controls. Place the router in an open, elevated location away from thick walls, metal objects, microwaves, and other sources of wireless interference.

2. Ports & Buttons

Component	Function
Power	Connect the supplied power adapter. Use only the recommended adapter.
WAN / Internet	Connect the Ethernet cable from the modem/ONT or ISP equipment.
LAN 1–4	Connect computers, TVs, printers, consoles, or other wired devices.
WPS	Starts WPS pairing for compatible wireless devices.
Reset	Restores factory settings when held for approximately 10 seconds while powered on.

3. LED Indicator Guide

Indicator	Normal	Red / Blinking
Power	Solid white/green: router powered on.	Off: check adapter and power outlet.
Internet	Solid: Internet connection available.	Red: WAN/ISP connection problem; blinking may indicate connection activity or failure.
2.4G / 5G	On: wireless network active.	Off: corresponding Wi-Fi band is disabled.
LAN	On/blinking: Ethernet device connected or transmitting.	Off: cable/device may be disconnected.

4. Quick Installation

- **Connect WAN:** Plug the ISP/modem Ethernet cable into the blue WAN/Internet port.
- **Connect power:** Attach the supplied adapter and switch the router on.
- **Wait for startup:** Allow 1–2 minutes for the Power and Internet indicators to stabilize.
- **Connect a device:** Join the default Wi-Fi network printed on the router label, or connect through LAN.
- **Open setup:** Visit the router's local management address shown on its label/manual and complete the setup wizard.
- **Secure the network:** Change the administrator password and Wi-Fi password; use WPA2/WPA3 security when available.

5. Basic Configuration

From the web administration interface, users can change the Wi-Fi name (SSID), Wi-Fi password, security mode, guest network settings, DHCP options, LAN configuration, parental/access controls, firmware settings, and device status. Save/apply changes after editing. Do not disconnect power while firmware is being updated.

6. Troubleshooting

Problem	Recommended Checks
Internet light is red	Check WAN cable → restart modem/ONT and router → verify ISP service → inspect WAN status in the router interface.
No Wi-Fi	Check that Wi-Fi is enabled → restart router → verify SSID visibility → reconnect using the correct password.
Slow Wi-Fi	Move closer to router → reduce interference → try 5 GHz nearby → restart router → check connected devices.
Device cannot connect	Forget and reconnect to Wi-Fi → verify password → restart device → check whether access control is blocking it.
Router does not power on	Check power outlet and adapter → reseal connector → try another compatible outlet → avoid using an unapproved adapter.

7. Safety & Reset

Keep the router dry and well ventilated. Do not open the device or use damaged cables. A factory reset erases custom configuration such as Wi-Fi names, passwords, and ISP settings. Before resetting, record required settings if possible. After reset, reconfigure the Internet connection and secure the wireless network.

Support Reference: This manual is a synthetic project document created for the TechSupport RAG demonstration. It is intended to provide realistic troubleshooting content for PDF retrieval and should not be treated as documentation for a real commercial router.