```
1 void setup()
2 \mid \{
3
     Serial.begin(9600); //baud rate for USB
     Serial3.begin (9600); //baud\ rate
4
5 }
 6
 7
  void loop()
8
   {
9
     int iDigitASCII = 0;
10
     //Xbee is connected to one of the serial I/O ports
11
12
     iDigitASCII = Serial3.read();
13
14
     //suppressing the nothing recieved characters
     if (iDigitASCII != −1)
15
16
17
       //printing recieved data to monitor
       Serial.println(iDigitASCII);
18
19
20 }
21
22|//From\ the\ sending\ module\ we\ write:
23 \mid // \quad 1 \quad \mid n \quad 2 \quad \mid n \quad 3 \quad \mid n \quad 4 \quad \mid n
                                          5 \mid n
24 //and we recieve the cooresponding ASCII values:
   // 49 10 50 10 51 10 52 10 53 10
```