Assembly Language Programming of 8085

Unit-2

Topics

- Introduction
- 2. Programming model of 8085
- Instruction set of 8085
- Example Programs
- Addressing modes of 8085
- Instruction & Data Formats of 8085

1. Introduction

- A microprocessor executes instructions given by the user
- Instructions should be in a language known to the microprocessor
- Microprocessor understands the language of 0's and 1's only
- This language is called Machine Language

- For e.g.
 - 01001111
 - Is a valid machine language instruction of 8085
 - It copies the contents of one of the internal registers of 8085 to another

A Machine language program to add two numbers

00111110

00000010

00000110

00000100

10000000

;Copy value 2H in register A

;Copy value 4H in register B

;A = A + B

Assembly Language of 8085

- It uses English like words to convey the action/meaning
- For e.g.
 - MOV to indicate data transfer
 - ADD to add two values
 - SUB to subtract two values

Assembly language program to add two numbers


```
MVI A, 2H ;Copy value 2H in register A
MVI B, 4H ;Copy value 4H in register B
ADD B ;A = A + B
```

Note:

- Assembly language is specific to a given processor
- For e.g. assembly language of 8085 is different than that of Motorola 6800 microprocessor

Microprocessor understands Machine Language only!


- Microprocessor cannot understand a program written in Assembly language
- A program known as **Assembler** is used to convert a Assembly language program to machine language




Low-level/High-level languages

- Machine language and Assembly language are both
 - Microprocessor specific (Machine dependent) so they are called
 - Low-level languages
- Machine independent languages are called
 - High-level languages
 - For e.g. BASIC, PASCAL,C++,C,JAVA, etc.
 - A software called **Compiler** is required to convert a high-level language program to machine code

2. Programming model of 8085





Overview: 8085 Programming model

- Six general-purpose Registers
- Accumulator Register
- Flag Register
- Program Counter Register
- Stack Pointer Register

Six general-purpose registers

- B, C, D, E, H, L
- Can be combined as register pairs to perform 16-bit operations (BC, DE, HL)

Accumulator – identified by name A

- This register is a part of ALU
- 8-bit data storage
- Performs arithmetic and logical operations
- Result of an operation is stored in accumulator

3. Flag Register

- This is also a part of ALU
- 8085 has five flags named
 - Zero flag (Z)
 - Carry flag (CY)
 - Sign flag (S)
 - Parity flag (P)
 - Auxiliary Carry flag (AC)

- · These flags are five flip-flops in flag register
- Execution of an arithmetic/logic operation can set or reset these flags
- Condition of flags (set or reset) can be tested through software instructions
- 8085 uses these flags in decision-making process

4. Program Counter (PC)

- A 16-bit memory pointer register
- Used to sequence execution of program instructions
- Stores address of a memory location
 - where next instruction byte is to be fetched by the 8085
- when 8085 gets busy to fetch current instruction from memory
 - PC is incremented by one
 - PC is now pointing to the address of next instruction

5. Stack Pointer Register

- a 16-bit memory pointer register
- Points to a location in Stack memory
- Beginning of the stack is defined by loading a 16-bit address in stack pointer register

Instruction Set of 8085

- Consists of
 - 74 operation codes, e.g. MOV
 - 246 Instructions, e.g. MOV A,B
- 8085 instructions can be classified as
 - 1. Data Transfer (Copy)
 - 2. Arithmetic
 - 3. Logical and Bit manipulation
 - 4. Branch
 - 5. Machine Control

Data Transfer (Copy) Operations

- Load a 8-bit number in a Register
- 2. Copy from Register to Register
- Copy between Register and Memory
- Copy between Input/Output Port and Accumulator
- Load a 16-bit number in a Register pair
- Copy between Register pair and Stack memory

Example Data Transfer (Copy) Operations Instructions

MVI B, 4FH

MOV A,B

MOV M,B

OUT 01H

IN 07H

LXI H, 2050H

- Load a 8-bit number 4F in register B
- Copy from Register B to Register A
- Load a 16-bit number2050 in Register pair HL
- Copy from Register B to Memory Address 2050
- 5. Copy between Input/Output Port and Accumulator

2. Arithmetic Operations

- Addition of two 8-bit numbers
- 2. Subtraction of two 8-bit numbers
- 3. Increment/ Decrement a 8-bit number

Example Arithmetic Operations / Instructions

- Add a 8-bit number 32H to Accumulator
- Add contents of Register B to Accumulator
- Subtract a 8-bit number 32H from Accumulator
- Subtract contents of Register
 from Accumulator
- Increment the contents of Register D by 1
- Decrement the contents of Register E by 1

ADI 32H

ADD B

SUI 32H

SUB C

INR D

DCR E

Logical & Bit Manipulation Operations

- 1. AND two 8-bit numbers
- 2. OR two 8-bit numbers
- 3. Exclusive-OR two 8-bit numbers
- 4. Compare two 8-bit numbers
- 5. Complement
- Rotate Left/Right Accumulator bits

Example Logical & Bit Manipulation Operations / Instructions

- Logically AND Register H with Accumulator
- Logically OR Register L with Accumulator
- Logically XOR Register B with Accumulator
- Compare contents of Register C with Accumulator
- 5. Complement Accumulator
- 6. Rotate Accumulator Left

ANA H

ORA L

XRA B

CMP C

CMA

RAL

4. Branching Operations

These operations are used to control the flow of program execution

1.Jumps

- Conditional jumps
- Unconditional jumps

2.Call & Return

- Conditional Call & Return
- Unconditional Call & Return

Example Branching Operations / Instructions

- Jump to a 16-bit Address 2080H if Carry flag is SET
- Unconditional Jump
- Call a subroutine with its 16-bit Address
- 4. Return back from the Call
- Call a subroutine with its 16-bit Address if Carry flag is RESET
- 6. Return if Zero flag is SET

JC 2080H

JMP 2050H

CALL 3050H

RET

CNC 3050H

RZ

Machine Control Instructions

These instructions affect the operation of the processor. For e.g.

HLT Stop program execution

NOP Do not perform any operation

4. Writing a Assembly Language Program

- Steps to write a program
 - Analyze the problem
 - Develop program Logic
 - Write an Algorithm
 - Make a Flowchart
 - Write program Instructions using Assembly language of 8085

Program 8085 in Assembly language to add two 8bit numbers and store 8-bit result in register C.

1. Analyze the problem

Addition of two 8-bit numbers to be done

2. Program Logic

- Add two numbers
- Store result in register C
- Example

```
10011001 (99H) A
+00111001 (39H) D
11010010 (D2H) C
```

3. Algorithm

Get two numbers

2. Add them


3. Store result

4. Stop

Translation to 8085 operations

- Load 1st no. in register D
- Load 2nd no. in register E
- Copy register D to A
- Add register E to A
- Copy A to register C
- Stop processing

4. Make a Flowchart



- Load 1st no. in register D
- Load 2nd no. in register E
- Copy register D to A
- Add register E to A
- Copy A to register C
- Stop processing

5. Assembly Language Program

- Get two numbers
- a) Load 1st no. in register D
- b) Load 2nd no. in register E
- 2. Add them
- a) Copy register D to A
- b) Add register E to A
- 3 Store result
- a) Copy A to register C
- 4. Stop
- a) Stop processing

MVI D, 2H MVI E, 3H

MOV A, D

MOV C, A

HLT

Program 8085 in Assembly language to add two 8bit numbers. Result can be more than 8-bits.


1. Analyze the problem

- Result of addition of two 8-bit numbers can be 9-bit
- Example


```
10011001 (99H) A
+10011001 (99H) B
100110010 (132H)
```

The 9th bit in the result is called CARRY bit.

- How 8085 does it?
 - Adds register A and B
 - Stores 8-bit result in A
 - SETS carry flag (CY) to indicate carry bit



Storing result in Register memory



Step-1 Copy A to C

Step-2

- a) Clear register B
- b) Increment B by 1

2. Program Logic

- Add two numbers
- Copy 8-bit result in A to C
- If CARRY is generated
 - Handle it
- 4. Result is in register pair BC


3. Algorithm


- Load two numbers in registers D, E
- 2. Add them
- 3. Store 8 bit result in C
- 4. Check CARRY flag
- 5. If CARRY flag is SET
 - Store CARRY in register B
- 4. Stop

Translation to 8085 operations

- Load registers D, E
- · Copy register D to A
- Add register E to A
- · Copy A to register C
- Use Conditional Jump instructions
- Clear register B
- Increment B
- Stop processing


4. Make a Flowchart





5. Assembly Language Program

- Load registers D, E
- · Copy register D to A
- Add register E to A
- Copy A to register C
- Use Conditional Jump instructions
- Clear register B
- Increment B
- Stop processing



Addressing Modes of 8085

 Format of a typical Assembly language instruction is given below-

address 07H

- The various formats of specifying operands are called addressing modes
- Addressing modes of 8085
 - Register Addressing
 - Immediate Addressing
 - Memory Addressing
 - Input/Output Addressing

Register Addressing

- Operands are one of the internal registers of 8085
- Examples-

MOV A, B

ADD C

2. Immediate Addressing

- Value of the operand is given in the instruction itself
- Example-

MVI A, 20H LXI H, 2050H ADI 30H

SUI 10H

Memory Addressing

- One of the operands is a memory location
- Depending on how address of memory location is specified, memory addressing is of two types
 - Direct addressing
 - Indirect addressing

3(a) Direct Addressing

- 16-bit Address of the memory location is specified in the instruction directly
- Examples-


LDA 2050H ;load A with contents of memory location with address 2050H

STA 3050H; store A with contents of memory location with address 3050H

3(b) Indirect Addressing

- A memory pointer register is used to store the address of the memory location
- Example-

MOV M, A ;copy register A to memory location whose address is stored in register pair HL



4. Input/Output Addressing

- 8-bit address of the port is directly specified in the instruction
- Examples-

IN 07H OUT 21H

Instruction & Data Formats

8085 Instruction set can be classified according to size (in bytes) as

- 1. 1-byte Instructions
- 2. 2-byte Instructions
- 3. 3-byte Instructions

One-byte Instructions

- Includes Opcode and Operand in the same byte
- Examples-

Opcode	Operand	Binary Code	Hex Code
MOV	C, A	0100 1111	4F H
ADD	В	1000 0000	8 0 H
HLT		0111 0110	76 H

Two-byte Instructions

- First byte specifies Operation Code
- Second byte specifies Operand
- Examples-

Opcode	Operand	Binary Code	Hex Code
MVI	A, 32H	0011 1110	3EH
		0011 0010	32 H
MVI	B, F2H	0000 0110	06 H
		1111 0010	F2H

1. Three-byte Instructions

- · First byte specifies Operation Code
- Second & Third byte specifies Operand
- · Examples-

Opcode	Operand	Binary Code	Hex Code
LXI	H, 2050H	0010 0001	21 H
		0101 0000	50 H
		0010 0000	20 H
LDA	3070H	0011 1010	3A H
		0111 0000	70 H
		0011 0000	30 H

2. Two-byte Instructions