


- * Pick GPIO for rocket—ready signal.
- * Buffer btw rocket—ready signal and BB, ign. board, etc?
- * Umbilical connection state
- * Ignition fuse state


Portland State Aerospace Society http://psas.pdx.edu/>

Sheet: /BeagleBone Black Cape/ File: beaglebone_cape.sch


Title: LTC3 BeagleBone Black Cape Interface

Size: B Date: 2016-01-16
KiCad E.D.A. kicad 4.0.0rc1a-stable Rev: A ld: 5/7





External Device Power



External Device Triggers

- TODO:

 * Determine values for bleeder resistor
 and filter capacitor on each output connector.

 * Pick new PolyFuses, 0.5—1.0A max.

Portland	State Aeros	pace Society	<http: <="" th=""><th>psas.pdx.edu/></th></http:>	psas.pdx.edu/>

Sheet: /External Device Power & Triggers/
File: external_devices.sch

Title: LTC3 External Power & Triggers

ize: B	Date: 2016-01-16	Rev: A
iCad E.D.A.	kicad 4.0.0rc1a-stable	ld: 7/7