pump_sizing

May 10, 2016

1 Electric Feed System Pump Size Estimates

We're exploring the use of an all-electric pump for the propellant feed system. What follows is a preliminary pump sizing and requirements analysis to guide further inquiry.

1.1 Design Approach

Turbomachines, contrary to popular belief, are not not powered by black magic (largely). The process for determining pump requirements is a straight forward one. First we need to establish design goals. High efficiency, high performance, and minimum mass are desirable from a vehicle mass faction standpoint. But designs that increase efficiency and decrease mass can also increase pump-inlet pressure required to suppress cavitation, which can in turn lead to increases in propellant tank mass. Also we do not wish to compromise design simplicity, reliability, operational life, and cost. In some sense these are hard tradeoffs. So we should first define the relative importance/emphasis of these design goals.

1.2 Design Inputs

Engine and vehicle requirements dictate the types, flow rates and pressure levels of the propellants that the pumps deliver to the engine thrust chamber. These are assumed to be given from an earlier and more fundamental analysis of vehicle design. The pumps must deliver propellant without requiring an inlet pressure greater that that allowed by other parts of the feed system. A pump operating under a specified condition (rotational speed and fluid angles of attack on internal surfaces) produce a constant-volume flow rate and constant head rise. To summarize the (given) inputs are propellant mass flow rate, pump pressure rise, pump inlet pressure, and physical and derived quantities such as propellant density and vapor pressure, volume flow rate and NPSH. Volumetric flow rate, Q, is given by

$$Q = \frac{\dot{m}}{\rho}$$

where \dot{m} is the mass flow rate, and ρ is the fluid density. The pump head rise is given by

$$H_p = \frac{\Delta p_p}{g_0 \rho}$$

where Δp_p is the required rise in pressure and g_0 is the gravitational acceleration. Available Net Positive Suction Head is given by

$$NPSH_{available} = \frac{p_i - p_v}{g_0 \rho}$$

Note that this formulation of NPSH assumes that the elevation head (including the additional head due to acceleration of the launch vehicle) is small relative to the vapor pressure and tank pressure.

Also note that due to the preponderence of barleycorn units used in hydraulic engineering this document will use them as well, both by convention, and also due to the fact that most vendor data sheets are provided in that unit system.

1.3 Useful Physical Properties of Propellants

	density ρ [kg/m ³]	vapor pressure p_v [Pa]
ethanol	789	8.84E3
LOX	1141	5E6

```
In [1]: import math as m
        # propellant properties and physical constants
       rho = 789
                                              # propellant density (ethanol and LOX respectively) [kg/m
       p_v = 8.84E3
                                              # propellant vapor pressure [Pa]
       g_0 = 9.81
                                              # gravitational acceleration [m/s/s]
        # rocket model (assuming sea-level operation)
       isp = 246 * 0.90
                                                  # specific impulse (sea-level, optimistic estimate) [
       f = 4.5E3
                                                 # thrust [N]
       mdot_t = f/(g_0 * isp)
                                                 # total mass flowrate [kg/s]
        chamber_p= 380 * 6.895 * 1000
                                                 # chamber pressure (assumed to be 380 psi currently)
       loss_factor = 1.15
                                                 # estimate of line and injector losses
       OF = 1.3
                                                 # mixture ratio
       mdot_o = mdot_t / (1 + (1/0F))
                                                 # oxidizer mass flowrate [kg/s]
       mdot_f = mdot_t / (1 + OF)
                                                 # fuel mass flowrate [kg/s]
                                                 # inlet pressure (currently 1 atm) [Pa]
       p_i = 101.3E3
       delta_p = chamber_p * loss_factor - p_i # required pump discharge pressure [Pa]
        #barleycorn conversions
       g_0 = 32.2
       delta_p = delta_p * 0.000145038
       mdot = mdot_f * 2.20462
       rho = rho * 0.062428
       h_i = p_i * 0.000145038 * 144 / rho
       h_v = p_v * 0.000145038 * 144 / rho
        # derived parameters
                                           # volumetric flowrate [f^3/s]
       q = mdot / rho
       h_p = 144 * delta_p / rho
                                           # required head rise [ft]
       npsh_a = h_i - h_v  # Net Positive Suction Head (available) [ft]
       print("mass flow rate")
       print("%.3f" % mdot, "lbm/s ", "\n")
       print("volumetric flow rate")
       print("%.4f" % q, "ft^3/s", "\n")
       print("required pressure head")
       print("%.3f" % h_p, "ft", "\n")
       print("Net Positive Suction Head Available")
       print("%.3f" % npsh_a, "ft")
mass flow rate
```

1.986 lbm/s

```
volumetric flow rate
0.0403 ft^3/s

required pressure head
1234.672 ft

Net Positive Suction Head Available
39.205 ft
```

A brief vendor search shows that there are no COTS pump solutions that even remotely approach satisfying our requirements with reasonable weights and pricepoints. On possibility is to accept a lower chamber pressure, or to jack up the pressure at the pump inlet by pressurizing the propellant tanks. This has the advantage of making the required pump head more reasonable, and should additionally help supress cavitation within the pump. The disadvantage is that it goes against the original point of using pumps especially to enable thin and lightwight propellant tanks.

1.4 Design Outputs

Given the requirements and the design inputs there are six basic steps needed to size a pump.

- 1. Determine the number of stages.
- 2. Determine the pump rotational speed.
- 3. Determine the pump impeller tip speeds.
- 4. Determine the pump impeller entrance and exit tip diameters
- 5. Determine pump efficiency
- 6. Determine the shaft power required to drive the pump.

1.5 Determine Number of Stages

The number of stages is generally either determined by the next largest integer value greater than the ratio of the pump-pressure rise to the maximum allowable stage-pressure rise, or by $NPSH_{required}$. If a centrifugal pump is used the approximate limits on stage-pressure rise is 47MPa for LOX and ethanol (citation needed). At 47 MPa impeller tips become so thick that they restrict flow passages and develop large k-losses. We determine the number of stages from a simple rule of thumb

$$n \ge \frac{\Delta p_p}{\Delta p_s}$$

where Δp_p is the required pressure rise and we assume Δp_s to be 47MPa.

```
In [2]: # number of stages

delta_p_s = 47E6 * 0.000145038  # estimated allowable pressure rise per stage [Pa]
    n = int(m.ceil(delta_p/delta_p_s))  # number of stages

print("number of stages")
    print(n)

number of stages
1
```

1.6 Determine Pump Rotational Speed

The next step is to estimate the impeller-tip speeds, rotational speed, and finally impeller sizes. Impeller tip speed is given by

$$u_t = \psi \sqrt{\frac{2g_0 H_p}{n}}$$

where ψ is the pump-stage head coefficient which we can assume to have a numerical value of between 0.4 and 1.5 (citation needed). As mentioned previously we want the highest rotational speed to get the lowest pump mass and highest performance, however there are practical constraints on things such as bearings. If there is no boost stage and and if there is a definite NPSH limit the pump rotational speed in rad/s can be determined by

$$N_r = \frac{u_{ss} NPSH^{0.75}}{\sqrt{Q}}$$

Suction-specific speed, u_{ss} , indicates the minimum net positive suction head (NPSH, inlet pressurization above the vapor pressure expressed in meters) at which a pump operating at rotational speed N, and volume flow rate Q, can operate without cavitation effects. u_{ss} values fall between 5000 and 50,000 depending on efficiency of the pump with 7000 to 12,000 being typical. Lower numbers are more conservative. A large suction-specific speed indicates an ability to operate at low inlet pressures. Large values are obtained by using large diameters for the pump-inlet tip and small diameters for the inlet hub such that the inlet axial velocity head is minimized. Additionally thin, gradually curved blades with sharp leading edges produce the minimum static pressure gradients on the blade surfaces. Inducers have both features, and are therefore widely used in pumping applications on rocket engines. The important thing is that the $NPSH_{available}$ must be higher than $NPSH_{required}$ to avoid cavitation. $NPSH_{required}$ is determined on a pump by pump basis. This places the upper limit on impeller specific speed. If additional head is required by the pump the propellant needs to be pre-pressurized before reaching the pump impeller, such as with the aformentioned inducer, or with additional pump stages (e.g. 'booster' stages), or by pressurizing the propellant tank. As a historical note the German V-2 oxygen tank was pressurized to 2.3 atm (autogenuously) largely to suppress pump cavitation.

$$N_s = \frac{N_r \sqrt{Q}}{\left(\frac{H_p}{n}\right)^{0.75}}$$

 N_s is the stage-specific speed where N_r is the pump's rotational speed and n is the number of stages. Stage specific speed, N_s , is a parameter that characterizes geometrically and hydrodynamically similar pumps. Centrifugal pump are generally low-capacity/high-head devices and thus are at the low specific speed side of the spectrum. Each class of pump (radial, francis, mixed, axial) lends itself to a particular range of specific speeds.

Out[3]:

TABLE 10-2. Pump Types

	Impeller type					
	Radial	Francis	Mixed flow	Near axial	Axial	
Basic shape (half section)	Casir					
Specific speed N _s U.S. nomenclature SI consistent units	500-1000 0.2-0.3	1000-2000	2000-3000 0.6-0.8	3000-6000 1.0-2.0	Above 8000 Above 2.5	
Efficiency %	50-80	60-90	70-92	76-88	75-82	

In [4]: # pump rotational speed

```
psi = 1
                                                        # pump stage head coefficient (estimated)
       u_t = psi * m.sqrt(2 * g_0 * h_p)
                                                        # impeller vane tip speed [ft/s]
       u_ss = 10E3
                                                        # suction specific speed
       npsh_r = npsh_a * 0.8
       n_r = (u_ss * npsh_r**0.75)/(21.2 * m.sqrt(q)) # pump rotational speed [RPM]
       n_r_a = n_r * 2 * m.pi / 60
       n_s = (21.2* n_r * m.sqrt(q))/(h_p / n)**0.75
                                                        # pump specific speed
       print("impeller tip speed")
       print("%.2f" % u_t, "ft/s", "\n")
       print("pump rotational speed")
       print("%.2f" % n_r, "RPM", "\n")
       print("pump specific speed")
       print("%.2f" % n_s)
impeller tip speed
281.98 ft/s
pump rotational speed
31133.67 RPM
pump specific speed
636.30
```

It should be noted that the combination of flowrate, pressure rise and fluid density togeather with the allowable range of speeds places the pump in the very low end of the specific speed range, where the predicted maximum attainable efficiency for several types of centrifugal pumps are below those of positive displacement type pumps. It is not likely that an efficiency beter than 50% is attainable; as such several stages may be required for the desired capacity. Positive displacement type pumps may offer improved efficiency at the cost of less steady flow, noise, and much poorer reliability.

Additionally, it's difficult to extrapolate pump efficiencies availabile in literature to such small high-head pumps, as the implicit assumption of geometric and hydrodynamic similarity may well be broken.

1.7 Impeller Diameters

Knowing the rotational speed, we can get the impeller diameters using

$$D_o = \frac{u_t}{N_r}$$

$$D_i = \left(\frac{4Q}{\pi \phi N_r (1 - L^2)}\right)^{1/3}$$

Where D_o is the diameter of the impeller outlet (m), also called the discharge, D_i is the diameter of the impeller inlet (m), L is the ratio of the hub diameter to the tip diameter, and ϕ is the inducer-inlet flow coefficient. Minimizing the factors ϕ and L minimizes the NPSH required by the pump. The inducer-inlet flow coefficient, ϕ , is the tangent of the flow angle approaching the inducers blade tip. It is one of the main design parameters used to maximize suction performance. Generally, lower values are better. Assume 0.1 if using inducer, otherwise use 1.

```
In [5]: # impeller diameters
```

```
l = 0.3
phi = 1
d_o = u_t * 2 / n_r_rad * 12
d_i = (4 * q/(m.pi * phi * n_r_rad * (1 - 1**2)))**(1/3) * 12  # impeller outer diameter [in]

print("impeller discharge diameter")
print("%.3f" % d_o, "in", "\n")
print("impeller inlet diameter")
print("impeller inlet diameter")
print("impeller inlet diameter")
print("%.4f" % d_i, "in")
impeller discharge diameter
2.076 in
```

impeller inlet diameter
0.3104 in

1.8 Shaft Power

The required shaft power can be determined from

$$P_{req} = \frac{g_0 \dot{m} H_p}{\eta_p}$$

where η_p is the pump efficiency and can be determined from the stage-specific speed and tabulated efficiency data.

```
In [8]: # shaft power
```

```
from numpy import interp

#from a table of efficiencies for radial impellers found in Munson et. al., 2009
def effic(n_s):
    eta_t = [0.55, 0.80, 0.83, 0.85, 0.84, 0.82]
    n_s_t = [500, 1000, 1500, 2000, 2500, 3000]
    eta = interp(n_s, n_s_t, eta_t)
```

```
return eta
```

```
eff = 0.4 # a more realistic estimated efficiency
        \#eta = input('given an pump specific speed of \{\} and flow rate of \{\} m^3/s what is the pump eff
        def power(mdot, h_p, n_s): # required shaft power [W]
           p_req = mdot * h_p/(effic(n_s) * 0.738)
           return p_req
       print("pump efficiency")
        print("%.2f" % float(100*effic(n_s)), "%", "\n")
       print("required shaft power (optimistic)")
       print("%.2f" % power(mdot, h_p, n_s), "W", "\n")
       print("required shaft power (realistic)")
       print("%.2f" % power(mdot,h_p, eff), "W")
pump efficiency
61.81 %
required shaft power (optimistic)
5374.95 W
required shaft power (realistic)
6040.94 W
```

It should be noted that 62% is very optimistic for any hombrew pump volute/inducer/impeller combination. We should count ourselves lucky if we hit 40% efficient.