

### CSE 4305 Computer Organization and Architecture

## Internal Memory

Course Teacher: Md. Hamjajul Ashmafee

Lecturer, CSE, IUT

Email: ashmafee@iut-dhaka.edu




# Internal Memory





#### Semiconductor Main Memory

• **Previously** doughnut shaped ferromagnetic loops (cores) were used in **main memory** – but now, **semiconductor chips** are used in the place of magnetic core memory. Types:






Memory Type	Category	Erasure	Write Mechanism	Volatility	
Random-access memory (RAM)	Read-write memory	Electrically, byte-level	Electrically	Volatile	
Read-only memory (ROM)	Read-only	Not possible	Masks		
Programmable ROM (PROM)	memory	Not possible			
Erasable PROM (EPROM)		UV light, chip-level		Nonvolatile	
Electrically Erasable PROM (EEPROM)	Read-mostly memory	Electrically, byte-level	Electrically		
Flash memory		Electrically, block-level			



### **Organization**

- Basic element of semiconductor memory memory cell
- **Property** of memory cell:
  - Has two stable states 1 and 0
  - Capable of being written to set state
  - Capable of being **read** to sense state
- Has 3 functional terminals





#### RAM

- Random Access Memory
- Most common type of semiconductor memory
- Misuse of this term of only confining this device as accessing random even though others like ROM, Flash memory are also capable of accessing random
- Application <u>Temporary storage</u>
- Volatile
- Possible both read and write
- Newer RAM are non volatile
- Two forms DRAM and SRAM



#### **DRAM**


- **D**ynamic RAM
- Store data as charge or capacitance
- As charge or capacitance has the tendency of decaying naturally, a refreshing circuitry is required though power is supplied – <u>Dynamic</u>
- Write operation voltage applied
- Read operation sense the charge through an amplifier



#### **SRAM**

- **S**tatic RAM
- Store value using flip flops
- Hold data as long as power is supplied
- 4 transistors are used to store data
- Data is available both in its original and complement form
- No refresh circuit is required

#### SRAM and DRAM: 1 bit cell structure



#### SRAM vs DRAM

- Which one is better?
  - Cost
  - Capacity
  - Power consumption
  - So on



#### **ROM**

- Read Only Memory
- Permanent pattern of data
- Non volatile No power source is required
- Easy to read but impossible to write
- Application:
  - Microprogramming
    - Process of writing microcode for a microprocessor. Microcode is low-level code that defines how a microprocessor should function when it executes machine-language instructions.
  - Library subroutines
  - System programs
  - Function tables



#### ROM...

- Created as any other IC data is actually wired/ fabricated
- Problems:
  - Data insertion cost is huge
  - No room for error if one bit is wrong, whole batch of ROMs (produced in bulk) will be invalid



### Types of ROM

- PROM
- EPROM
- EEPROM
- Flash Memory



#### **PROM**

- Programmable ROM
- Less expensive
- Non volatile
- Written only once electrically





#### **EPROM**

- Read mostly memory writing is possible
- Erasable Programmable ROM
- Written electrically
- Erasure performed by shining an intense UV light through a window into the chip – takes 20 mins to erase
- Alterable multiple times
- Expensive







#### **EEPROM**


- Read mostly memory
- Electrically Erasable Programmable ROM
- Written at anytime without erasing prior content just the desired byte(s)
- Write operation is longer than read operation
- More expensive





### Flash Memory


- Read mostly memory
- Named as speed of reprogramming
- Electrical erasure
- Erased in minutes or seconds
- Erase just block rather than whole content





### Chip Logic

- Cells are arranged in array as logical arrangement
- Read or write is possible in bit or word (of several bytes) level





Lecture 5



### Chip Packaging

- An IC is mounted on a package that contains pin for connection
- Pins support
  - Address of the word
  - Data
  - Power supply
  - Ground
  - Chip enable
  - Program voltage
    - during programming write








### **Module Organization**

• How many memory modules are required and how they are arranged:



Lecture 5



### **Interleaved Memory**

- Main memory is composed of collection of DRAM chips grouped together to form memory bank – independently able to service a memory read and write
- Example:
  - Odd bank
  - Even bank




#### **Error Correction**

- A semiconductor memory is subject to errors:
  - **Hard failure**: Permanent physical defect so that the memory cell are affected to store data Always 0/1/switching harsh environmental abuse, manufacturing defects, destroy
  - **Soft error**: random, non-destructive altering one or more bits without damaging memory caused power supply problems or alpha/ radioactive particles
- A code is generated from the data which is stored in memory and also stored in memory associated with that data when that data is fetched from memory another code generated from data in same way to compare it with previous one. Results may be:
  - No errors are detected.
  - An error is detected and it is possible to correct error correction bits are generated to produce corrected data
  - An error is detected and it is impossible to correct



#### Error Correction...



f = calculation function that produces code from data


M = data word

K = code word




#### Error Correction...

- Error Correcting Code: Code that will help to correct the erroneous data
- Hamming Code is the simplest way of error correcting
- Hamming code is **different from Hamming distance** where the **Hamming distance** between two strings of equal length is the number of positions at which the corresponding symbols are different.





## **Hamming Code**



Lecture 5 . 24



#### Hamming Code...

- At first, we have to determine the length of the code: (M+K)
- Two K-length codes (for old and newly fetched) will be compared bit by bit by performing XOR between them the **result is called syndrome word** (k bits long)
- Each bit of the syndrome is 0 or 1 according to if there is a match or not
- If k=0<sub>10</sub>; there is no error.
- The length (M+K) must satisfy:  $2^{K}-1 \ge M + K$

■ 
$$K = 3: 2^3 - 1 < 8 + 3$$
  
■  $K = 4: 2^4 - 1 > 8 + 4$  Where M = 8



### Single Error Correction Code

#### For 8 bit data

Bit position	12	11	10	9	8	7	6	5	4	3	2	1
Position number	1100	1011	1010	1001	1000	0111	0110	0101	0100	0011	0010	0001
Data bit	D8	D7	D6	D5		D4	D3	D2		D1		
Check bit					C8				C4		C2	C1



### Single Error Correction Code

- If the syndrome contains all 0s, no error has been detected.
- If the syndrome contains one and only one bit set to 1, then an error has occurred in one of the 4 check bits. No correction is needed.
- If the syndrome contains more than one bit set to 1, then the numerical value of the syndrome indicates the position of the data bit in error. This data bit is inverted for correction.




### Single Error Correction Code

- Data Stored: 00111001 (D1 is rightmost position)
- Data Fetched: 00111101



### SEC and Double Error Detecting Code





### **Module Organization**

• Error



### **Module Organization**

• Error