# **FEITIAN**





# Revision History:

Date	Revision	Description
April. 2013	V1.0	Release of the first version

Copyright © Feitian Technologies Co., Ltd. Website: www.FTsafe.com

## Software Developer's Agreement

All Products of Feitian Technologies Co., Ltd. (Feitian) including, but not limited to, evaluation copies, diskettes, CD-ROMs, hardware and documentation, and all future orders, are subject to the terms of this Agreement. If you do not agree with the terms herein, please return the evaluation package to us, postage and insurance prepaid, within seven days of their receipt, and we will reimburse you the cost of the Product, less freight and reasonable handling charges.

- 1. Allowable Use You may merge and link the Software with other programs for the sole purpose of protecting those programs in accordance with the usage described in the Developer's Guide. You may make archival copies of the Software.
- 2. Prohibited Use The Software or hardware or any other part of the Product may not be copied, reengineered, disassembled, decompiled, revised, enhanced or otherwise modified, except as specifically allowed in item 1. You may not reverse engineer the Software or any part of the product or attempt to discover the Software's source code. You may not use the magnetic or optical media included with the Product for the purposes of transferring or storing data that was not either an original part of the Product, or a Feitian provided enhancement or upgrade to the Product.
- 3. Warranty Feitian warrants that the hardware and Software storage media are substantially free from significant defects of workmanship or materials for a time period of twelve (12) months from the date of delivery of the Product to you.
- 4. Breach of Warranty In the event of breach of this warranty, Feitian's sole obligation is to replace or repair, at the discretion of Feitian, any Product free of charge. Any replaced Product becomes the property of Feitian.

Warranty claims must be made in writing to Feitian during the warranty period and within fourteen (14) days after the observation of the defect. All warranty claims must be accompanied by evidence of the defect that is deemed satisfactory by Feitian. Any Products that you return to Feitian, or a Feitian authorized distributor, must be sent with freight and insurance prepaid.

EXCEPT AS STATED ABOVE, THERE IS NO OTHER WARRANTY OR REPRESENTATION OF THE PRODUCT, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

5. Limitation of Feitian's Liability – Feitian's entire liability to you or any other party for any cause whatsoever, whether in contract or in tort, including negligence, shall not exceed the price you paid for the unit of the Product that caused the damages or are the subject of, or indirectly related to the cause of action. In no event shall Feitian be liable for any damages caused by your failure to meet your obligations, nor for any loss of data, profit or savings, or any other consequential and incidental damages, even if Feitian has been advised of the possibility of damages, or for any claim by you based on any third-party claim.

6. Termination – This Agreement shall terminate if you fail to comply with the terms herein. Items 2, 3, 4 and 5 shall survive any termination of this Agreement.

# **Contents**

Chapter 1.	Overview	1
•		
Chapter 2.	Definitions	2
2.1 Error	codes	2
Chantau 2	API Reference	7
Chapter 3.	API Reference	3
3.1 ft_rea	ader	3
3.2 isPow	verOn	3
	erOff	
3.4 getAt	r	4
3.5 getCa	ardStatus	5
	Apdu	

# **Chapter 1. Overview**

This chapter describes how to develop bR301 reader applications, including the development interfaces supported by the product (bR301) and how to develop applications based on these interfaces.

FEITIAN bR301 is specially engineered to accommodate a range of smart card applications. Developers use it as a platform to generate and deploy related products and services. Moreover, FEITIAN bR301 is a terminal unit which is seamlessly integrated to all major systems of operation. Additional features such as the built-in inclusive support for different smart card interfaces has facilitated the wide scale and cross industry adoption of bR301.

bR301 suits customers where security concerns are the most salient and satisfies the demand for a flexible solution for ID authentication, e-commerce, e-payment, information security and access control.

bR301 and the rest of FEITIAN's line of smart card readers offer each customer a complete solution for all manner of utilizations.

# **Chapter 2. Definitions**

## 2.1 Error codes

The following is a list of commonly used errors. Since different cards produce different errors they must map over to these error messages.

```
RETURN_SUCCESS = 0;

ERROR_RECEIVE_LRC = 240;

PROTO_NOT_SUPPORT = 1;

IFD_COMMUNICATION_ERROR = 612;

IFD_NOT_SUPPORTED = 614;

TRANS_RETURN_ERROR = 61441;

BUFFER_NOT_ENOUGH = 61442;
```

# **Chapter 3. API Reference**

# 3.1 ft\_reader

#### Synopsis:

public ft\_reader (java.io.InputStream Intmp,java.io.OutputStream Outmp)

#### Parameters:

N/A

## **Description:**

Constructor Detail.

#### **Example:**

Please follow sample code.

#### **Returns:**

```
RETURN_SUCCESS = 0;

PROTO_NOT_SUPPORT = 1;

IFD_COMMUNICATION_ERROR = 612;

TRANS_RETURN_ERROR = 61441;
```

## 3.2 isPowerOn

### Synopsis:

public boolean isPowerOn()

#### Parameters:

N/A

## **Description:**

This function use to provide power to card and get card ATR, if no card insert to reader, will return failed.

#### **Example:**

Please follow sample code.

#### **Returns:**

```
RETURN_SUCCESS = 0;

PROTO_NOT_SUPPORT = 1;

IFD_COMMUNICATION_ERROR = 612;

TRANS_RETURN_ERROR = 61441;
```

## 3.3 PowerOff

#### Synopsis:

public int PowerOff()

#### Parameters:

N/A

### **Description:**

This function use to power off card.

#### **Example:**

Please follow sample code.

#### **Returns:**

```
RETURN_SUCCESS = 0;

PROTO_NOT_SUPPORT = 1;

IFD_COMMUNICATION_ERROR = 612;

TRANS_RETURN_ERROR = 61441;
```

# 3.4 getAtr

#### Synopsis:

public byte[] getAtr()

### **Parameters:**

N/A

### **Description:**

This function returns card ATR number.

## **Example:**

Please follow sample code.

#### **Returns:**

```
RETURN_SUCCESS = 0;

PROTO_NOT_SUPPORT = 1;

IFD_COMMUNICATION_ERROR = 612;

TRANS_RETURN_ERROR = 61441;
```

# 3.5 getCardStatus

#### Synopsis:

public int getCardStatus()

#### Parameters:

N/A

#### **Description:**

Get card status:

```
CARD_PRESENT = 0;
CARD_UNKNOW = 1;
CARD_ABSENT = 2;
```

#### **Example:**

Please follow sample code.

#### **Returns:**

```
CARD_PRESENT = 0;
CARD_UNKNOW = 1;
CARD_ABSENT = 2;
```

# 3.6 transApdu

### Synopsis:

#### Parameters:

tx\_length IN input data's length

tx\_buffer IN input data

rx\_length OUT return data's length rx\_buffer OUT return data from card

#### **Description:**

This function sends an APDU to the smart card contained in the reader. The card responds from the APDU and stores this response in rx\_buffer and it's length in rx\_length.

#### **Example:**

Please follow sample code.

### **Returns:**

RETURN\_SUCCESS = 0; ERROR\_RECEIVE\_LRC = 240; PROTO\_NOT\_SUPPORT = 1; IFD\_COMMUNICATION\_ERROR = 612; IFD\_NOT\_SUPPORTED = 614; TRANS\_RETURN\_ERROR = 61441; BUFFER\_NOT\_ENOUGH = 61442;