Water Washable Resin

Print & Post-Processing Instructions

Print

- On most 405nm LCD printers (Elegoo, Anycubic, Phrozen, etc.), good starting settings for printing this resin at a 50um layer height is a 20s burn layer exposure and 3s layer exposure.

Wash

- Carefully remove parts from the build plate and, if necessary, remove supports. Place parts in a sonicator or a vortex mixer filled with plain water. Room temp water will work fine, but water heated up to 40C will work even faster.
- Run the machine for 2 minutes.
- Remove the part and spray with compressed air to loosen up any resin trapped in cracks, crevices, and channels.
- Place parts back into the water and run for another 2 minutes.
- Repeat this process until the parts come out clean. Set on a clean paper towel to allow the water to evaporate. Gently dab with a paper towel or spray with air to speed up the drying process.

Cure

- Place parts in a 365/385/405nm cure box and run for 15 minutes.

Tips

- If no vortexer or sonicator is available, hold the part and move it back and forth in a basin of water and alternate with air spraying to clean the parts.