Back -WA-130-S

Step 1

Mart a centerline on the wood piece to allow for proper hole position.

Drill eighteen (18) 1/4" holes where shown.

