AquaPearl 500 Pro Product Manual

Version 3.2, March 2026

1. Box Contents

Your AquaPearl 500 Pro is shipped with the following items. Please check the box before you discard the packaging.

- 1 x AquaPearl 500 Pro purifier unit with pre-installed filter set (FLT-S5, FLT-C5, FLT-M5)
- 1 x wall-mount bracket with 4 screws and 4 wall plugs
- 1 x inlet tubing, 6 mm, 2 m long
- 1 x outlet tap and 1/4-inch tap adaptor
- 1 x power cable, 1.5 m, 3-pin
- 2 x spare tubing clips
- 1 x quick start card and 1 x warranty card

No tools, descaling kit or spare filters are included in the box. The descaling kit (DSC-1) is sold separately.

2. Technical Specifications

Specification	Value
Filtered flow rate	3.0 L/min
Tank capacity	8 L
Dimensions (W x D x H)	38 x 18 x 42 cm
Weight	7.2 kg
Power	60 W, 220-240 V AC, 50 Hz
Inlet water pressure	15 to 80 psi (1.0 to 5.5 bar)
Maximum inlet TDS	1,500 ppm
Operating temperature	5 to 38 degrees C
Purification stages	4: sediment, carbon block, RO membrane, UV-LED

The UV-LED module is rated for 20,000 hours and does not need routine replacement.

3. Control Panel and Indicator Lights

The control panel has a single RESET button, a pairing button and a ring of indicator lights.

- Steady blue: ready to dispense.
- Pulsing blue: the tank is filling.
- Green: UV-LED sterilisation is active.
- Amber: attention needed, such as low inlet pressure.
- Red steady or flashing: a filter has reached its limit or a fault has occurred.

4. Operating Instructions

Open the inlet valve fully, plug in the unit and wait for the ring to turn steady blue. Press the tap lever to dispense water. The unit refills the tank automatically when the level drops.

Do not run the unit with the inlet valve closed. Do not dispense hot water: the AquaPearl 500 Pro supplies room-temperature purified water only.

5. Filter Maintenance

Replace each filter on schedule. The unit counts filter life in the background and alerts you when a filter reaches its limit.

Filter	Part number	Replace every
Sediment filter (stage 1)	FLT-S5	4 months
Carbon block filter (stage 2)	FLT-C5	8 months
RO membrane (stage 3)	FLT-M5	18 months

After replacing a filter, press and hold the RESET button for 5 seconds to reset its counter. After any filter replacement you must flush the system; the flushing procedure is described in the Installation Guide.

6. Cleaning and Descaling

Wipe the exterior with a soft damp cloth once a month. Do not use bleach, solvents or abrasive cleaners.

Descale the unit every 3 months. Sanitise the water tank every 6 months. To descale:

- Switch off the unit, unplug it and close the inlet valve.
- Drain the tank by pressing the tap lever until empty.
- Mix one descaling kit (DSC-1) with 1 litre of warm water and pour it into the tank.
- Leave the solution for 20 minutes.
- Reopen the inlet valve, plug in the unit and run three full tanks (24 litres) of water to waste.
- Resume normal use.

7. Audible Alert Codes

The unit signals faults with a number of beeps and a light pattern. The codes below apply to firmware 2.4 and later. Units on firmware 2.3 or earlier use an older meaning for E-05; see the Product Changelog.

Code	Beeps and light	Meaning
E-01	1 beep, amber	Inlet pressure low or inlet valve closed
E-02	2 beeps, amber	Tank-full sensor fault
E-03	3 short beeps, red flashing	Sediment pre-filter saturated
E-04	4 beeps, red flashing	Carbon filter expired
E-05	5 beeps, steady red	RO membrane saturated (firmware 2.4 and later)
E-06	6 beeps, red and base light flashing	Leak detected
E-07	7 beeps, amber flashing	Pump overheating
E-08	8 beeps, all lights flashing	Control board communication fault

For E-03, replace the sediment filter (FLT-S5) and then hold RESET for 5 seconds. For E-06, close the inlet valve, unplug the unit and contact support. For E-08, contact support and do not open the unit.

8. Safety Warnings

- Use only a grounded 3-pin socket and keep the plug dry.

- Never open the housing. Opening the housing by anyone other than a Pearlz-authorised technician is an unauthorised repair.

- Install the unit on the cold water line only.

- Keep the unit at least 30 cm away from heat sources.

- Switch off and unplug the unit before any maintenance.

- This product is for private household use only.