## 06

```
; INITIALIZE
mov al,00h
mov si,2000h
mov cl,0Ah
; LOAD TEN NUMBERS
load:
mov [si],al
inc si
inc al
dec cl
jnz load
; INITIALIZE SUM
mov si,2000h
mov ax,0000h
mov cx,0Ah
; CALCULATE SUM
REPEAT:
mov bl,[si]
mov bh,00h
add ax,bx
inc si
dec cx
jnz REPEAT
; STORE RESULT
mov [200Ah],ax
HLT
```

## 08

```
mov [2000h], 05h
mov [2001h], 0Ah
mov [2002h], 22h
mov [2003h], 07h
mov [2004h], 13h
mov [2005h], 40h
mov [2006h], 01h
mov [2007h], 08h
mov [2008h], 33h
mov [2009h], 0Ch
 ; SEARCH
mov si,2000h
mov byte ptr [200Ah],13h
mov cx,0Ah
mov bl,00h
mov byte ptr [200Bh],0FFh
search:
mov al,[si]
cmp al,[200Ah]
je found
inc si
inc bl
loop search
hlt
found:
mov [200Bh],bl
hlt
```

## 09

```
ORG 100H
; ODD NUMBER USING BITWISE OPERATION
mov al,07h
and al,01h
mov [2000h],al
; EVEN NUMBER USING BITWISE OPERATION
mov al,08h
and al,01h
mov [2001h],al
HLT
```