

1. Setup WiFi operation mode:




2. Setup WAN IP




3. Private LAN IP details (with DHCP enabled):




4. DHCP settings:




5. Wireless settings:



6. Change Remote Management Port (Default port is 8080):



7. Change Router login user and password:



Email: saiful.bhuiyan@amberit.com.bd