AmberIT WiFi Router Checklist DOCUMENT

1. (i) WAN IP details:	Provided by AmberIT: WAN/Internet IP address, Subnet Mask, Default gateway address
(ii)DNS (Primary and secondary):	**Dhaka and Others Zone:** DNS1: 118.179.223.10 DNS2: 202.4.96.6 **Khulna:** DNS: 118.179.44.250 **Sylhet:** DNS: 118.179.42.218
2. **Private** LAN IP details (with **DHCP** enabled):	192.168.1.1 or 192.168.0.1 (Keep the default)
3. (i) DHCP Settings: Is DHCP enabled on the LAN:	Yes / No (For WiFi: Yes / For AP: No)
(ii) Input DNS IP (Primary and secondary) on LAN DHCP settings:	Dhaka and Others Zone: DNS1: 118.179.223.10 DNS2: 202.4.96.6 Khulna: DNS: 118.179.44.250 Sylhet: DNS: 118.179.42.218
4. Wireless settings:	1. SSID/WiFi Name: [As per client request] 2. Channel: 1 or 6 or 11 3. Channel Width: Auto 4. Channel/Network mode: 11b/g/n or default #Enable SSID broadcast
5. Wireless security:	1. Security mode: WPA/WPA2 Personal 2. Encryption: AES 3. Password: [As per client request]
6. Change Remote Management Port (Default port is 80):	1. Enable remote management 2. Change Port to 8124 3. Remote Management IP Address: 255.255.255.255 or select any
7. Change Router login user and password:	User: admin, password: aitcid[CID_Number]

8. Time settings:	1. Time zone: GMT +6 (Alma-Ata/Astana/Dhaka)
9. Security Policy:	1. Enable Firewall (TPLINK)