
# **Instruction Manual**

# **PIRATE - 4WD Mobile Platform**

# 安装说明书




产品特性1-2 Features
产品安装说明3 Notice for Assembly
电机安装4 Moters Assembly
电池盒安装5 Battery Holder Assembly
开关及插座安装6 Power Jack and Switch Assembly
前后挡板安装7 Front and Rear Plate Assembly
底板安装8 Base Plate Assembly
传感器固定版安装9 Sensor Plate Assembly
上盖板安装10 Top Plate Assembly
红外传感器支架安装11 IR Sensor Bracket Assembly
车身上板安装12 Upper Deck Assembly
车轮安装13 Wheels Assembly
零部件清单 14−15 Parts List



# 产品特性 Features

#### 整机尺寸:



## 简介:

PIRATE-4WD Mobile Platform四轮驱动机器人是DFRobot研制的机器人实验平台,该平台不但可以用51控制、STC控制器、AVR控制器控制外,更适合使用世界上广泛推广的Arduino控制器,Arduino开放平台拥有全球众多使用者,有丰富的使用例子程序。机身采用高强度铝合金材料,高速电机加优质橡胶轮运动灵活快速,适合室内的平坦路面行进。使用Arduino控制器编程简单,控制起来非常有趣。适合机器人比赛,及其相关研究项目。本小车安装孔兼容多种传感器。

整机重量: 710g 车轮直径: 65mm 最大行驶速度: 61cm/s

#### 电机参数:

● 电机供电电压: 3-6V

● 减速比: 1:120

● 无负载转速 (3V): 90RPM

● 无负载转速 (6V): 160RPM

● 无负载运行电流 (3V): 140mA

● 无负载运行电流 (6V): 170mA

● 堵转电流 (3V): 260mA


● 堵转电流 (6V): 470mA

● 力矩 (3V): 1.2Kgcm

● 力矩 (6V): 1.92Kgcm

● 重量: 45g

#### **Dimensions:**



#### Introduction:

The Pirate four-wheel-drive robot is a DFRobot original design and widely useds self-developed control panel for the Arduino platform. The platform can becontrolled by a wide variety of microcontrollers including the widely popular Arduino. The Arduino platform has a large user base which provides a vastamount of resources and sample programs on the internet. The four different drives, powered by high-quality high-speed motors and flexible rubber wheels are mounted on a high-strength aluminum alloy body. This robotic platform is uitable for indoor use or flat road surfaces.

Complete Machine Weight: 710g

Wheel Diameter: 65mm Highest Speed: 61cm/s

#### Motor Feature:

• Gear Ratio: 1:120

No-load speed (3V): 90RPM

• No-load speed (6V): 160RPM

• No-load current (3V): 140mA

No-load current (6V): 170mA

• Stall current (3V): 260mA

Stall current (6V): 470mA

• Torque (3V): 1.2Kgcm

• Torque (6V): 1.92Kgcm

• Weight: 45g





#### 以下设备不包括在ROB0003的部件清单内,用户需自行配备:

- 1.5节AA电池。
- 2. 控制器以及电机驱动器。

### 您还需要准备以下工具,并参考零部件清单进行ROB0003的安装:

- 1. 十字螺丝刀(适用于M2.5, M3, M4的螺丝)。
- 2. 尖嘴钳。
- \*本说明书不含电子部分安装,如需了解可输入网址或扫描二维码进入查看。 中文教程:http://wiki.dfrobot.com.cn/index.php/(SKU:ROB0003)海盗船四轮机器人



### The following parts below are not included in the Parts List, they are self-provided:


- 1. AA battery (5 pieces).
- 2. Micro-controller and Motor driver.


# When starting assembly, prepare tools below and pick out the parts referring to the parts list:


- 1. Phillips screwdriver (for screws M2.5, M3, M4).
- 2. Needle noses pliers.
- \* Electronic installation is not included in this instruction; If you need, please refer to tutorials on official website of DFRobot.

https://www.dfrobot.com/wiki/index.php?title=4WD\_Mobile\_Platform\_SKU:ROB0003








































A1 M0308x8 M3x6mm平圆头十字带垫螺丝 Philips Flange Screw (M3x6) A0 M0304x1 前盖板 Front Plate



























红外传感器支架 IR Sensor Mounting Bracket






**A1** 



M0308x9 M3x6mm平圆头十字带垫螺丝 Philips Flange Screw (M3x6mm)



A0


M0306x1 车身上板 Upper Deck **A1** M0308x4

M3x6mm平圆头十字带垫螺丝 Philips Flange Screw (M3x6mm)

 $\bigcirc$ M0320x4 M3x50mm六角铜柱 Copper Standoff (M3x50mm)







PIRATE - 4WD Mobile Platform



编号 Product NO.	盒编号 BOX	袋编号 Packet	名称 Name	数量 Amount	备注 Remark
M0301		A0	底板 Base Plate	1	
M0302		A0	侧板 Side Plate	2	
M0303		A0	后盖板 Rear Plate	1	
M0304		A0	前盖板 Front Plate	1	
M0305		A0	上盖板 Top Plate	1	
M0306		A0	车身上板 Upper Deck	1	
M0307		A1	M3X4mm沉头十字螺丝 Philips Contersunk Screw (M3X4mm)	2	
M0308		A1	M3x6mm平圆头十字带垫螺丝 Philips Flange Screw (M3x6mm)	40	
M0309		A1	M2.5X25mm半圆头十字螺丝 Philips Truss Screw(M2.5X25mm)	8	
M0310		A1	M2.5螺母 M2.5 Nut	8	
M0311		A1	红外传感器支架 IR Sensor Mounting Bracket	3	
M0312		A1	M6专用垫片 M6 Special Washer	1	
M0322		A1	M3X10mm六角铜柱 Copper Standoff (M3x10mm)	4	



14

编号 Product NO.	盒编号 BOX	袋编号 Packet	名称 Name	数量 Amount	备注 Remark
M0313		A1	M6螺母 M6 Nut	2	
M0314		A1	M2.5垫圈 M2.5 Washer	8	
M0315		A1	电源开关 Power Switch	1	
M0316		A1	电源插口 Power Jack	1	
M0317		A1	M2.5弹簧垫圈 M2.5 Spring Washer	8	
M0318		A1	M8螺母 M8 Nut	1	
M0319		A2	传感器固定板 Sensor Plate	1	
M0320		A1	M3x50mm六角铜柱 Copper Standoff (M3x50mm)	4	
M0321		A1	M3螺母 M3 Nut	20	
P0301		А3	电机 Motor	4	
P0302		A0	轮子 Wheel	4	
P0303		A4	电池盒 Battery Holder	1	
P0304		A4	红黑电机线 Motor Wire	1	

## 主控器:

Romeo BLE 多合一控制器 SKU: DFR0305
Bluno Mega 2560控制器 SKU: DFR0323
WiDo WiFi 物联网主控器 SKU: DFR0321

### 巡线机器人:

● Mini寻线传感器 SKU: SEN0017● 智能灰度传感器 SKU: SEN0147

# 避障机器人:

● 3-80cm红外数字壁障传感器 SKU: SEN0019

红外扫描套件 SKU: KIT0019超声波扫描套件 SKU: KIT0020

# 环境传感器:

● 高精度DHT22温湿度传感器 SKU: SEN0137

● ML8511 UV紫外线传感器 SKU: SEN0175

● PM2.5 激光粉尘传感器 SKU: SEN0177

● CO2 二氧化碳传感器模块 SKU: SEN0159

● 6轴电子罗盘LSM303DLH SKU: SEN0079

# 通信模块:

• GPS/GPRS/GSM 模块 SKU: TEL0051

● SIM800H GPRS/GSM扩展板 集成DTMF/TTS SKU: TEL0089

# 电池:

● 7.4V 2200MA 锂电池 SKU: FIT0137





# 附件 Accessories

#### **Controller:**

- Romeo BLE (Arduino Compatible Atmega 328) SKU: DFR0305
- Bluno Mega 2560 Bluetooth 4.0 SKU: DFR0321
- WiDo Open Source IoT Node (Arduino Compatible) SKU: DFR0321

# **Line Tracking Robot:**

- Line Tracking Sensor for Arduino SKU: SEN0017
- Smart Grayscale Sensor SKU: SEN0147

# **Adjustable Infrared Robot:**

- Adjustable Infrared Sensor Switch SKU: SEN0019
- IR Scanner Kit SKU: KIT0019
- Ultrasonic Scanner kit SKU: KIT0020

#### **Environment Sensor:**

- DHT22 Temperature and Humidity Sensor SKU: SEN0137
- UV Sensor ML8511 SKU: SEN0175
- PM2.5 Sensor Module Laser Sensing SKU: SEN0177
- CO2 Sensor (Arduino compatible) SKU: SEN0159
- LSM303 Breakout Board Tilt Compensated Compass SKU: SEN0079

#### **Communication Module:**

- GPS/GPRS/GSM Shield SKU: TEL0051
- SIM800H GPRS Shield SKU: TEL0089

# **Battery:**

• 7.4V Lipo 2200mAh Battery SKU: FIT0137



**PIRATE - 4WD Mobile Platform** 



电话 (Tel): 86-021-61620183

服务支持 (Service): techsupport@dfrobot.com

网站: www.DFRobot.com.cn Website: www.DFRobot.com

○ 本说明书最终解释权归DFRobot所有

DFRobot has the final authority of interpretation on this manual