



GLENCREAG

USER MANUAL

WK84 Wooden Wired Mechanical Keyboard

WIN:

 + 	Windows
 + 	Brightness-
 + 	Volume+
 + 	Brightness+
 + 	Insert
 + 	Back to Desktop
 + 	Backlight Mode
 + 	Mission Control
 + 	Backlight Color
 + 	E-Mail
 + 	Backlight On/Off
 + 	Calculator
 + 	Backlight Brightness+
 + 	Last Song
 + 	Backlight Brightness-
 + 	Play/Pause
 + 	Backlight Speed-
 + 	Next Song
 + 	Backlight Speed+
 + 	Mute
 + 	Win Lock
 + 	Volume-
 + 	Long Press to Restore Factory Mode


MAC:

	+		Mac	
	Brightness-		+	Insert
	Brightness+		+	Backlight Mode
	Back to Desktop		+	Backlight Color
	Mission Control		+	Backlight On/Off
	Last Song		+	Backlight Brightness+
	Play/Pause		+	Backlight Brightness-
	Next Song		+	Backlight Speed-
	Mute		+	Backlight Speed+
	Volume-		+	Long Press to Restore Factory Mode
	Volume+			

DFU MODE

There are 3 methods to enter dfu mode (development Firmware upgrade) on the keyboard:


Method 1: Press and hold the switch located under the space bar, and then connect the keyboard to the computer.



Method 2: Connect the keyboard to the computer first, and then simultaneously short press Fn + Left Alt + Tab.



Method 3: Press and hold the ESC key first, and then plug the keyboard into the computer.





<https://glencreag.com>

After-sales Service

All GLENCREAG products are covered by a 2-year warranty.

The keyboard can support VIA drivers: <https://usevia.app/>

Please visit the official website at www.glencreag.com to download the firmware and JSON files and check the detailed steps.

If you encounter quality problems or use problems with your

GLENCREAG products, please contact us via

support@glencreag.com

We will reply within 48 hours.