D

 \mathbf{C}

B

A



Enclustra User Schematics

Mars PM3 Revision 5.2

Disclaimer

User schematics do not include proprietary Enclustra design elements, such as power supply circuits. These circuits use optimized designs which are extremely compact and remain proprietary to Enclustra. The user manual provides all necessary information to use the module and its interfaces.

User schematics are provided after purchase of Enclustra hardware, and may also be provided in certain cases before purchase, to assist in product evaluation.

No part of the schematics may be copied or modified without written permission from Enclustra.

Full schematics, including a full bill-of-materials, may be available through the purchase of a hardware licence for the product in question. Please contact Enclustra Sales for more information.

Note: DNE = Do Not Equip (parts not equipped by default)

© Enclustra GmbH

D































