

Attribute: Assign Attribute to Element

Property

Functions

afx_msg long **OSPropertyUI::AssignMemberAttribute** (LPCTSTR strAttributeName, LPCTSTR strValue, const VARIANT FAR &varMemberList)
Assign member(s) to an attribute.

afx_msg long **OSPropertyUI::AssignElementAttribute** (LPCTSTR strAttributeName, LPCTSTR strValue, const VARIANT FAR &varElementList)
Assign element(s) to an attribute.

Detailed Description

These functions are related to assign attribute to elements.

Function Documentation

◆ AssignElementAttribute()

```
long OSPropertyUI::AssignElementAttribute ( LPCTSTR strAttributeName,
                                         LPCTSTR strValue,
                                         const VARIANT FAR & varElementList )
```

Assign element(s) to an attribute.

Parameters

[in] **strAttributeName** Name of the attribute.
 [in] **strValue** A string value
 [in] **varElementList** Element(s) number ID VARIANT array.

Return values

0 OK.
-1 General error.

C++ Syntax

```
// Assign element(s) to attribute named "EleAttri1".
long RetVal = OSPropertyUI::AssignElementAttribute((LPCTSTR)"EleAttri1", (LPCTSTR)"A
string value", varElementList);
```

VBA Syntax

```
' Assign element(s) to attribute named "EleAttri1".
Dim RetVal As long = OSPropertyUI.AssignElementAttribute("EleAttri1", "A string value",
varElementList);
```

See also

[OSPropertyUI::CreateElementAttribute](#)
[OSPropertyUI::DeleteElementAttribute](#)

◆ [AssignMemberAttribute\(\)](#)

```
long OSPropertyUI::AssignMemberAttribute ( LPCTSTR strAttributeName,
                                         LPCTSTR strValue,
                                         const VARIANT FAR & varMemberList )
```

Assign member(s) to an attribute.

Parameters

- [in] **strAttributeName** Name of the attribute.
- [in] **strValue** A string value
- [in] **varMemberList** Member(s) number ID VARIANT array.

Return values

- 0** OK.
- 1** General error.

C++ Syntax

```
// Assign member(s) to attribute named "MemAttri1".
long RetVal = OSPropertyUI::AssignMemberAttribute((LPCTSTR)"MemAttri1", (LPCTSTR)"A
string value", varMemberList);
```

VBA Syntax

```
' Assign member(s) to attribute named "MemAttri1".
Dim RetVal As long = OSPropertyUI.AssignMemberAttribute("MemAttri1", "A string value",
varMemberList);
```

See also

- [OSPropertyUI::CreateMemberAttribute](#)
- [OSPropertyUI::DeleteMemberAttribute](#)