Rockchip USB Initialization Log Analysis

文件标识: RK-KF-YF-099

发布版本: V1.1.1

日期: 2020-02-19

文件密级: □绝密 □秘密 □内部资料 ■公开

免责声明

本文档按"现状"提供,福州瑞芯微电子股份有限公司("本公司",下同)不对本文档的任何陈述、信息和 内容的准确性、可靠性、完整性、适销性、特定目的性和非侵权性提供任何明示或暗示的声明或保证。 本文档仅作为使用指导的参考。

由于产品版本升级或其他原因,本文档将可能在未经任何通知的情况下,不定期进行更新或修改。

商标声明

"Rockchip"、"瑞芯微"、"瑞芯"均为本公司的注册商标,归本公司所有。

本文档可能提及的其他所有注册商标或商标,由其各自拥有者所有。

版权所有© 2019福州瑞芯微电子股份有限公司

超越合理使用范畴,非经本公司书面许可,任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部,并不得以任何形式传播。

福州瑞芯微电子股份有限公司

Fuzhou Rockchip Electronics Co., Ltd.

地址: 福建省福州市铜盘路软件园A区18号

网址: <u>www.rock-chips.com</u>

客户服务电话: +86-4007-700-590

客户服务传真: +86-591-83951833

客户服务邮箱: <u>fae@rock-chips.com</u>

前言

概述

本文档主要提供 Rockchip SDK 平台 Kernel 3.10 和 Kernel 4.4 USB 子系统初始化时相关的日志分析。

读者对象

本文档(本指南)主要适用于以下工程师:

技术支持工程师 软件开发工程师 硬件开发工程师

修订记录

日期	版本	作者	修改说明
2017-12-12	V1.0	王明成	初始版本
2019-01-09	V1.1	吴良峰	使用 markdownlint 修订格式
2020-02-19	V1.1.1	吴良峰	增加免责声明,商标声明以及版权声明

目录

Rockchip USB Initialization Log Analysis

- 1. Linux USB 子系统简介
- 2. Rockchip SoC USB 控制器列表
- 3. Kernel 3.10
 - 3.1 适用芯片
 - 3.2 主机侧日志
 - 3.2.1 USB CORE
 - 3.2.2 设备类驱动
 - 3.2.3 Host 控制器驱动
 - 3.2.3.1 EHCI
 - 3.2.3.2 OHCI
 - 3.2.3.3 DWC2 Host
 - 3.2.3.4 DWC3 Host
- 4. 设备侧日志
 - 4.1 DWC2 Peripheral
 - 4.2 DWC2 Peripheral 枚举日志
- 5. Kernel 4.4
 - 5.1 适用芯片
 - 5.2 主机侧日志
 - 5.2.1 USB CORE 及设备类驱动
 - 5.2.2 Host 控制器驱动
 - 5.2.2.1 EHCI
 - 5.2.2.2 OHCI
 - 5.2.2.3 DWC2 Host
 - 5.2.2.4 DWC3 Host
- 6. 设备侧日志
 - 6.1 DWC2/DWC3 Peripheral
 - 6.2 DWC2 Peripheral 枚举日志
 - 6.3 DWC3 Peripheral 枚举日志

1. Linux USB 子系统简介

在 Linux 系统中,提供了主机侧和设备侧视角的 USB 驱动框架及通用驱动程序。

- 主机侧分为 USB Core、HOST 控制器驱动,HUB 驱动和各设备类驱动。
- 设备侧分为 Gadget 框架、Devices 控制器驱动和各设备类 Function 驱动。

2. Rockchip SoC USB 控制器列表

芯片\控制器	EHCI&OHCI	DWC2	DWC3
RV1108	Υ	Υ	N
RK312X	Υ	Υ	N
RK3288	Υ	Υ	N
RK322X	Υ	Υ	N
RK322XH	Υ	Υ	Υ
RK3328	Υ	Υ	Υ
RK3366	Υ	Υ	Υ
RK3368	Υ	Υ	N
RK3399	Υ	N	Υ

3. Kernel 3.10

3.1 适用芯片

本章节介绍 Linux Kernel 3.10 初始化日志,主要适用于 RV1108、RK312X、RK3288、RK322X、RK322XH、RK3328、RK3368 等有运行 Kernel 3.10 SDK 的平台。

3.2 主机侧日志

3.2.1 USB CORE

```
01 [ 0.959817] usbcore: registered new interface driver usbfs
02 [ 0.959890] usbcore: registered new interface driver hub
03 [ 0.960070] usbcore: registered new device driver usb
...
```

以上是 Linux Kernel 3.10 启动阶段 USB 模块最早输出的 3 句 log。01 行表示注册 USB 文件系统,系统正常启动后,对应生成/sys/bus/usb/目录;02 行表示成功注册 USB HUB 驱动;03 行表明注册 USB 通用设备驱动,即 usb_generic_driver。通常 USB 设备都是以设备的身份先与 usb_generic_driver 匹配,成功之后,会分裂出接口,当对接口调用 device_add()后,会引起接口和接口驱动的匹配。

3.2.2 设备类驱动

```
1.234947] usbcore: registered new interface driver catc
01 [
02 [
       1.235015] usbcore: registered new interface driver kaweth
03 [
       1.235109] usbcore: registered new interface driver pegasus
       1.235180] usbcore: registered new interface driver rtl8150
04 [
       1.235246] usbcore: registered new interface driver r8152
05 [
06 [
       1.235379] usbcore: registered new interface driver hso
       1.235451] usbcore: registered new interface driver asix
07 [
       1.235515] usbcore: registered new interface driver ax88179_178a
] 80
09 [
       1.235586] usbcore: registered new interface driver cdc_ether
       1.235656] usbcore: registered new interface driver cdc_eem
10 [
       1.235727] usbcore: registered new interface driver dm9601
11 [
       1.235793] usbcore: registered new interface driver dm9620
12 [
13 [
       1.235867] usbcore: registered new interface driver smsc75xx
14 [
       1.235996] usbcore: registered new interface driver smsc95xx
       1.236065] usbcore: registered new interface driver gl620a
15 [
       1.236132] usbcore: registered new interface driver net1080
16 [
17 [
       1.236197] usbcore: registered new interface driver plusb
       1.236266] usbcore: registered new interface driver rndis_host
18 [
```

上面为主机侧设备类驱动,即各个 USB 设备 HOST 端的驱动程序,可通过 menuconfig 进行配置。

```
Location:
| -> Device Drivers
| -> USB support
| *** USB Device Class drivers ***
| <> xxx
| <> xxx
```

3.2.3 Host 控制器驱动

3.2.3.1 EHCI

```
1.243691] ehci_hcd: USB 2.0 'Enhanced' Host Controller (EHCI) Driver
01 [
       1.243722] ehci-platform: EHCI generic platform driver
02 [
       1.244307] ehci-platform ff5c0000.usb: EHCI Host Controller
03 [
       1.244358] ehci-platform ff5c0000.usb: new USB bus registered, assigned
04 [
bus number 3
      1.244875] ehci-platform ff5c0000.usb: irq 48, io mem 0xff5c0000
05 [
       1.252401] ehci-platform ff5c0000.usb: USB 2.0 started, EHCI 1.00
06 [
       1.252526] usb usb3: New USB device found, idVendor=1d6b, idProduct=0002
07 [
       1.252561] usb usb3: New USB device strings: Mfr=3, Product=2,
] 80
SerialNumber=1
       1.252593] usb usb3: Product: EHCI Host Controller
09 [
      1.252623] usb usb3: Manufacturer: Linux 3.10.104 ehci_hcd
10 [
      1.252654] usb usb3: SerialNumber: ff5c0000.usb
11 [
12 [ 1.253238] hub 3-0:1.0: USB hub found
13 [ 1.253284] hub 3-0:1.0: 1 port detected
. . .
```

上述为 EHCI 控制器初始化完整打印,从 log 可以获取到如下信息:

- 控制器基本信息,包括中断号、设备虚拟地址、控制器版本等信息。
- EHCI 控制器被枚举为一个 USB2.0 Root HUB (hub 3-0:1.0),同时也可以看出该 HUB 被分配的 BUS Number (3)。

3.2.3.2 OHCI

```
01 [ 1.253939] ohci_hcd: USB 1.1 'Open' Host Controller (OHCI) Driver
02 [ 1.253970] ohci-platform: OHCI generic platform driver
03 [ 1.254316] ohci-platform ff5d0000.usb: Generic Platform OHCI controller
04 [ 1.254366] ohci-platform ff5d0000.usb: new USB bus registered, assigned bus number 4
```

```
05 [ 1.254456] ohci-platform ff5d0000.usb: irq 49, io mem 0xff5d0000
06 [ 1.308870] usb usb4: New USB device found, idVendor=1d6b, idProduct=0001
07 [ 1.308909] usb usb4: New USB device strings: Mfr=3, Product=2,
SerialNumber=1
08 [ 1.308942] usb usb4: Product: Generic Platform OHCI controller
09 [ 1.308973] usb usb4: Manufacturer: Linux 3.10.104 ohci_hcd
10 [ 1.309004] usb usb4: SerialNumber: ff5d0000.usb
11 [ 1.309601] hub 4-0:1.0: USB hub found
12 [ 1.309648] hub 4-0:1.0: 1 port detected
...
```

上述为 OHCI 控制器初始化完整打印,同 EHCI,从 log 也可以获取到如下信息:

- 控制器基本信息,包括中断号、设备虚拟地址、控制器版本等信息。
- OHCI 控制器被枚举为一个 USB1.1 Root HUB (hub 4-0:1.0),同时也可以看出该 HUB 被分配的 BUS Number (4)。

3.2.3.3 DWC2 Host

```
1.313609] usb20_otg ff580000.usb: DWC OTG Controller
01 [
       1.313660] usb20_otq ff580000.usb: new USB bus registered, assigned bus
02 [
number 5
      1.313719] usb20_otg ff580000.usb: irq 55, io mem 0x00000000
03 [
      1.313833] usb usb5: New USB device found, idVendor=1d6b, idProduct=0002
04 [
05 [
       1.313868] usb usb5: New USB device strings: Mfr=3, Product=2,
SerialNumber=1
06 [
      1.313900] usb usb5: Product: DWC OTG Controller
       1.313931] usb usb5: Manufacturer: Linux 3.10.104 dwc_otq_hcd
07 [
08 [
      1.313962] usb usb5: SerialNumber: ff580000.usb
09 [ 1.314523] hub 5-0:1.0: USB hub found
      1.314568] hub 5-0:1.0: 1 port detected
10 [
11 [ 1.315013] usb20_host: version 3.10a 21-DEC-2012
```

上述为 DWC2 HOST 控制器初始化完整打印,同其它 Host 控制器,从 log 也可以获取到如下信息:

- 控制器基本信息,包括中断号、设备虚拟地址、控制器版本(version 3.10a 21-DEC-2012)等信息。
- DWC2 HOST 控制器被枚举为一个 USB2.0 Root HUB (hub 5-0:1.0),同时也可以看出该 HUB 被分配的 BUS Number (5)。

3.2.3.4 DWC3 Host

```
01 [ 1.240046] xhci-hcd xhci-hcd.0.auto: xHCI Host Controller
02 [ 1.240104] xhci-hcd xhci-hcd.0.auto: new USB bus registered, assigned bus
number 1
03 [ 1.241268] xhci-hcd xhci-hcd.0.auto: irq 99, io mem 0xff600000
```

```
04 [ 1.241409] usb usb1: New USB device found, idVendor=1d6b, idProduct=0002
       1.241443] usb usb1: New USB device strings: Mfr=3, Product=2,
05 [
SerialNumber=1
       1.241477] usb usb1: Product: xHCI Host Controller
06 [
      1.241508] usb usb1: Manufacturer: Linux 3.10.104 xhci-hcd
07 [
       1.241539] usb usb1: SerialNumber: xhci-hcd.0.auto
08 [
      1.242232] hub 1-0:1.0: USB hub found
09 [
      1.242282] hub 1-0:1.0: 1 port detected
10 [
11 [
      1.242570] xhci-hcd xhci-hcd.0.auto: xHCI Host Controller
12 [ 1.242617] xhci-hcd xhci-hcd.0.auto: new USB bus registered, assigned bus
number 2
       1.242734] usb usb2: New USB device found, idVendor=1d6b, idProduct=0003
13 [
      1.242771] usb usb2: New USB device strings: Mfr=3, Product=2,
14 [
SerialNumber=1
15 [ 1.242803] usb usb2: Product: xHCI Host Controller
      1.242834] usb usb2: Manufacturer: Linux 3.10.104 xhci-hcd
16 [
17 [ 1.242865] usb usb2: SerialNumber: xhci-hcd.0.auto
18 [ 1.243408] hub 2-0:1.0: USB hub found
19 [ 1.243451] hub 2-0:1.0: 1 port detected
. . .
```

DWC3 Host 集成 XHCI 控制器,上述为 XHCI 控制器初始化完整打印,从 log 可以获取到如下信息:

- 控制器基本信息,包括中断号、控制器物理地址等信息。
- XHCI 控制器分别被枚举为一个 USB3.0 Root HUB (hub 1-0:1.0)和一个 USB2.0 Root HUB (hub 2-0:1.0),同时也可以看出两个 HUB 分别被分配到的 BUS Number。

4. 设备侧日志

目前,运行 Kernel 3.10 SDK 的 Rockchip 芯片上仅集成 DWC2 IP,所以 Devices 控制器仅 DWC2 一个,内核使用 dwc_otg_310 驱动,位于 drivers/usb/dwc_otg_310 目录。

4.1 DWC2 Peripheral

```
01 [
      1.312160] usb20_otg: version 3.10a 21-DEC-2012
02 [
       1.312963] Core Release: 3.10a
      1.312992] Setting default values for core params
03 [
       1.313179] Using Buffer DMA mode
04 [
      1.313207] Periodic Transfer Interrupt Enhancement - disabled
05 [
06 [
       1.313233] Multiprocessor Interrupt Enhancement - disabled
07 [
      1.313262] OTG VER PARAM: 0, OTG VER FLAG: 0
08 [ 1.313288] ^^^^^^^^^^^Device Mode
. . .
```

上面为 Devcies 控制器初始化 log, 从 log 也可以得到一些控制器信息。

• 01-02 行:控制器软件版本(version 3.10a 21-DEC-2012),IP 版本: 3.10a

• 控制器当前的工作模式和部分参数的配置。

4.2 DWC2 Peripheral 枚举日志

```
9.208851] [otg id chg] last id -1 current id 64
01 [
       9.208971] rk_battery_charger_detect_cb , battery_charger_detect 6
02 [
       9.308586] Using Buffer DMA mode
03 [
       9.308692] Periodic Transfer Interrupt Enhancement - disabled
04 [
05 [
       9.308710] Multiprocessor Interrupt Enhancement - disabled
       9.308729] OTG VER PARAM: 0, OTG VER FLAG: 0
06 [
       9.308745] ^^^^^^^^^^Device Mode
07 [
] 80
       9.308774] dwc_otg_hcd_resume, usb device mode
       9.409073] wc_otg_hcd_suspend, usb device mode
09 [
       9.799241] **********vbus detect********
10 [
       9.801964] rk_battery_charger_detect_cb , battery_charger_detect 1
11 [
       9.924721] Using Buffer DMA mode
12 [
13 [
       9.924755] Periodic Transfer Interrupt Enhancement - disabled
       9.924772] Multiprocessor Interrupt Enhancement - disabled
14 [
       9.924790] OTG VER PARAM: 0, OTG VER FLAG: 0
15 ſ
       9.924807] ^^^^^^^^^^^Device Mode
16 [
                 ****************soft connect!!!**********
17 [
       9.924873]
18 [
     10.038883] USB RESET
      10.129663] ndroid_work: sent uevent USB_STATE=CONNECTED
19 [
    10.133049] USB RESET
20 [
21 [
      10.256977] android_usb gadget: high-speed config #1: android
22 [ 10.257999] android_work: sent uevent USB_STATE=CONFIGURED
23 [
     10.297006]
                 mtp_open
```

上面 log 为 DWC2 peripheral 枚举的完整日志。

- 01 行表示检测到 USB ID 变化,有 USB 线接入;
- 03-07 为控制器重新初始化 log;
- 10 行表示检测到 VBUS;
- 18-22 行为 USB 枚举成功,并通过 UEVENT 事件通知 Android 层 Gadget 连接成功。

5. Kernel 4.4

5.1 适用芯片

本章节介绍 Linux Kernel 4.4 初始化日志,主要适用于 RK312X、RK3288、RK322X、RK322XH、RK3328、RK3366、RK3368,RK3399 等有运行 Kernel 4.4 SDK 的平台。

5.2 主机侧日志

5.2.1 USB CORE 及设备类驱动

跟 Linux Kernel 3.10 相同,usbcore 注册 USB 文件系统、注册 USB HUB 驱动,以及注册 USB 通用设备驱动,log 同<u>Linux Kernel 3.10</u>。

设备类驱动亦同Kernel 3.10, log 和配置方式也相同。

5.2.2 Host 控制器驱动

5.2.2.1 EHCI

```
01 [
       0.869076] ehci_hcd: USB 2.0 'Enhanced' Host Controller (EHCI) Driver
02 [
       0.869099] ehci-pci: EHCI PCI platform driver
       0.869191] ehci-platform: EHCI generic platform driver
03 [
       0.873032] ehci-platform ff5c0000.usb: EHCI Host Controller
04 [
05 [
       0.873078] ehci-platform ff5c0000.usb: new USB bus registered, assigned
bus number 2
       0.873322] ehci-platform ff5c0000.usb: irq 44, io mem 0xff5c0000
06 [
       0.883191] ehci-platform ff5c0000.usb: USB 2.0 started, EHCI 1.00
07 [
       0.883418] usb usb2: New USB device found, idVendor=1d6b, idProduct=0002
] 80
09 [
       0.883438] usb usb2: New USB device strings: Mfr=3, Product=2,
SerialNumber=1
       0.883454] usb usb2: Product: EHCI Host Controller
10 [
       0.883469] usb usb2: Manufacturer: Linux 4.4.103 ehci_hcd
11 [
12 [
       0.883484] usb usb2: SerialNumber: ff5c0000.usb
13 [
       0.884226] hub 2-0:1.0: USB hub found
14 [
       0.884291] hub 2-0:1.0: 1 port detected
```

上述为 EHCI 控制器初始化完整打印,从 log 也可以获取到如下信息:

- 控制器基本信息,包括中断号、设备虚拟地址、控制器驱动版本等信息。
- EHCI 控制器被枚举为一个 USB2.0 Root HUB (hub 2-0:1.0),同时也可以看出该 HUB 被分配的 BUS Number (2)。

```
0.884853] ohci_hcd: USB 1.1 'Open' Host Controller (OHCI) Driver
        0.884897] ohci-platform: OHCI generic platform driver
        0.885315] ohci-platform ff5d0000.usb: Generic Platform OHCI controller
        0.885352] ohci-platform ff5d0000.usb: new USB bus registered, assigned
bus number 3
        0.885551] ohci-platform ff5d0000.usb: irq 45, io mem 0xff5d0000
        0.940734] usb usb3: New USB device found, idVendor=1d6b, idProduct=0001
        0.940763] usb usb3: New USB device strings: Mfr=3, Product=2,
SerialNumber=1
7 80
        0.940783] usb usb3: Product: Generic Platform OHCI controller
09 [
        0.940800] usb usb3: Manufacturer: Linux 4.4.103 ohci_hcd
       0.940815] usb usb3: SerialNumber: ff5d0000.usb
10 [
11 [ 0.941546] hub 3-0:1.0: USB hub found
12 [
       0.941597] hub 3-0:1.0: 1 port detected
. . .
```

上述为 OHCI 控制器初始化完整打印,同 EHCI,从 log 也可以获取到如下信息:

- 控制器基本信息,包括中断号、设备虚拟地址、控制器驱动版本等信息。
- OHCI 控制器被枚举为一个 USB1.1 Root HUB (hub 3-0:1.0),同时也可以看出该 HUB 被分配的 BUS Number (3)。

5.2.2.3 DWC2 Host

```
0.579425] ff580000.usb supply vusb_d not found, using dummy regulator
01 [
       0.579500] ff580000.usb supply vusb_a not found, using dummy regulator
02 [
       0.866540] dwc2 ff580000.usb: EPs: 10, dedicated fifos, 972 entries in
03 [
SPRAM
       0.867120] dwc2 ff580000.usb: DWC OTG Controller
04 [
05 [
       0.867163] dwc2 ff580000.usb: new USB bus registered, assigned bus number
7 90
       0.867211] dwc2 ff580000.usb: irq 43, io mem 0x00000000
       0.867428] usb usb1: New USB device found, idVendor=1d6b, idProduct=0002
07 [
] 80
       0.867449] usb usb1: New USB device strings: Mfr=3, Product=2,
SerialNumber=1
       0.867466] usb usb1: Product: DWC OTG Controller
09 [
10 [
       0.867480] usb usb1: Manufacturer: Linux 4.4.103 dwc2_hsotq
11 [
       0.867495] usb usb1: SerialNumber: ff580000.usb
12 [
       0.868254] hub 1-0:1.0: USB hub found
       0.868303] hub 1-0:1.0: 1 port detected
13 [
```

上述为 DWC2 HOST 控制器初始化完整打印,同其它 Host 控制器,从 log 也可以获取到如下信息:

控制器基本信息,包括中断号、设备虚拟地址、控制器部分配置信息。

• DWC2 HOST 控制器被枚举为一个 USB2.0 Root HUB (hub 1-0:1.0),同时也可以看出该 HUB 被分配的 BUS Number (1)。

5.2.2.4 DWC3 Host

```
0.942624] xhci-hcd xhci-hcd.7.auto: xHCI Host Controller
01 [
        0.942662] xhci-hcd xhci-hcd.7.auto: new USB bus registered, assigned bus
02 [
number 4
        0.943032] xhci-hcd xhci-hcd.7.auto: hcc params 0x0220fe64 hci version
03 [
0x110 quirks 0x00210010
       0.943107] xhci-hcd xhci-hcd.7.auto: irq 185, io mem 0xff600000
        0.943357] usb usb4: New USB device found, idVendor=1d6b, idProduct=0002
        0.943378] usb usb4: New USB device strings: Mfr=3, Product=2,
06 [
SerialNumber=1
        0.943395] usb usb4: Product: xHCI Host Controller
07 [
        0.943410] usb usb4: Manufacturer: Linux 4.4.103 xhci-hcd
09 [
       0.943425] usb usb4: SerialNumber: xhci-hcd.7.auto
       0.944176] hub 4-0:1.0: USB hub found
10 [
       0.944226] hub 4-0:1.0: 1 port detected
        0.944647] xhci-hcd xhci-hcd.7.auto: xHCI Host Controller
       0.944676] xhci-hcd xhci-hcd.7.auto: new USB bus registered, assigned bus
13 [
14 [
        0.944779] usb usb5: We don't know the algorithms for LPM for this host,
disabling LPM.
       0.944943] usb usb5: New USB device found, idVendor=1d6b, idProduct=0003
        0.944963] usb usb5: New USB device strings: Mfr=3, Product=2,
SerialNumber=1
        0.944979] usb usb5: Product: xHCI Host Controller
18 [
        0.944994] usb usb5: Manufacturer: Linux 4.4.103 xhci-hcd
       0.945009] usb usb5: SerialNumber: xhci-hcd.7.auto
20 [
       0.945718] hub 5-0:1.0: USB hub found
21 [
       0.945766] hub 5-0:1.0: 1 port detected
. . .
```

DWC3 Host 集成 XHCI 控制器,上述为 XHCI 控制器初始化完整打印,从 log 可以获取到如下信息:

- 控制器基本信息,包括中断号、设备虚拟地址、控制器版本等信息。
- XHCI 控制器分别被枚举为一个 USB3.0 Root HUB (hub 4-0:1.0)和一个 USB2.0 Root HUB (hub 5-0:1.0),同时也可以看出两个 HUB 被分配到的 BUS Number。

6. 设备侧日志

目前,Rockchip SoC 除 RK3399 芯片外,其它芯片都是集成 DWC2 OTG IP,RK3399 集成 DWC3 OTG IP,支持 USB3.0,所以设备侧 log 分 dwc2 和 dwc3 阐述。

Kernel 4.4, DWC2 使用 drivers/usb/dwc2 目录驱动; DWC3 使用 drivers/usb/dwc3 目录驱动。

6.1 DWC2/DWC3 Peripheral

Kernel 4.4,开机在没有连接 USB 线的情况下,对于 DWC2,如果控制器为 OTG 模式,日志同<u>DWC2</u> <u>Host</u>;如果为 Peripheral 模式,则没有特别 log 输出;DWC3 跟 DWC2 类似。

6.2 DWC2 Peripheral 枚举日志

```
01 [ 18.566773] read descriptors
02 [ 18.566811] read descriptors
03 [ 18.566820] read strings
04 [ 18.631141] dwc2 ff580000.usb: bound driver configfs-gadget
05 [ 18.767106] dwc2 ff580000.usb: new device is high-speed
06 [ 18.796143] android_work: sent uevent USB_STATE=CONNECTED
07 [ 18.807125] dwc2 ff580000.usb: new device is high-speed
08 [ 18.835990] dwc2 ff580000.usb: new address 1
09 [ 18.871528] configfs-gadget gadget: high-speed config #1: b
10 [ 18.871732] android_work: sent uevent USB_STATE=CONFIGURED
...
```

上面 Log 为 DWC2 Peripheral 枚举的完整日志。

- 01-03 行 Android 层开始配置 Gadget;
- 04-05 为控制器枚举信息;
- 06 行表示枚举成功,Gadget 通过 Uevent 向 Android 发送 Connected 消息;
- 10 行 Gadget 通过 Uevent 向 Android 发送 Configured 消息;表示 Gadget 配置成功。

6.3 DWC3 Peripheral 枚举日志

```
01 [ 13.924130] fusb302 4-0022: CC connected in 1 as UFP
02 [ 14.061902] phy phy-ff770000.syscon:usb2-phy@e450.5: charger =
USB_SDP_CHARGER
03 [ 15.633013] fusb302 4-0022: PD disabled
04 [ 15.635514] cdn-dp-fb fec00000.dp-fb: lanes count does not change: 0
05 [ 15.651643] rockchip-dwc3 usb@fe800000: USB peripheral connected
06 [ 19.811878] read descriptors
07 [ 19.811923] read strings
08 [ 19.938589] android_work: sent uevent USB_STATE=CONNECTED
09 [ 19.973662] configfs-gadget gadget: super-speed config #1: b
10 [ 19.974071] android_work: sent uevent USB_STATE=CONFIGURED
...
```

上面 log 为 DWC3 Peripheral 枚举的完整日志。

- 01 行 FUSB302 检测到 USB 线有接入;
- 02 行充电检测启动,因为接着 PC,所以为标准充电器;
- 06-07 行 Android 层开始配置 Gadget;
- 08 行表示枚举成功,Gadget 通过 Uevent 向 Android 发送 Connected 消息;

● 09-10 行,USB Config 配置成功, 息。	Gadget 通过 Uevent 向 Android 发送 Configured 配置成功消
15.0	