Why do we use binary in a computer system?

Provides the greatest opportunity for noise immunity


How many bits does one decimal symbol takes?

Approximately \approx 3.3 bits

What conclusion can be drawn from this?

Hexadecimal and octal are more convenient than decimal when describing values on a bus

Electrical Circuit Representation



Parallel bus

Collection of wires communicating a value between sub-circuits

A Brief History of Processor Representation

Intel 4004 (1971)

The first commercially availe
MOS 6502 and Zilog Z80 (~1975) rcially available microprocessor had a word length of 4 bits

Popular 8-bit processors in early personal computers, such as the Apple II (6502) and TRS-80 (Z80)

Motorola 88030, PowerPC G4, and Intel Pentium (upto 2004).

Processor at the era of 32-bit architecture, being widely used in personal computers and workstations

IBM PowerPC G5 and x86-64 (e.g., Intel Core 2 and AMD64, introduced in 2003–2004)

The transition to 64- bit, offering higher performance, larger addressable memory space, and greater efficiency in modern computing

Modern Processors (2020s onwards)

Intel Core i9 AMD Ryzen Apple M-series continue to evolve the 64-bit architecture multi-core designs advanced parallel processing


coprocessors for AI Coprocessors for Machine learning
and be informed by design elements of ARM and RISC-V

ARM (stylised in lowercase as arm, formerly an acronym for Advanced RISC Machines and originally Acorn RISC Machine) is a family of RISC instruction




Converting between bases:

Decimal to Binary



2. Binary to decimal

Binary number - 1010




3. Decimal to hex

It may be easier to convert into binary first and then into the required base


4. Hex to decimal

Hexadecimal to Decimal



5. Hex to binary

How to Convert HEX TO BINARY



1111001110110111



6. Binary to he

To convert binary numbers into hexadecimals, you only have to make 4-bit groups and convert directly each group:



7. Decimal to Octal

Decimal to Octal Conversion



(136)₁₀ = (210)₈

Signed Magnitude Representation

The MSB is an indicator, i.e., indicates it is negative

The value of the remaining bits are calculated as before

1101 _{25M} :	1	1	0	1
Position:	negative? negative?	2 ² 4	2¹ 2	2º 1
Value:	-1 x -5 ₁₀	(1 x 4 +	0 x 2 +	1 x 1)

Two's Complement Properties

Can represent more negative numbers than positive

The range is asymmetric

$$1000_{2TC} = -8$$

$$0111_{2TC} = +7$$

For N bits, the range is -2^{N-1} to $(2^{N-1}-1)$

Unique zero

Signed magnitude has both +0 and -0

Forming Two's Complement

To form the bit pattern for a negative number in two's complement:

Take the representation of the positive number

Invert the bits, ensuring there are enough bits for the MSB to be the sign

Add 1, ignoring any overflow

What is the two's complement bit pattern for -9?

```
+9_{10} = 1001_2
```

Ensure enough bits: 000010012

Invert: 11110110₂ Add 1: 11110111₂ -9₁₀ = 11110111_{2TC}

Addition in Two's Complement

Addition is almost the same as we've seen previously

Just as before but ignore any overflow

$$00001001 = +9$$
 $00001101 = +13$ $00000101 = +5$
 $+11110111 = -9$ $+11110111 = -9$
 $00000000 = 0$ $00000100 = 4$ $11111100 = -4$
 11111111 111

Fixed Point Representation

Add columns to denote the fractional parts of a value

10.112	=	1	0	1	1
Position	n: =	2¹ 2	2º 1	2 ⁻¹ 0.5	2 ⁻² 0.25
Value	=	(1 x 2 + 2.75 ₁₀	0 x 1 +	1 x 0.5 +	1 x 0.25)

Floating Point Representation

Scientific notation allows small and large values to be written succinctly

The speed of light is 3x108 m/s $\approx 299,792,458$ m/s Floating point uses the same principles as scientific notation

Express numbers as (mantissa x 10exponent)
The mantissa represents the detail of the value to a certain precision

The exponent represents the magnitude of the value

IEEE Floating Point

Floating point representation trades precision for range

Extending range at the expense of reducing precision

IEEE Standard 754 is widely used and specifies levels of binary precision

Single precision (using 32 bits)

Double precision (using 64 bits)

Quad precision (using 128 bits)



For example, single precision uses 1 bit for the sign (s), 8 bits for the exponent (e) and 23 bits for the mantissa (m)