Rockchip Mediaserver Introduction

ID: RK-SM-YF-361

Release Version: V0.0.2

Release Date: 2020-09-03

Security Level: □Top-Secret □Secret □Internal ■Public

DISCLAIMER

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP") DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

Trademark Statement

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

All rights reserved. ©2020. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: <u>www.rock-chips.com</u>

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

Preface

Overview

This document is intended to introduce each module of the mediaserver application.

Product Version

Chipset	Kernel Version	
RV1109	Linux 4.19	
RV1126	Linux 4.19	
RK1808	Linux 4.4	
RK1806	Linux 4.4	

Intended Audience

This document (this guide) is mainly intended for:

Technical support engineers

Software development engineers

Revision History

Date	Version	Author	Change Description
2020-04-28	V0.0.1	Vicent	Initial version
2020-09-03	V0.0.2	Ruby	Update the company name and document format

Contents

Rockchip Mediaserver Introduction

- 1. Overview
 - 1.1 Application Introduction
 - 1.2 Usage
- 2. Code Modules Introduction
 - 2.1 Directory Structure
 - 2.2 Configuration Introduction
 - 2.2.1 ipc-display.conf
 - 2.2.2 Nodes that Record the Sequence of Arrangement and Combination Between Pipes
 - 2.2.3 Nodes that Record the Sequence of Arrangement and Combination Between Flows
 - 2.2.4 flow_index Parameter
 - 2.2.5 Flow Name
 - 2.2.6 Flow Parameter
 - 2.2.7 Stream Parameter

1. Overview

1.1 Application Introduction

Mediaserver comes with the concept of pipe, configures and reorganizes the media streams of single or multiple channels, and provides IPC communication interfaces, which can interact with web and other interfaces. Developers can realize any arrangement and combination of the following functions through simple configurations:

- 1. Text stream reading, camera device collection, audio device collection.
- 2. Audio/video frequency encoding.
- 3. rtsp/rtmp/Alibaba Cloud streaming, cloud intercom function, picture upload.
- 4. Video file recording, taking photos, and audio playback.
- 5. Support filter plug-ins such as rockface, rockx, rga, etc.
- 6. Can interact with the web

1.2 Usage

mediaserver [-c config] [-d / -D] [-s / -S] [-h]

- -c: specify the path of the configuration file
- -d: indicates that dbserver is not used
- -D: means to use the default configuration in dbserver
- -s: indicates that dbus is registered on the system bus
- -S: indicates that dbus is registered on the session bus


Examples:

Use IPC products with screen: mediaserver -c /oem/usr/shared/mediaserver/rv1109/ipc-display.conf

Use IPC products without screen: mediaserver -c /oem/usr/shared/mediaserver/rv1109/ipc.conf

2. Code Modules Introduction

2.1 Directory Structure



2.2 Configuration Introduction


The configuration file is in json format.

Pipe represents an independent multimedia channel.

Flow represents a Source/IO/Sink unit in a multimedia channel.

Stream represents the processing method used by Flow.

2.2.1 ipc-display.conf



2.2.2 Nodes that Record the Sequence of Arrangement and Combination Between Pipes

```
Pipe_x:ID of the multimedia channel
```

2.2.3 Nodes that Record the Sequence of Arrangement and Combination Between Flows

```
Flow_x: The ID of the Source/IO/Sink unit in the current multimedia channel flow_index: Record flow type, stream type, upper and lower flow name flow_name: record the flow name flow_param: record flow parameters stream_param: record stream parameters
```

2.2.4 flow_index Parameter

```
fix_resolution: Whether to fix the resolution and not be changed by the
database
   flow_index_name: flow name and ID, to prevent multiple flows of the same type
in the current pipe
   flow_type: flow type
   stream_id: stream ID: 0: mian stream; 1: sub stream; 2 third stream
   stream_type: stream type
   upflow_index_name: previous flow name
   ...
```

2.2.5 Flow Name

```
name: current flow name
```

2.2.6 Flow Parameter

```
name: The name of the stream/filter/encoder used by the current flow
input_data_type: input buffer type
output_data_type: output buffer type
...
```

2.2.7 Stream Parameter

device: device node

frame_num: the number of buffered frames

height: high resolution use_libv412: Use libv412

v412_capture_type: camera capture type
v412_mem_type: allocate memory type

virtual_height: resolution virtual height
virtual_width: resolution virtual width

width: resolution width

. . .