CONNECTION DIAGRAM

Toggle Switch

→ For Standby V
Auto Mode.

* NO — Normally open.
* NC — Normally close.

RelayNO

Switch

Neutral

ARDUINO NANO

4
8
2

5V
GND

5V
GND

8
5V
GND

RELAY

NO
C
NC

Live

5V OUT GND

2

PIR Sensor.