## Cleaning

If you need to clean the unit, wipe it with a dry towel. Do not wipe the contactor pins to avoid inserting particles inside the shell. In case the contactor needs internal cleaning, use a vacuum cleaner or a fine brush, with the contactor facing down allowing particles to leave the shell.