Location and mounting requirements

The unit may lie on the floor, on top of a table or desk, on its carrier enclosure in closed position, or on any other surface that provides suitable stability.

It is required a power socket nearby for powering the unit. It is advised to organise with site personnel prior to carry out testing.

Instructions for protective earthing

Protective earthing is ensured by straight connection of the BS 1363 power cord cable (provided) into the power input connector, located on the unit rear panel. Make sure the power cord is PAT tested before using it.

Connections to the supply

Connections to the supply are achieved by straight connection of the BS 1363 power cord cable (provided) into the power input connector, located on the unit rear panel. Make sure the power cord is PAT tested before using it.

Ventilation requirements

The Faraday P100 Series is a self-ventilated unit. Do not use the unit above or below rated environmental conditions.