



INSTALLATION MANUAL FLOOR MOUNT TROLLEY/AV CART




MODEL	SERIES	VESA	DISPLAY SIZE	MAX LOAD
LG-EMERALD 3-N20	FLOOR MOUNT TROLLEY/AV CART	100x100 to 900x600	72" to 98"	287 lbs (130 kg)

Checklist




IMPORTANT: Ensure that you have received all parts according to the checklist prior to installation.

Checklist




IMPORTANT: Prior to installation, ensure that you have received all the parts as per the checklist

1. Product Dimension




2. Installation


Instructions for fixing floor mount.




View after inserting the screw to bottom side of the base rail


3. Place the wheels to bottom side of the base left and right rail and rotate wheel thread until it fully but to base rail








5. Place the connecting rod on the left stand rail and insert the washer and screw (Refer M-D in the checklist - stand unit)



6. Place the right stand rail on the semi assumbled unit and insert the washer and screw


Note:

(Refer M-D in the checklist - stand unit)




7. After finishing the previous step 4, insert the washer and screw Note:


(Refer M-A, M-B in the checklist - stand unit)




8. Place the tray on the connecting rod slot and press the downwards to lock




9. Place the adjustable plate and insert the washer and screw (Refer M-D in the checklist - stand unit)




10. Place the camera ledge on the adjustable plate and insert the screw (Refer M-D in the checklist - stand unit)




11. Camera ledge can adjust upto 250mm height






13. Screw the knob to the connecting rod (Refer knob M-H in the checklist - stand unit)



14. Place the interface bracket on the TV/ display and insert the washer and screw (Refer the checklist for the suitable screw and washer)



15. Place the TV/ display on the floor stand

