

# APPLICATION NOTE (DOC No. HX8357-B-AN)

### <sup>>></sup>HX8357-B

320RGB x 480 dot, 262K color, with internal GRAM,TFT Mobile Single Chip Driver *Preliminary version 01 March, 2010* 

Himax Technologies, Inc. http://www.himax.com.tw







### **List of Contents**

March, 2010

1.	HX835	7-B Reference FPC circuit and Initial code	3
	1.1	CMO's F03509/03206 panel	3
	1.1.1	HX8357-B MPU interface reference FPC circuit for CMO's F03509/03206 panel	
	1.1.2	HX8357-B MPU interface reference initial code for CMO's F03509 panel	4
	1.1.3	HX8357-B MPU interface reference initial code for CMO's F03206 panel	
	1.2	Tianma's TM035NYH01 panel	
	1.2.1	HX8357-B MPU interface reference FPC circuit for Tianma's TM035NYH01 panel	
	1.2.2	HX8357-B MPU interface reference initial code for Tianma's TM035NYH01 panel	7
	1.3	BOE's 3.5 inch panel	8
	1.3.1	HX8357-B MPU interface reference FPC circuit for BOE's 3.5 inch panel	
	1.3.2	HX8357-B MPU interface reference initial code for BOE's 3.5 inch panel	9
	1.4	TRULY's 3.5 inch panel	
	1.4.1	HX8357-B MPU interface reference FPC circuit for TRULY's 3.5 inch panel	11
	1.4.2	HX8357-B MPU interface reference initial code for TRULY's 3.5 inch panel	12
2. I	Revision	History	14



### <sup>>></sup> HX8357-B

320RGB x 480 dot, 262K color, with internal GRAM, TFT Mobile Single Chip Driver



### List of Figures

March, 2010

Figure 1. 1 MPU mode Reference FPC Circuit for CMO's F03509/03206 panel	3
Figure 1. 2 MPU mode Reference FPC Circuit for Tianma's TM035NYH01 panel	
Figure 1. 3 MPU mode Reference FPC Circuit for BOE's 3.5 inch panel	
Figure 1. 4 MPU mode Reference FPC Circuit for TRULY's 3.5 inch panel	



### <sup>>></sup>НХ8357-В

320RGB x 480 dot, 262K color, with internal GRAM, TFT Mobile Single Chip Driver



Version 01 March, 2010

### 1. HX8357-B Reference FPC circuit and Initial code

1.1 CMO's F03509/03206 panel

1.1.1 HX8357-B MPU interface reference FPC circuit for CMO's F03509/03206 panel




Figure 1. 1 MPU mode Reference FPC Circuit for CMO's F03509/03206 panel

-P.3-



### 1.1.2 HX8357-B MPU interface reference initial code for CMO's F03509 panel

```
void LCD_Initial_HX8357B_CMO_3_5(void)
  All Power On();
                              // VCI & IOVCC On
  DelayX1ms(10);
  HW RESET();
                              // Hardware Reset
  DelayX1ms(10);
  Set_NOKIA_8B_CMD(0x11);
                              //Sleep Out
  DelayX1ms(150);
  Set_NOKIA_8B_CMD(0xB4);
                              //Set RM, DM
  Set_NOKIA_8B_PA(0x00);
                              //MPU Mode
  Set NOKIA 8B CMD(0xC8);
                              //Set Gamma
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x67);
  Set_NOKIA_8B_PA(0x04);
  Set_NOKIA_8B_PA(0x70);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x1E);
  Set_NOKIA_8B_PA(0x37);
  Set_NOKIA_8B_PA(0x01);
  Set NOKIA 8B PA(0x77);
  Set NOKIA 8B PA(0x07);
  Set NOKIA 8B PA(0x0F);
  Set_NOKIA_8B_PA(0x00);
                              //Set Power
  Set_NOKIA_8B_CMD(0xD0);
  Set_NOKIA_8B_PA(0x44);
                              //DDVDH
  Set_NOKIA_8B_PA(0x41);
  Set_NOKIA_8B_PA(0x07);
                              //VREG1
  Set NOKIA 8B CMD(0xD1);
                              //Set VCOM
  Set NOKIA 8B PA(0x2A);
  Set_NOKIA_8B_PA(0x14);
  Set_NOKIA_8B_CMD(0xE9);
                             //Set Panel
  Set_NOKIA_8B_PA(0x01);
  Set_NOKIA_8B_CMD(0x29);
                             //Display On
  DelayX1ms(5);
```

}



#### 1.1.3 HX8357-B MPU interface reference initial code for CMO's F03206 panel

```
void LCD_Initial_HX8357B_CMO_3_2(void)
  All Power On();
                              // VCI & IOVCC On
  DelayX1ms(10);
  HW RESET();
                              // Hardware Reset
  DelayX1ms(10);
  Set NOKIA 8B CMD(0x11);
                             //Sleep Out
  DelayX1ms(150);
  Set_NOKIA_8B_CMD(0xB4);
                             //Set RM, DM
  Set_NOKIA_8B_PA(0x00);
                              //MPU Mode
  Set NOKIA 8B CMD(0xC0);
                             //Set PANEL
  Set_NOKIA_8B_PA(0x14);
  Set_NOKIA_8B_PA(0x3B);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x02);
  Set NOKIA 8B PA(0x11);
  Set NOKIA 8B CMD(0xC8);
                              //Set Gamma
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x37);
  Set NOKIA 8B PA(0x20);
  Set NOKIA 8B PA(0x03);
  Set NOKIA 8B PA(0x05);
  Set NOKIA 8B PA(0x0E);
  Set NOKIA 8B PA(0x55);
  Set_NOKIA_8B_PA(0x04);
  Set_NOKIA_8B_PA(0x77);
  Set_NOKIA_8B_PA(0x30);
  Set_NOKIA_8B_PA(0x07);
  Set NOKIA 8B PA(0x0A);
  Set NOKIA 8B CMD(0xD0);
                              //Set Power
  Set_NOKIA_8B_PA(0x44);
                              //DDVDH
  Set_NOKIA_8B_PA(0x41);
                              //VREG1
  Set_NOKIA_8B_PA(0x07);
  Set_NOKIA_8B_CMD(0xD1);
                              //Set VCOM
  Set_NOKIA_8B_PA(0x47);
                             //VCOMH
  Set NOKIA 8B PA(0x0F);
                              //VCOML
  Set_NOKIA_8B_CMD(0xE9);
                             //Set Panel
  Set NOKIA 8B PA(0x01);
```

}

Set NOKIA 8B CMD(0x29);

DelayX1ms(5);

//Display On



### 1.2 Tianma's TM035NYH01 panel

## 1.2.1 HX8357-B MPU interface reference FPC circuit for Tianma's TM035NYH01 panel




Figure 1. 2 MPU mode Reference FPC Circuit for Tianma's TM035NYH01 panel

**Himax Confidential** 

This information contained herein is the exclusive property of Himax and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Himax.

-P.6-March, 2010



# 1.2.2 HX8357-B MPU interface reference initial code for Tianma's TM035NYH01 panel

```
void LCD_Initial_HX8357B_Tianma_3_5(void)
{
    TBD
}
```





### 1.3 BOE's 3.5 inch panel

### 1.3.1 HX8357-B MPU interface reference FPC circuit for BOE's 3.5 inch panel




Figure 1. 3 MPU mode Reference FPC Circuit for BOE's 3.5 inch panel

**Himax Confidential** 


This information contained herein is the exclusive property of Himax and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Himax.



#### 1.3.2 HX8357-B MPU interface reference initial code for BOE's 3.5 inch panel

```
void LCD_Initial_HX8357B_BOE_3_5(void)
  All Power On();
                              // VCI & IOVCC On
  DelayX1ms(10);
  HW RESET();
                              // Hardware Reset
  DelayX1ms(10);
  Set NOKIA 8B CMD(0x11);
                             //Sleep Out
  DelayX1ms(150);
  Set_NOKIA_8B_CMD(0xB4);
                             //Set RM, DM
  Set_NOKIA_8B_PA(0x00);
                              //MPU Mode
  Set NOKIA 8B CMD(0xC0);
                             //Set PANEL
  Set_NOKIA_8B_PA(0x14);
  Set_NOKIA_8B_PA(0x3B);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x02);
  Set NOKIA 8B PA(0x11);
  Set NOKIA 8B CMD(0xC8);
                             //Set Gamma
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x36);
  Set NOKIA 8B PA(0x13);
  Set NOKIA 8B PA(0x21);
  Set NOKIA 8B PA(0x09);
  Set NOKIA 8B PA(0x0C);
  Set NOKIA 8B PA(0x46);
  Set_NOKIA_8B_PA(0x14);
  Set_NOKIA_8B_PA(0x77);
  Set_NOKIA_8B_PA(0x12);
  Set_NOKIA_8B_PA(0x06);
  Set NOKIA 8B PA(0x12);
  Set NOKIA 8B CMD(0xD0);
                              //Set Power
  Set_NOKIA_8B_PA(0x45);
                              //DDVDH
  Set_NOKIA_8B_PA(0x41);
                              //VREG1
  Set_NOKIA_8B_PA(0x02);
  Set_NOKIA_8B_CMD(0xD1);
                              //Set VCOM
  Set_NOKIA_8B_PA(0x44);
                             //VCOMH
  Set NOKIA 8B PA(0x0F);
                              //VCOML
  Set_NOKIA_8B_CMD(0xE9);
                             //Set Panel
  Set NOKIA 8B PA(0x01);
  Set NOKIA 8B CMD(0xEE);
                             //Set EQ
  Set NOKIA 8B PA(0x00);
```

Set\_NOKIA\_8B\_PA(0x00); Set\_NOKIA\_8B\_PA(0x00); Set\_NOKIA\_8B\_PA(0x00);





```
Set NOKIA 8B CMD(0xED);
                               //Set DIR TIM
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set NOKIA 8B PA(0xA2);
  Set_NOKIA_8B_PA(0xA2);
Set_NOKIA_8B_PA(0xA2);
  Set_NOKIA_8B_PA(0xA2);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0xAE);
  Set_NOKIA_8B_PA(0xAE);
  Set_NOKIA_8B_PA(0x01);
  Set_NOKIA_8B_PA(0xA2);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_CMD(0x29); //Display On
  DelayX1ms(5);
}
```



### 1.4 TRULY's 3.5 inch panel

#### 1.4.1 HX8357-B MPU interface reference FPC circuit for TRULY's 3.5 inch panel




Figure 1. 4 MPU mode Reference FPC Circuit for TRULY's 3.5 inch panel

**Himax Confidential** 


This information contained herein is the exclusive property of Himax and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Himax.



#### 1.4.2 HX8357-B MPU interface reference initial code for TRULY's 3.5 inch panel

```
void LCD_Initial_HX8357B_TRULY_3_5(void)
  All Power On();
                              // VCI & IOVCC On
  DelayX1ms(10);
  HW RESET();
                              // Hardware Reset
  DelayX1ms(10);
  Set NOKIA 8B CMD(0x11);
                             //Sleep Out
  DelayX1ms(150);
  Set_NOKIA_8B_CMD(0xB4);
                             //Set RM, DM
  Set_NOKIA_8B_PA(0x00);
                              //MPU Mode
  Set NOKIA 8B CMD(0xC0);
                             //Set PANEL
  Set_NOKIA_8B_PA(0x14);
  Set_NOKIA_8B_PA(0x3B);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x02);
  Set NOKIA 8B PA(0x11);
  Set NOKIA 8B CMD(0xC8);
                             //Set Gamma
  Set_NOKIA_8B_PA(0x02);
  Set_NOKIA_8B_PA(0x25);
  Set NOKIA 8B PA(0x01);
  Set NOKIA 8B PA(0x23);
  Set NOKIA 8B PA(0x02);
  Set NOKIA 8B PA(0x08);
  Set NOKIA 8B PA(0x67);
  Set_NOKIA_8B_PA(0x25);
  Set_NOKIA_8B_PA(0x57);
  Set_NOKIA_8B_PA(0x32);
  Set_NOKIA_8B_PA(0x04);
  Set NOKIA 8B PA(0x04);
  Set NOKIA 8B CMD(0xD0);
                              //Set Power
  Set_NOKIA_8B_PA(0x44);
                              //DDVDH
  Set_NOKIA_8B_PA(0x41);
                              //VREG1
  Set_NOKIA_8B_PA(0x06);
  Set_NOKIA_8B_CMD(0xD1);
                              //Set VCOM
  Set_NOKIA_8B_PA(0x53);
                             //VCOMH
  Set NOKIA 8B PA(0x0F);
                              //VCOML
  Set_NOKIA_8B_CMD(0xE9);
                             //Set Panel
  Set NOKIA 8B PA(0x01);
  Set NOKIA 8B CMD(0xEE);
                             //Set EQ
  Set NOKIA 8B PA(0x00);
```

Set\_NOKIA\_8B\_PA(0x00); Set\_NOKIA\_8B\_PA(0x00); Set\_NOKIA\_8B\_PA(0x00);





```
APPLICATION NOTE V01
  Set NOKIA 8B CMD(0xED);
                              //Set DIR TIM
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set NOKIA 8B PA(0xA2);
  Set_NOKIA_8B_PA(0xA2);
Set_NOKIA_8B_PA(0xA2);
  Set_NOKIA_8B_PA(0xA2);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_PA(0xAE);
  Set_NOKIA_8B_PA(0xAE);
  Set_NOKIA_8B_PA(0x01);
  Set_NOKIA_8B_PA(0xA2);
  Set_NOKIA_8B_PA(0x00);
  Set_NOKIA_8B_CMD(0x29); //Display On
  DelayX1ms(5);
}
```

320RGB x 480 dot, 262K color, TFT Mobile Single Chip Driver



APPLICATION NOTE V01

### 2. Revision History

Version	Date	Description of changes	
	2010/03/01	1. New setup	
	2010/04/16	1. Add HX8357-B MPU interface reference FPC circuit and	
		initial code for Tianma's TM035NYH01 panel.	
		2. Add HX8357-B MPU interface reference FPC circuit and	
		initial code for BOE's 3.5 inch panel.	
01		3. Add Initial code for CMO's F03206 panel.	
01		1. Modify the Note4 of Figure 1.1, 1.2, 1.3	
	2. Add HX8357-B MPU interface reference	2. Add HX8357-B MPU interface reference FPC circuit and	
	2010/06/03	initial code for TRULY's 3.5 inch panel.	
	2010/00/03	3. Modify the initial code for CMO's F03509/03206 and BOE's	
		3.5 inch panel.	
		4. Delete D1 of Figure 1.1, 1.2, 1.3 and 1.4	

