
## **Trigger configuration:**

- Coincidence mode
- Coincidence level
- Type (external NIM/TTL, automatic, software)
- Send software trigger



## **Select display mode:**

- Waveform (oscilloscope)
- Spectrum (multichannel analyzer)
- Blank (high rate data)

## **Acquisition settings:**

- Acquisition window length
- Post trigger percentage