



YEAR

SEM

111

EC 8394

ANALOG AND DIGITAL COMMUNICATION

UNIT No. II PULSE AND DATA COMMUNICATION

2.1.1 PULSE AMPLITUDE MODULATION











## PULSE AMPLITUDE MODULATION

#### **Pulse Modulation**

Pulse modulation is a technique in which the signal is transmitted with the information by pulses. This is divided into Analog Pulse Modulation and Digital Pulse Modulation.

Analog pulse modulation is classified as

- Pulse Amplitude Modulation (PAM)
- Pulse Width Modulation (PWM)
- Pulse Position Modulation (PPM)


Digital modulation is classified as

- Pulse Code Modulation
- Delta Modulation

### **Pulse Amplitude Modulation**

Pulse amplitude modulation is a technique in which the amplitude of each pulse is controlled by the instantaneous amplitude of the modulation signal. It is a modulation system in which the signal is sampled at regular intervals and each sample is made proportional to the amplitude of the signal at the instant of sampling. This technique transmits the data by encoding in the amplitude of a series of signal pulses.

1




## Modulation Signal

There are two types of sampling techniques for transmitting a signal using PAM. They are:


- 1. Flat Top PAM
- 2. Natural PAM

**Flat Top PAM:** The amplitude of each pulse is directly proportional to modulating signal amplitude at the time of pulse occurrence. The amplitude of the signal cannot be changed with respect to the analog signal to be sampled. The tops of the amplitude remain flat.



### **PAM**

**Natural PAM:** The amplitude of each pulse is directly proportional to modulating signal amplitude at the time of pulse occurrence. Then follows the amplitude of the pulse for the rest of the half-cycle.



### **PAM**


## **Circuit Design of Pulse Amplitude Modulation**

A PAM is generated from a pure sine wave modulating signal and a square wave generator which produces the carrier pulse and a PAM modulator circuit.

Natural

A sine wave generator is used which is based on Wien Bridge Oscillator circuit. This can

produce distortion less sine wave at the output. The circuit is designed such that the amplitude and the frequency of the oscillator can be adjusted using a potentiometer.




#### Generator

The frequency can be varied by varying the potentiometer R2 and the amplitude of the adjusted using the potentiometer R. The frequency of the sine wave generated is given by

$$F = 1/(2\pi\sqrt{R1R2C1C2})$$

The square wave is generated using op-amp based astable circuit. The op-amp is used to reduce the complexity of generating the square wave. The ON time and the OFF time of the pulse can be made identical and the frequency can be adjusted without changing them.



The time period of the pulses generated depends on the value of the resistance R and the capacitance C. The period of the op-amp astable circuit is given by

$$T = 2.2RC$$

# **Types of PAM**

Pulse amplitude modulation is categorized into two types


- 1. Single Polarity PAM
- 2. Double Polarity PAM

Single polarity PAM is a situation where a suitable fixed DC bias is added to the signal to ensure that all the pulses are positive.

Double polarity PAM is a situation where the pulses are both positive and negative.

#### **Demodulation of PAM**

For the demodulation of the PAM signal, the PAM signal is fed to the low pass filter. The low pass filter eliminates the high-frequency ripples and generates the demodulated signal. This signal is then applied to the inverting amplifier to amplify its signal level to have the demodulated output with almost equal amplitude with the modulating signal.



## signal

## **Applications of PAM**

- It is used in Ethernet communication.
- It is used in many micro-controllers for generating the control signals.
- It is used in Photo-biology.
- It is used as an electronic driver for LED lighting.

## **Advantages**

- It is a simple process for both modulation and demodulation.
- Transmitter and receiver circuits are simple and easy to construct.
- PAM can generate other pulse modulation signals and can carry the message at the same time.

## **Disadvantages**

- Bandwidth should be large for transmission PAM modulation.
- Noise will be great.
- Pulse amplitude signal varies so the power required for transmission will be more.



# **ELECTRONICS & INSTRUMENTATION ENGINEERING**

## **ANALOG AND DIGITAL COMMUNICATION**