
SPE1A



PS_IMPES_1

TMARCH

0.1 1 0.1 5 0.3 0.3 300 0.2 0.3 0.001

Final time: 3655.5 Days

Total time steps: 5533

Total nonlin steps: 5533

Total linear steps: 8828

Linear solver time: 0.932773s

Simulation time: 2.44659s

$\mathsf{OC}_\mathsf{IMPES}_1$

0.1 1 0.1

Final time: 3655.5 Days

Total linear steps: 19177
Linear solve time: 1.22111s
Total time steps: 4970
Simulation time: 1.68812s


OC_IMPES_0.1

0.1 0.1 0.1

Final time: 3655.5 Days
Total linear steps: 109630
Linear solve time: 6.66679s

Total time steps: 36563 Simulation time: 10.0991s

SPE1B



IMPES

TMARCH

 $0.1\ 1\ 0.1\ 5\ 0.3\ 0.3\ 300\ 0.2\ 0.3\ 0.001$

Final time: 3655.5 Days

Total time steps: 4168
Total nonlin steps: 4168
Total linear steps: 7601
Linear solver time: 0.824397s
Simulation time: 1.99241s

OC_IMPES_1

0.1 1 0.1

Final time: 3655.5 Days

Total linear steps: 15679
Linear solve time: 1.03353s
Total time steps: 3964
Simulation time: 1.40656s


$OC_IMPES_0.1$


0.1 10.1 0.1

Final time: 3655.5 Days Total linear steps: 109441

Linear solve time: 5.84241s
Total time steps: 36563
Simulation time: 9.20546s

SPE9





Final time: 900 Days
Total time steps: 7767
Total nonlin steps: 7767
Total linear steps: 12465
Linear solver time: 57.9099s
Simulation time: 276.62s

OC_IMPES_1_wc

Final time: 900 Days
Total linear steps: 16808
Linear solve time: 48.808s
Total time steps: 4106
Simulation time: 63.845s

OC_IMPES_0.1_wc with well control

Final time: 900 Days
Total linear steps: 32056
Linear solve time: 83.3344s
Total time steps: 9000
Simulation time: 115.682s

OC_IMPES_1_nwc no well control
Final time: 900 Days
Total linear steps: 16455
Linear solve time: 48.4109s
Total time steps: 4033
Simulation time: 63.0615s

OC_IMPES_0.1_nwc

Final time: 900 Days
Total linear steps: 31955
Linear solve time: 84.0852s
Total time steps: 9000
Simulation time: 116.621s