

Power
X001
White Light
Y001
OUT
White Light
Y001
Oven OFF
X002
Oven ON
X006
OVEN
Y002
OVEN
Y002
OUT
Green Light
Y003
OUT
White Light
Y001
Tempature Sw...
X003
Red Light
Y004
OUT
White Light
Y001
Tempature Sw...
X003
Fan OFF
X004
OVEN
Y002
Fan ON
X005
Fan
Y005
Fan
Y005
OUT
Yellow Light
Y006
OUT