

RF02 programming guide

1. Brief description


RF02 is a low cost FSK transmit IC witch integrated all RF functions in a single chip. It only need a MCU, a crystal, a decouple capacitor and antenna to build a hi reliable FSK transmitter. The operation frequency can cover 300 to 1000MHz.

RF02 supports a command interface to setup frequency, deviation, output power and also data rate. No need any hardware adjustment when using in frequency-hopping applications

RF02 can be used in applications such as remote control toys, wireless alarm, wireless sensor, wireless keyboard/mouse, home-automation and wireless data collection.

2. Commands

1. Timing diagram



2. Configuration Setting Command

| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|----|----|------------|----|----|----|----|----|----|----|-------|
| | 1 | 0 | 0 | b1 | b0 | d2 | d1 | d0 | x 3 | x2 | x1 | x0 | ms | m2 | m1 | m0 | 8080h |

b1..b0: band select:

| b1 | b0 | band[MHz] |
|----|----|-----------|
| 0 | 1 | 433 |
| 1 | 0 | 868 |
| 1 | 1 | 915 |

d2..d0: select frequency of CLK pin

| d2 | d1 | d0 | CLK frequency[MHz] |
|----|----|----|--------------------|
| 0 | 0 | 0 | 1 |
| 0 | 0 | 1 | 1.25 |
| 0 | 1 | 0 | 1.66 |
| 0 | 1 | 1 | 2 |
| 1 | 0 | 0 | 2.5 |
| 1 | 0 | 1 | 3.33 |
| 1 | 1 | 0 | 5 |
| 1 | 1 | 1 | 10 |

CLK signal is derive form crystal oscillator and it can be applied to MCU clock in to save a second crystal.

If not used, please set bit "dc" to disable CLK output

x3..x0: select crystal load capacitor

| х3 | x2 | x1 | x0 | Load capacitor [pF] |
|----|----|----|----|---------------------|
| 0 | 0 | 0 | 0 | 8.5 |
| 0 | 0 | 0 | 1 | 9.0 |
| 0 | 0 | 1 | 0 | 9.5 |
| 0 | 0 | 1 | 1 | 10.0 |
| | | | | |
| 1 | 1 | 1 | 0 | 15.5 |
| 1 | 1 | 1 | 1 | 16.0 |

To integrate the load capacitor internal can not only save cost, but also adjust reference frequency by software

ms: select modulation polarity

m2..m0: select frequency deviation

| m2 | m1 | m0 | frequency deviation[kHz] |
|----|----|----|--------------------------|
| 0 | 0 | 0 | 30 |
| 0 | 0 | 1 | 60 |
| 0 | 1 | 0 | 90 |
| 0 | 1 | 1 | 120 |
| 1 | 0 | 0 | 150 |
| 1 | 0 | 1 | 180 |
| 1 | 1 | 0 | 210 |



3. Power Management Command

| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|---|---|----|----|----|----|----|----|----|----|-------|
| | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | a1 | a0 | ex | es | ea | eb | et | dc | C000h |

a1: Crystal oscillator and synthesizer are enabled by Data transmit Command and disable by Sleep command.

a0: Power amplifier is enabled by Data transmit Command and disable by Sleep Command.

ex: Enable crystal oscillator

es: Enable synthesizer

ea: Enable power amplifier

eb: Enable low battery detection funciton

et: Enable wake-up timer

dc: Disable output of CLK pin

4. Frequency Setting Command

| | | - | • | | U | | | | | | | | | | | | |
|-----|----|----|----|----|-----|-----|----|----|----|----|----|----|----|----|----|----|-------|
| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
| | 1 | 0 | 1 | 0 | f11 | f10 | f9 | f8 | f7 | f6 | f5 | f4 | f3 | f2 | f1 | f0 | A7D0h |

f11..f0: set operation frequency:

433band: Fc=430+F*0.0025 MHz 868band: Fc=860+F*0.0050 MHz

915band: Fc=900+F*0.0075 MHz

Fc is carrier frequency

5. Data Rate Command

| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|---|---|----|----|----|----|----|----|----|----|-------|
| | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 0 | r7 | r6 | r5 | r4 | r3 | r2 | r1 | r0 | C800h |

r7..r0: set data rate

BR=10000000/29/ (R+1)

BR is data rate

6. Power Setting Command

| bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|---|---|---|---|---|----|----|----|-----|
| | 1 | 0 | 1 | 1 | 0 | p2 | p1 | р0 | B0h |

p2..p0: set relative output power:



Pout=Pmax-P*3 [dBm]

Pmax is the max output power; it is related to the antenna impedance.

7. Low Battery Detector and Tx bit Synchronization Command

| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|---|---|-----|---|-----|----|----|----|----|----|-------|
| | 1 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | dwc | 0 | ebs | t4 | t3 | t2 | t1 | t0 | C200h |

dwc: Disable wake-up timer periodical calibration

ebs: Enable TX bit synchronization function

t4..t0: Set threshold voltage of Low battery detector

Vlb=2.2+T*0.1 [V]

8. Sleep Command

| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|---|---|----|----|----|----|----|----|----|----|-------|
| | 1 | 1 | 0 | 0 | 0 | 1 | 0 | 0 | s7 | s6 | s5 | s4 | s3 | s2 | s1 | s0 | C400h |

If crystal oscillator, synthesizer and power amplifier are auto-controlled, this command will close power amplifier and synthesizer immediately, then stop crystal oscillator after S periods of CLK signal

9. Wake-Up Timer Command

| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-------|
| | 1 | 1 | 1 | r4 | r3 | r2 | r1 | r0 | m7 | m6 | m5 | m4 | m3 | m2 | m1 | m0 | E000h |

The wake-up timer period is determined by:

$$T_{\text{wake-up}} = M * 2^R [ms]$$

For continual operation, bit 'et' must be cleared and set

10. Data Transmit Command

| bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----|---|---|---|---|---|---|---|---|
| | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 |

This command indicate that the following data on SDI pin is to be transmitted, the transmission stops if nSel return to hi.


11. Status Register Read Command


| bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | POR |
|-----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|-----|
| • | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |

This command is used to read internal status register content, output starts at 8_{th} clock of SCK.



3. Transmission Demo flow diagram






Note: After RF02 initialization, Open transmitter and use nIRQ as data rate clock. MCU write data bit on FSK pin at nIRQ falling edge.



4. Example 1(for AVR microcontroller)



copyright (c) 2006

Title: RFO2B simple example based on AVR C

Current version: v1.0

Function: Package send Demo

Processor ATMEGA48
Clock: 10MHz Crystal

Operate frequency: 434MHz
Data rate: 4.8kbps
Package size: 23byte
Author: Tank

Company: Hope microelectronic Co., Ltd.

Contact: +86-0755-86106557 E-MAIL: hopefsk@hoperf.com

Date: 2006-10-24

Connections

| ATMEGA48 SIDE | RF02B SIDE |
|---------------|------------|
| SCK | >SCK |
| MISO:NC | |
| MOSI | >SDI |
| SS | >nSEL |
| PB1 | >FSK |
| INTO< | nIRQ |

PCO~PC3: LEDO~LED3



#include <mega48.h>

```
#define DDR_IN
                         0
#define DDR OUT
                         1
#define PORT_SEL
                         PORTB
#define PIN_SEL
                         PINB
#define DDR_SEL
                         DDRB
#define PORT_SDI
                         PORTB
#define PIN_SDI
                         PINB
#define DDR_SDI
                         DDRB
#define PORT_SCK
                         PORTB
#define PIN_SCK
                         PINB
#define DDR_SCK
                         DDRB
#define PORT SDO
                         PORTB
#define PIN_SDO
                         PINB
#define DDR_SDO
                         DDRB
#define PB7
                         7//--\
#define PB6
                         6//
#define RFXX SCK
                         5//
#define RFXX SDO
                         4// RF PORT
#define RFXX_SDI
                         3//
#define RFXX_SEL
                         2//
                         1//
#define RFXX_DATA
#define PB0
                         0//--/
#define SEL_OUTPUT()
                         DDR_SEL |= (1<<RFXX_SEL)
#define HI_SEL()
                         PORT_SEL = (1<<RFXX_SEL)
                         PORT_SEL&=~(1<<RFXX_SEL)
#define LOW_SEL()
#define SDI_OUTPUT()
                         DDR SDI = (1 << RFXX SDI)
#define HI_SDI()
                         PORT_SDI = (1 << RFXX_SDI)
#define LOW_SDI()
                         PORT_SDI&=~(1<<RFXX_SDI)
#define SDO_INPUT()
                         DDR_SD0&= ^{\sim} (1<<RFXX_SD0)
#define SDO HI()
                         PIN_SDO&(1<<RFXX_SDO)
#define SCK_OUTPUT()
                         DDR\_SCK \mid = (1 << RFXX\_SCK)
#define HI_SCK()
                         PORT_SCK = (1 << RFXX_SCK)
```



#define LOW_SCK() PORT_SCK&=~(1<<RFXX_SCK)


```
void RFXX_PORT_INIT(void) {
  HI_SEL();
  HI SDI();
  LOW_SCK();
  SEL_OUTPUT();
  SDI_OUTPUT();
  SDO_INPUT();
  SCK_OUTPUT();
unsigned int RFXX_WRT_CMD(unsigned int aCmd) {
  unsigned char i;
  unsigned int temp;
  LOW_SCK();
  LOW_SEL();
  for(i=0;i<16;i++){
    temp<<=1;
    if(SDO HI()){
      temp = 0x0001;
    LOW_SCK();
    if(aCmd&0x8000){
      HI_SDI();
    }else{
      LOW SDI();
    }
    HI_SCK();
    aCmd <<=1;
  };
  LOW_SCK();
  HI_SEL();
  return(temp);
}
void RF02B_SEND(unsigned char aByte) {
  unsigned char i;
  for (i=0; i<8; i++) {
    while(PINB&(1<<RFXX_SD0));//Polling nIRQ</pre>
    while(!(PINB&(1<<RFXX_SDO)));
    if (aByte&0x80) {
      PORTB = (1 << RFXX_DATA);
    }else{
```

```
PORTB\&=^(1<<RFXX_DATA);
    }
    aByte<<=1;
}
void main(void)
  unsigned int i, j, ChkSum;
  RFXX_PORT_INIT();
  RFXX_WRT_CMD (0xCC00);
  RFXX_WRT_CMD (0x8B61);//433BAND, +/-90kHz
  RFXX_WRT_CMD(0xA640);//434MHz
  RFXX_WRT_CMD (0xD040);//RATE/2
  RFXX_WRT_CMD(0xC823);//4.8kbps
  RFXX WRT CMD (0xC220); //ENABLE BIT SYNC
  RFXX_WRT_CMD(0xC001);//CLOSE ALL
  PORTB = (1 < RFXX_DATA);
  DDRB = (1 << RFXX_DATA); //SET DATA OUTPUT
  while (1) {
    RFXX WRT CMD(0xC039);//START TX
    ChkSum=0;
    RF02B_SEND(0xAA);//PREAMBLE
    RF02B_SEND(0xAA);//PREAMBLE
    RF02B_SEND(0xAA);//PREAMBLE
    RF02B SEND(0x2D);//HEAD HI BYTE
    RF02B_SEND(0xD4);//HEAD LOW BYTE
    RF02B_SEND(0x30);//DATA0
    ChkSum+=0x30;
    RF02B_SEND(0x31); //DATA1
    ChkSum+=0x31;
    RF02B\_SEND(0x32);
    ChkSum+=0x32;
    RF02B\_SEND(0x33);
    ChkSum+=0x33;
    RF02B SEND (0x34);
    ChkSum+=0x34;
    RF02B\_SEND(0x35);
    ChkSum+=0x35;
```

```
RF02B SEND (0x36);
  ChkSum+=0x36;
  RF02B\_SEND(0x37);
  ChkSum+=0x37;
  RF02B SEND (0x38);
  ChkSum+=0x38;
  RF02B\_SEND(0x39);
  ChkSum+=0x39;
  RF02B\_SEND(0x3A);
  ChkSum+=0x3A;
  RF02B\_SEND(0x3B);
  ChkSum+=0x3B;
  RF02B\_SEND(0x3C);
  ChkSum+=0x3C;
  RF02B\_SEND(0x3D);
  ChkSum+=0x3D;
  RF02B_SEND(0x3E);
  ChkSum+=0x3E;
  RF02B_SEND(0x3F);//DATA15
  ChkSum+=0x3F;
  RF02B_SEND(ChkSum);//DATA16
  RF02B_SEND(0xAA);//DUMMY BYTE
  RFXX_WRT_CMD(0xC001);//CLOSE TX
  for (i=0; i<5000; i++) for (j=0; j<123; j++);
};
```



5. Example 2(for PIC microcontroller)



copyright (c) 2006

Title: RF02B simple example based on PIC C

Current version: v1.0

Function: Package send Demo

Processor PIC16F73 Clock: 10MHz Crystal

Operate frequency: 434MHz
Data rate: 4.8kbps
Package size: 23byte
Author: Robben

Company: Hope microelectronic Co., Ltd.

Contact: +86-0755-86106557 E-MAIL: hopefsk@hoperf.com

Date: 2006-11-10

TRISB4=0

#include "pic.h"

#define SCK_OUT()

typedef unsigned char uchar; typedef unsigned int uint;

#define SDI RB5
#define SCK RB4
#define nSEL RB2
#define FSK RB1
#define nIRQ RB7
#define SDO RB6
#define SDI_OUT() TRISB5=0

```
#define nSEL_OUT()
                     TRISB2=0
#define FSK_OUT()
                     TRISB1=0
#define nIRQ_IN()
                     TRISB7=1
#define SDO_IN()
                     TRISB6=1
void WriteO( void );
void Write1( void );
void WriteCMD( uint CMD );
void RF2_Init( void );
void DelayUs( uint us );
void WriteFSKbyte( uchar DATA );
void DelayMs(uint ms);
CONFIG (0x3FF2);
初始化端口
**************
void RF2_Init( void )
{
 nSEL=1;
 SDI=1;
 SCK=0;
 FSK=0;
 nSEL_OUT();
 SDI_OUT();
 SDO IN();
 SCK_OUT();
 FSK_OUT();
}
void main()
 uint ChkSum=0;
 RF2_Init();
 WriteCMD( 0xCC00 );
 WriteCMD( 0x8B61 );
 WriteCMD( 0xA640 );
 WriteCMD( 0xD040 );
 WriteCMD( 0xC823 );
 WriteCMD( 0xC220 );
 WriteCMD( 0xC001 );
 while(1)
```

```
WriteCMD( 0xC039 );
WriteFSKbyte( 0xAA );
WriteFSKbyte( 0xAA );
WriteFSKbyte( 0xAA );
WriteFSKbyte( 0x2D );
WriteFSKbyte( 0xD4 );
WriteFSKbyte( 0x30 );//DATA0
ChkSum+=0x30;
WriteFSKbyte( 0x31 );//DATA1
ChkSum+=0x31;
WriteFSKbyte( 0x32 );
ChkSum+=0x32;
WriteFSKbyte( 0x33 );
ChkSum+=0x33:
WriteFSKbyte( 0x34 );
ChkSum+=0x34;
WriteFSKbyte( 0x35 );
ChkSum+=0x35;
WriteFSKbyte( 0x36 );
ChkSum+=0x36;
WriteFSKbyte( 0x37 );
ChkSum+=0x37;
WriteFSKbyte( 0x38 );
ChkSum+=0x38;
WriteFSKbyte( 0x39 );
ChkSum+=0x39;
WriteFSKbyte( 0x3A );
ChkSum+=0x3A:
WriteFSKbyte( 0x3B );
ChkSum+=0x3B;
WriteFSKbyte( 0x3C );
ChkSum+=0x3C;
WriteFSKbyte(0x3D);
ChkSum+=0x3D;
WriteFSKbyte( 0x3E );
ChkSum+=0x3E;
WriteFSKbyte( 0x3F );//DATA15
ChkSum+=0x3F:
ChkSum&=0x0FF;
WriteFSKbyte( ChkSum );
WriteFSKbyte( 0xAA );
```

```
WriteCMD( 0xC001 );
   DelayMs( 1000 );
  }
}
/***********
命令字写 0,提供时序
************
void WriteO( void )
{
 SDI=0;
 SCK=0;
 NOP();
 SCK=1;
 NOP();
命令字写1,提供时序
*************
void Writel( void )
{
 SDI=1;
 SCK=0;
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
```

```
NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 NOP();
 SCK=1;
 NOP();
}
/************
写一个字节发送数据
*************/
void WriteFSKbyte( uchar DATA )
 uchar n=8;
 nSEL=1;
 while(n--)
    while(!nIRQ);
    while(nIRQ);
    if (DATA&0x80)
     FSK=1;
    else
     FSK=0;
    DATA=DATA<<1;
  }
/************
写一条命令字
*************
void WriteCMD( uint CMD )
 uchar n=16;
 SCK=0;
 nSEL=0;
 while(n--)
  {
    if (CMD&0x8000)
    Writel();
    else
    WriteO();
```

```
CMD=CMD<<1;
 }
 SCK=0;
 nSEL=1;
}
/*************
***************
void DelayUs( uint us )
 uint i;
 while( us-- )
  {
     i=2;
     while( i-- )
      {
       NOP();
  }
/************
延时
*************
void DelayMs(uint ms)
 uchar i;
 while (ms--)
  i=35;
  while(i--)
   DelayUs(1);
  }
 }
}
```



RF02 Program

HOPE MICROELECTRONICS CO.,LTD

Address: Rm B.8/F LiJingGe Emperor Regency 6012 ShenNan Rd, Shenzhen, China

Tel: 86-755-82973805
Fax: 86-755-82973550
Email: sales@hoperf.com
trade@hoperf.com

Website: http://www.hoperf.com http://www.hoperf.cn http://hoperf.en.alibaba.com This document may contain preliminary information and is subject to change by Hope Microelectronics without notice. Hope Microelectronics assumes no responsibility or liability for any use of the information contained herein. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Hope Microelectronics or third parties. The products described in this document are not intended for use in implantation or other direct life support applications where malfunction may result in the direct physical harm or injury to persons. NO WARRANTIES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MECHANTABILITY OR FITNESS FOR A ARTICULAR PURPOSE, ARE OFFERED IN THIS DOCUMENT.

©2006, HOPE MICROELECTRONICS CO.,LTD. All rights reserved.

Tel: +86-755-82973806 Fax: +86-755-82973550 E-mail: sales@hoperf.com http://www.hoperf.com