## Django configuration on Raspberry Pi 3B+

## Part 5 Reading RFID Data

Sr No	Steps
INO	Before running server install following module in virtual environment
	pip install pyserial
	or pip installupgrade pyserial
	pip installupgrade pyserial
	HTML Page
	<center></center>
	<h1>Scanned RFID is</h1> <h1>RFID{{name}}</h1>
	urls.py
	from django.contrib import admin from django.urls import path from . import views
	urlpatterns = [ path(",views.index), ]
	Connect RFID reader to USB port of Raspberri Pi and open terminal, run
	dmesg   grep tty note down USB port number, say USB0 is allotted
	open views.py and edit it as follows
	from django.shortcuts import render import serial,time
	<pre>def index(request):     ser = serial.Serial()     ser.port = "/dev/ttyUSB0"</pre>
	ser.open() if ser.isOpen():     read_data = ser.read(12) return render(request,'home.html',{'name':read_data})